




1	MTD 16655	Dash Panel Support Brkt.
2	MTD 16656	Dash Panel
3	MTD 710-0118	Hex Bolt 5/16-18 x .75" Lg.*
4	MTD 725-0963	Bulb
5	MTD 710-0776	Hex AB-Tap Scr. 1/4 x .62"
6	MTD 725-1058	Socket
7	MTD 712-0267	Hex Nut 5/16-18 Thd.
8	MTD 725-0634	Light Switch
9	MTD 723-0333	Gas Gauge
10	MTD 726-0207	Hose Clamp
11	MTD 726-0209	Cable Tie
12	MTD 736-0119	L-Wash. 5/16" I.D.
13	MTD 725-0267	Ignition Switch
14	MTD 725-0201	Ignition Key
15	MTD 751-0172	Fuel Tank
16	MTD 751-0173	Gas Line 24" Long
17	MTD 761-0157	Blade Brake Ass'y.
18	MTD 710-0134	Carriage Bolt 1/4-20 x .62"
19	MTD 710-0793	Ribbed Neck Bolt 3/8-24 x .8"
20	MTD 15607	Seat Pivot Brkt.
21	MTD 16660	Rear Fender
22	MTD 17284	Seat Hinge Support Brkt.-R. H.
23	MTD 17283	Seat Hinge Support Brkt.-L. H.
24	MTD 17133	Deck Lift Index Brkt.
25	MTD 725-0514	Battery
26	MTD 710-0602	Hex Self-Tap Screw 5/6-18 x 1" Lg.
27	MTD 710-0255	Truss Mach. Scr. 1/4-20 x .75" Lg.
28	MTD 710-0726	Hex AB-Tap Scr. 5/16 x .75" Lg.
30	MTD 710-0623	Hex Self-Tap Scr. 3/8-16 x .75" Lg.
31	MTD 712-0287	Hex Nut 1/4-20 Thd.
33	MTD 731-0871	Battery Box w/Cover
34	MTD 732-0548	Compression Spring
35	MTD 725-0222	Headlight
36	MTD 736-0242	Bell-Wash 5/16" I.D.
37	MTD 736-0329	L-Wash. 1/4" I.D.
38	MTD 710-0351	Truss Wash. Hd. Tap Scr. #10 x .5" Lg.
39	MTD 731-0881	Grille Insert ((Style 7))
40	MTD 731-0465	Bezel ((Style 7))
41	MTD 710-0346	C-Sunk Mach. Scr. 1/4-20 x 1.5"((Style 7))
42	MTD 09960	Headlight Retainer ((Style 7))
43	MTD 16622	Side Panel-R.H((Style 2))
	MTD 16621	Side Panel-L.H ((Style 2))
	MTD 14748	Side Panel-R.H.((Style 7))
	MTD 14749	Side Panel-L.H.((Style 7))
	MTD 14670	Side Panel-R.H.((320, 330, 340))
	MTD 17175	Side Panel-R.H.((350))
	MTD 14669	Side Panel-L.H.((Style 0))
44	MTD 731-0511	Trim Strip 31" Lg.
45	MTD 17025	Grille ((Style 2))
	MTD 14787	Grille ((Style 7))
	MTD 17028	Grille ((Style 0))
46	MTD 17131	Grille Mtg. Brkt.-L.H. ((Style 2))
	MTD 17143	Grille Mtg. Brkt.-L.H. ((Style 0, 7))
47	MTD 17132	Grille Mtg. Brkt.-R.H. ((Style 2))
	MTD 17144	Grille Mtg. Brkt.-R.H. ((Style 0, 7))

48	MTD 16681	Hood ((Style 2, 7))
	MTD 17146	Hood ((Style 0))
49	MTD 736-0217	L-Wash. 3/8" I.D.-H.D.
50	MTD 712-0241	Hex L-Nut 3/8-24 Thd.
51	MTD 710-0258	Hex Bolt 1/4-20 x .62" Lg.*
52	MTD 710-0473	Truss Mach. Scr. #10-24 x .5" Lg.
53	MTD 723-0308	Foot Pad-R.H.
54	MTD 723-0309	Foot Pad-L.H.
57	MTD 712-0380	Lock Nut 1/4-28 Thd.
58	MTD 722-0157	Foam Strip
59	MTD 723-0302	Hood Stop
60	MTD 731-0705	Headlight Housing
61	MTD 731-0706	Lens
62	MTD 732-0414	Hood Spring
64	MTD 712-0272	Hex Sems Nut #10-24 Thd.
65	MTD 736-0413	Spr. Wash. .39" I.D. x .62" O.D.
66	MTD 738-0724	Shld. Bolt
67	MTD 749-0722	Grille Support
68	MTD 731-0511	Trim Strip 81" Lg.
72	MTD 746-0617	Choke Control
73	MTD 831-0823	Throttle Control Box
74	MTD 710-0779	Truss AB-Tap Scr. #10 x .5"
75	MTD 746-0501	Throttle Wire
76	MTD 757-0345	Seat Assembly
78	MTD 736-0159	Flat Wash. .344" I.D. x .88" O.D.
79	MTD 722-0160	Bushing
80	MTD 726-0267	Clamp
81	MTD 712-0107	Hex L-Nut 1/4-20 Thd.
82	MTD 726-0175	Clamp
83	MTD 710-0227	Hex Tap Scr. #8 x .5" Lg.
84	MTD 725-1303	Spring Switch
85	MTD 732-0581	Ext. Spring 5.31" Lg.
86	MTD 17239	Seat Lift Brkt.
87	MTD 726-0222	Insulator Nut Plate
88	MTD 738-0155	Shld. Bolt .437" Dia. x .162" Lg.
89	MTD 738-0296	Shld. Bolt .437" Dia. x .268" Lg.
90	MTD 736-0141	Spr. Wash. .445" I.D. x .751" O. D.
91	MTD 710-0759	Hex Bolt 5/16-18 x 518" Lg.*
92	MTD 736-0426	Fiber Washer





1	MTD 14650 Front Axle Ass'y.-R.H.
2	MTD 16479 Front Axle Ass'y.-L. H .
3	MTD 16481 Steering Arm
4	MTD 710-0152 Hex Bolt 3/8-24 x 1" Lg.
5	MTD 710-0538 Hex Bolt 5/16-18 x .62"
6	MTD 710-0772 Hex Bolt 5/16-24 x 2" Lg.
7	MTD 711-0198 Ferrule
8	MTD 711-0809 Steering Drag Link
9	MTD 712-0237 Hex L-Nut 5/16-24 Thd.
10	MTD 712-0241 Hex Nut 3/8-24 Thd.
11	MTD 712-0267 Hex Nut 5/16-18 Thd.
12	MTD 712-0711 Hex Jam Nut, 3/8-24
13	MTD 714-0470 Cotter Pin 1/8 Dia.
14	MTD 717-0622 Steering Gear Segment
15	MTD 723-3018 Drag Link Ball Joint 3/8-24 Thd.
16	MTD 726-0214 Push Cap
17	MTD 736-0119 L-Wash. 5/16" I.D.
18	MTD 736-0169 L-Wash. 3/8" I.D.
19	MTD 736-0187 Fl-Wash. .64" I.D. x 1.24"
20	MTD 736-0343 Fl-Wash. .340" I.D. x 1.25"
22	MTD 736-0271 Spr. Wash. .32 I.D. x .62
23	MTD 736-0285 Fl-Wash. .635 I.D. x 1.585
24	MTD 17198 Retainer Plate
25	MTD 738-0141 Shld. Bolt .437 Dia. x .350
26	MTD 738-0730 Steering Shaft
27	MTD 741-0225 Hex Flange Brg. .634 Dia.
28	MTD 747-0558 Tie Rod 18.37 Lg.
29	MTD 750-0532 Spacer .985 I.D.
30	MTD 750-0535 Spacer .380 I.D.
31	MTD 16657 Front Pivot Bar Support Brkt.
32	MTD 16658 Rear Pivot Bar Support Brkt.
33	MTD 17127 Pivot Bar Ass'y.
34	MTD 710-0118 Hex Bolt 5/16-18 x .75" Lg.
35	MTD 734-1422 Front Wheel Ass'y. Comp. 13 x 6
	MTD 734-1421 Tire Only
36	MTD 734-0997 Rim Ass'y. Only
37	MTD 734-0255 Air Valve
38	MTD 741-0487 Flange Bearing .632 I.D.
40	MTD 714-0111 Cotter Pin 3/32" Dia.
41	MTD 736-0185 Fl-Wash. .406" I.D. x .75"
42	MTD 712-0237 Hex L-Nut 5/16-24 Thd.
43	MTD 741-0501 Steering Column Brg.
44	MTD 710-0837 Cr-Sunk Scr. #10 x 5/8" Lg.
45	MTD 731-0805 Steering Wheel
46	MTD 731-0220 Steering Wheel Cap
47	MTD 731-0484 Hub Cap
48	MTD 731-0559 Bellow Steering Column
49	MTD 736-0242 Bell-Wash. .345 I.D. x .88
50	MTD 712-0798 Hex Nut 3/8-16 Thd.
51	MTD 738-0728 Shld. Bolt 1/2" Dia. x 2.32"




1	MTD 16670 Engine Pulley Belt Guard Ass'y.
2	MTD 10-0776 Hex AB-Tap Scr. 1/4 x .62"
3	MTD 710-0833 Hex Bolt 5/16-18 x 51/4" Lg.
4	MTD 712-0267 Hex Nut 5/16-18 Thd.
5	MTD 736-0242 Bell-Wash. .345" I.D. x .88
6	MTD 710-0286 Truss-Mach. Scr. 1/4-20 x .50" Lg.
7	MTD 720-0165 Gear Shift Knob
8	MTD 736-0270 Bell-Wash. .265" I.D. x .75
11	MTD 712-0138 Hex Nut 1/4-28 Thd.
12	MTD 17128 Spring Retainer Brkt.
13	MTD 750-0721 Spacer. 5" I.D.
14	MTD 710-0559 Hex Bolt 1/4-28 x 1.75" Lg.
15	MTD 15891 Idler Bracket
16	MTD 16352 Variable Speed Torque Brkt. Ass'y.
17	MTD 16676 Variable Speed Brkt. Ass'y.
18	MTD 16679 Variable Speed Pivot Brkt.
19	MTD 710-0118 Hex Bolt 5/16-18 x .75" Lg.
20	MTD 710-0539 Hex Bolt 3/8-24 x 13/4" Lg. Gr. 5
21	MTD 710-0703 Carr. Bolt 1/4-20 x .75" Lg.
22	MTD 710-0757 Hex Bolt 7/16-20 x 1.5" Lg.
23	MTD 710-0937 Hex Bolt 3/8-16 x 2.5" Lg.
24	MTD 711-0768 Belt Guard Pin
25	MTD 712-0241 Hex Nut 3/8-24 Thd.*
27	MTD 712-0287 Hex Nut 1/4-20 Thd.
28	MTD 712-0798 Hex Nut 3/8-16 Thd.
29	MTD 712-0922 Hex Jam Nut 1/2-20 Thd.
30	MTD 726-0175 Clamp
31	MTD 716-0114 Snap Ring
32	MTD 717-0800 Variable Speed Pulley Ass'y.
33	MTD 717-0775 Transaxle Complete
34	MTD 736-0607 Ext. L-Wash. 5/16" I.D.
36	MTD 732-0384 Extension Spring 6.12" Lg.
37	MTD 732-0459 Extension Spring 7.5" Lg.
38	MTD 732-0568 Extension Spring 2.59" Lg.
39	MTD 736-0117 Fl-Wash. .385" I.D. x .620"
40	MTD 736-0119 L-Wash. 5/16" I.D.
41	MTD 736-0169 L-Wash. 3/8" I.D.
42	MTD 736-0171 L-Wash. 7/16" I.D.
43	MTD 736-0322 Fl-Wash. .450" I.D. x 1.25"
44	MTD 736-0329 L-Wash. 1/4" I.D.
45	MTD 736-0331 Bell-Wash. .39" I.D. x 1.13"
46	MTD 736-0355 Fl-Wash. .56" I.D. x 1.0" O.D.
47	MTD 736-0414 Washer "Teflon" .565 I.D.
48	MTD 736-0921 L-Wash. 1/2" I.D.
49	MTD 738-0569 Shaft .56" Dia. x 3.875" Lg.
50	MTD 741-0405 Thrust Brg. 1.25 O.D.
51	MTD 741-0419 Flanged Nyliner Brg.
52	MTD 741-0495 Nyliner Flanged Brg.
53	MTD 747-0688 Speed Control Link
54	MTD 750-0703 Spacer
55	MTD 754-0280 V-Belt
56	MTD 754-0281 V-Belt
57	MTD 756-0374 1/2 V-Pulley .500" I.D. x 8.00"
58	MTD 756-0437 Idler Pulley 3-1/8" Dia.
59	MTD 756-0508 Dbl. Pulley 6.0" Dia. x 3.56"
60	MTD 732-0303 Extension Spring 3.18" Lg.
61	MTD 732-0413 Extension Spring 7.08" Lg.
62	MTD 748-0234 Shld. Spacer. 500" Dia.
63	MTD 710-0176 Hex Bolt 5/16-18 x 2.75" Lg.
64	MTD 16714 Front Frame
65	MTD 16715 Rear Frame

66	MTD 16654 Transaxle Support Brkt.
67	MTD 16659 Transaxle Brkt. Reinforcement
68	MTD 710-0726 Hex Wash. AB-Tap Scr. 5/16 x.75" Lg.
69	MTD 710-0258 Hex Bolt 1/4-20 x .62" Lg.
70	MTD 725-0771 Solenoid
71	MTD 725-0459 Circuit Breaker
72	MTD 712-0158 Hex L-Nut 5/16-18 Thd.
73	MTD 710-0189 Hex Bolt 5/16-18 x 3.0" Lg.
74	MTD 710-0351 Truss Mach. B-Tap Scr. #10 x.50" Lg.
75	MTD 16689 Clutch/Brake Pedal Ass'y.
76	MTD 16691 Clutch/Brake Pedal Mounting Brkt.
77	MTD 710-0134 Carr. Bolt 1/4-20 x .62" Lg.
78	MTD 710-0597 Hex Bolt 1/4-20 x 1.0" Lg.
79	MTD 710-0599 Hex TT-Tap Scr. 1/4-20 x .5"
80	MTD 711-0198 Ferrule
81	MTD 712-0271 Hex Sems Nut 1/4-20 Thd.
82	MTD 714-0111 Cot-Pin 3/32" Dia. x 1.0" Lg.
83	MTD 714-0507 Cot-Pin 3/32" Dia. x .75" Lg.
84	MTD 732-0582 Switch Actuator
86	MTD 736-0256 FI-Wash. .635" I.D. x 1.0"
88	MTD 747-0686 Brake Rod
90	MTD 725-0976 Ground Wire 7.25" Lg.
91	MTD 16663 Speed Control Lever
92	MTD 16693 5 Speed Selector Brkt.
	MTD 16694 7 Speed Selector Brkt.
93	MTD 738-0141 Shld Bolt .437" Dia. x .35" Lg.
94	MTD 711-0677 Ferrule
	MTD 712-0267 Hex Nut 5/16-18 Thd.
96	MTD 714-0104 Intern. Cot-Pin 5/16" Dia.
98	MTD 736-0119 L-Wash. 5/16 I.D.
99	MTD 736-0264 FI-Wash. .344" I.D. x .62"
100	MTD 736-0463 FI-Wash. .25" I.D. x .62" O.D.
101	MTD 747-0675 Speed Control Rod
106	MTD 710-0627 Hex L-Bolt 5/16-24 x .75" Lg.
107	MTD 734-1424 Rear Wheel Ass'y. Comp.
108	MTD 734-1423 Turf Tread 16.0 x 7.50 Rear
109	MTD 734-1450 Rear Wheel Rim Ass'y.
110	MTD 736-0242 Bell-Wash. .345" I.D. x .88"
114	MTD 17178 Shift Lever Adjusting Link
115	MTD 16482 Shift Lever Spring Brkt.
117	MTD 710-0289 Hex Bolt 1/4-20 x .50 Lg.
119	MTD 714-0149 Intern. Cotter Pin
121	MTD 720-0175 Ball Knob
122	MTD 726-0231 Retaining Ring
123	MTD 732-0499 Compression Spring 1.5" Lg.
125	MTD 736-0226 FI-Wash. .469" I.D. x .88"
126	MTD 747-0694 Shift Rod Ass'y.
127	MTD 747-0685 Shift Rod
129	MTD 725-0577 Safety Switch
130	MTD 17179 Shift Lever Support
131	MTD 710-0227 Hex Wash. Hd. #8 x .50" Lg.
132	MTD 726-0222 Insulator Nut Plate
133	MTD 725-0758 Spring Switch
134	MTD 710-0502 Hex Wash. Hd. Tap Scr. 3/8-16 x 1.25" Lg.
135	MTD 710-0672 Hex Bolt 5/16-24 x 1-1/4" Lg. Grade 5
136	MTD 736-0119 L-Wash. 5/16" I.D.
137	MTD 712-0123 Hex Nut 5/16-24 Thd.
	MTD 751-0157 Muffler for 8 HP
	MTD 751-0157 Muffler for 10 HP
	MTD 751-0450 Muffler for 11 HP
	MTD 751-0443 Muffler for 12 HP


140	MTD 736-0222 Ext. L-Wash. 1/4" I.D.
141	MTD 736-0141 Wave Wash. .445" I.D.
	MTD 710-0157 Hex Bolt 5/16-24 x .75" Lg.
	MTD 710-0412 Hex Bolt 1/4-28 x .75" Lg.
	MTD 749-0727 Engine Support

www.emc-motoculture.com




1	MTD 16661 Lift Shaft Ass'y.
2	MTD 16682 Pivot Sleeve Ass'y.
3	MTD 16683 Deck Lock Out Brkt.
4	MTD 16688 Stabilizer Ass'y.
5	MTD 16692 Deck Lift Hanger
6	MTD 16698 Deck Lift Float Brkt.
7	MTD 710-0134 Carr. Bolt 1/4-20 x .62" Lg.
8	MTD 712-0158 Hex L-Nut 5/16-18 Thd.
9	MTD 712-0287 Hex Nut 1/4-20 Thd.
10	MTD 712-0711 Hex L-Nut 3/8-24 Thd.
11	MTD 712-0798 Hex Nut 3/8-16 Thd.
12	MTD 714-0104 Intern. Cot-Pin 5/16" Dia.
13	MTD 714-0115 Cot-Pin 118" Dia.
14	MTD 714-0507 Cot-Pin 3132" Dia.
15	MTD 720-0143 Grip
16	MTD 726-0267 Clamp
17	MTD 736-0169 L-Wash. 3/8 I.D.
19	MTD 736-0185 FI-Wash. .406" I.D. x .75" O.D.
20	MTD 736-0329 L-Wash. 1/4" I.D.
21	MTD 738-0281 Shld. Bolt .625 Dia. x .170" Lg.
22	MTD 741-0225 Hex Flange Brg.
23	MTD 741-0495 Nyliner Flanged Brg.
24	MTD 747-0677 J-Bolt 3/8-16 x 5.25" Lg.
25	MTD 747-0678 Connecting Rod-R.H.
26	MTD 747-0679 Connecting Rod-L.H.
27	MTD 747-0689 Lift Link
28	MTD 750-0547 Spacer
29	MTD 732-0153 Spring 8.65" Lg.
30	MTD 710-0793 Ribbed Neck Bolt 3/8-24 x .80" Lg.
31	MTD 712-0241 Hex Nut 3/8-24 Thd.*
32	MTD 736-0354 FI-Wash. 3/8" I.D.
33	MTD 732-0564 Deck Spring 10.33" Lg.
34	MTD 712-0267 Hex Nut 5/16-18 Thd.*
35	MTD 710-0602 Hex Wash. Hd. Tap Scr. 5/16-18 x 1.0" Lg.
36	MTD 736-0174 Spr. Wash. .625" I.D.
37	MTD 16716 Switch Activating Brkt.
38	MTD 725-0803 Safety Switch
39	MTD 736-0170 L-Wash. 5/16" I.D.
40	MTD 710-0224 Hex AB-Tap Scr. #10 x .5" Lg.

www.emsmotoculture.com




1	MTD 16607 Belt Guard Deck-L.H.
2	MTD 16608 Belt Guard Deck-R.H.
3	MTD 16666 Rear Deck Brkt.-R.H.
4	MTD 17101 32" Deck Ass'y.
	MTD 17134 32" Deck Ass'y. Comp. ((Service Only))
5	MTD 710-0152 Hex Bolt 3/8-24 x 1.0" Lg.
6	MTD 710-0195 Hex Bolt 1/4-28 x .62" Lg.
7	MTD 710-1012 Rib Neck Bolt
8	MTD 712-0123 Hex Nut 5/16-24 Thd.
9	MTD 712-0138 Hex Nut 1/4-28 Thd.
10	MTD 712-0181 Hex L-Nut 3/8-16 Thd.
12	MTD 734-0973 Deck Wheel
13	MTD 736-0105 Bell-Wash. .380" I.D. x .88
14	MTD 736-0119 L-Wash. 5/16" I.D.
15	MTD 736-0217 L-Wash. 3/8" I.D. H.D.
16	MTD 736-0270 Bell-Wash. .265" I.D. x .75
17	MTD 738-0373 Shld. Bolt .498" Dia. x 1.53 Lg.
18	MTD 742-0477 L.H High-Lift Blade
19	MTD 742-0480 R.H. High-Lift Blade
20	MTD 748-0300 Blade Adapter
21	MTD 754-0355 V-Belt
23	MTD 09164 Reinforcement Plate
24	MTD 09322 Brake Disc
27	MTD 712-0123 Hex Nut 5/16-24 Thd.
28	MTD 712-0318 Hex Jam Nut 5/8-18 Thd.
29	MTD 736-0119 L-Wash. 5/16" I.D.
30	MTD 736-0158 L-Wash. 5/8" I.D.
33	MTD 750-0456 Spacer
34	MTD 756-0486 5" Dia. Pulley
35	MTD 710-0258 Hex Scr. 1/4-20 x .62" Lg.
36	MTD 712-0287 Hex Nut 1/4-20 Thd.
37	MTD 736-0329 L-Wash. 1/4" I.D.
43	MTD 17136 Chute Ass'y.
44	MTD 17137 Chute Bracket
45	MTD 710-0255 Truss-Mach. Scr. 1/4-20 x .75" Lg.
46	MTD 711-0808 Hinge Pin
47	MTD 712-0298 Hex Jam Nut 1/4-20 Thd.
48	MTD 732-0542 Torsion Spring 1.14" Lg.
49	MTD 710-0888 Hex Bolt 5/16-24 x 1.0" Lg. ((Special))
50	MTD 717-0900 Blade Spindle Complete

www.emsmotoculture.com



1	MTD 714-0129 #4 Hi-Pro Key 3/32 x 5/16" Dia.
2	MTD 716-0115 Snap Ring .625" Shaft
3	MTD 710-0854 Hex Bolt 1/4-20 x 1.75" Lg.*
4	MTD 710-0378 Hex Bolt 5/16-18 x 2.5"
5	MTD 717-0764 Upper Housing
6	MTD 710-0889 Hex Fl-Bolt 1/4-20 x .88" Lg.*
7	MTD 712-0287 Hex Nut 1/4-20 Thd.*
8	MTD 717-0634 Input Shaft
9	MTD 721-0178 Square Seal 5/8" I.D.
10	MTD 736-0335 Thrust Washer 5/8" I.D. x 1.25" O.D.
11	MTD 717-0633 Pinion Input 14T
12	MTD 716-0108 Retaining Ring 7/16" Ext.
13	MTD 717-0768 Drive Shaft
14	MTD 741-0336 Flange Brg. 5/8" I.D. x 3/4" Lg.*
	MTD 736-0349 Fl-Wash. 5/8" I.D. x 1.0" O.D. x .020 Thk.
	MTD 736-0336 Fl-Wash. 5/8" I.D. x 1.0" O.D. x .030" Thk.
	MTD 736-0337 Fl-Wash. 5/8" I.D. x 1.0" O.D. x .040 Thk.
16	MTD 717-0757 Bevel Gear 42T
17	MTD 717-0667 Clutch Collar
18	MTD 717-1020 Miter Gear 15T (H.D.)
19	MTD 716-0142 Snap Ring
20	MTD 717-0690 Thrust Bearing 1/2" I.D. x 1.0" O.D.
21	MTD 710-0862 Pan Head Scr. 1/4-20 x .50" Lg. w/Patch
22	MTD 717-0766 Axle R.H. Ass'y.-Kit
23	MTD 741-0340 Sleeve Bearing 3/4" I.D. x 1.0" Lg.
24	MTD 721-0179 Oil Seal 3/4" I.D.
25	MTD 741-0339 Flange Bearing 3/4" I.D. x 15/16" Lg.
26	MTD 736-0188 Fl-Wash. .760" I.D. x 1.49" O.D.
27	MTD 717-0673 Cross Shaft
28	MTD 717-0777 Differential Housing Ass'y.
33	MTD 736-0188 Fl-Wash. .760" I.D. x 1.49" O.D.
34	MTD 717-0761 Lower Housing
35	MTD 750-0555 Spacer .53" O.D. x 3/8" Lg.
36	MTD 736-0329 L-Wash. 1/4" I.D.
37	MTD 710-0886 Hex Bolt 1/4-20 x 1.50" Lg. (Grade 5)
38	MTD 712-0335 Castle Nut 5/16-24 Thd.
39	MTD 736-0159 Fl-Wash. .844" I.D. x .875" O.D.
40	MTD 717-0772 Actuating Arm
41	MTD 717-0679 Brake Yoke
42	MTD 717-0682 Puck Plate
43	MTD 717-0678 Brake Puck
44	MTD 717-0765 Axle L.H. Ass'y.-Kit
45	MTD 717-0677 Brake Disc
46	MTD 741-0337 Flange Bearing 5/8" I.D. x 15/16" Lg.
47	MTD 714-0161 Woodruff Key 3/16 x 5/8 HT
48	MTD 717-0754 Shift Fork Ass'y.
49	MTD 741-0662 Ball Detent .250" Dia.
50	MTD 732-0863 Spring Detent
51	MTD 714-0169 #9 Hi-Pro Key 3/16" x 3/4" Dia. HT
52	MTD 741-0335 Needle Brg. 5/8" I.C. x 1/2" Lg.
58	MTD 717-0681 Sq. Hd. Bolt 5/16-24 Thd.
59	MTD 1544-013 Cotter Pin 3/32" Dia. x .50" Lg.
	MTD 737-0148 Grease-Shell



www.encycliculture.com

1	MTD 725-0976 Ground Wire
2	MTD 725-0514 Battery
3	MTD 725-0926 Electric Wire
4	MTD 725-0771 Solenoid
5	MTD 725-0459 Circuit Breaker
6	MTD 725-0758 Spring Switch
7	MTD 725-0803 Safety Switch
8	MTD 725-0267 Key Switch
9	MTD 725-0634 Light Switch
10	MTD 725-0577 Safety Switch (Black)
11	MTD 725-1336 Harness ((B&S))
	MTD 725-1337 Harness ((Tecumseh))
12	MTD 725-1058 Socket
13	MTD 725-0963 Lamp
14	MTD 725-0916 Ground Wire
15	MTD 725-1243 Headlight Harness
16	MTD 725-0222 Lamp
17	MTD 725-1303 Seat Switch

www.emc-motoculture.com