


ECHO / modèle SRM-250 E


(débroussailleuse)

Clé No.	Numéro de pièce	Qté	Désignation
1-5	159 905-2233 0	1	Protecteur
6	900 242-0601 6	3	Vis 5 x 16
7	101 514-2233 1	1	Couvercle
8	900 242-0401 0	1	Vis 4 x 10
9	101 011-2233 0	1	Cylindre
10	900 162-0602 0	4	Boulon
11	101 010-2233 0	1	Joint
14	890 112-2723 0	1	Étiquette
15	101 511-2233 0	1	Carter
16	900 220-0400 6	1	Vis 4 x 6
17	900 242-0602 0	4	Vis 5 x 20
19	100 217-0693 0	1	Joint d'étanchéité
20	900 702-0003 2	1	Criclip
21	900 200-2233 1	1	Carter moteur
22	-100 215-0383 0	2	Pion de centrage
1-23	100 242-2233 0	1	Joint
24	900 610-3620 1	1	Roulement à billes
25	100 100-2233 0	1	Vilebrequin cdt
26	100 143-0031 0	1	Chapeite
27	900 800-3800 1	1	Roulement à billes
28	100 213-0653 0	1	Joint d'étanchéité
29	900 242-0602 5	4	Vis 5 x 25
30	100 012-2233 0	1	Roulement à aiguilles
31	100 015-0463 0	2	Joie d'axe
32	100 013-2233 0	1	Axe de piston
33	100 010-2233 0	1	Piston
34	100 011-0633 0	2	Segment, piston

— CARTER MOTEUR, EMBIELLAGE, PISTON ET CYLINDRE —




— EMBRAYAGE, LANCEUR, ALLUMAGE —



Clé No.	Numéro de pièce	Qté	Désignation
1	159 010-1023 0	1	Bougie d'allumage
2	159 011-0343 2	1	Ressort
3	159 012-0343 3	1	Coiffe de bougie
4	152 112-05-23 0	1	Pressé lige
5	156 626-2233 1	1	Bobine d'allumage
6	900 242-0602 0	2	Vis 5 x 20
7	175 046-2233 2	2	Bobine
8	175 018-0653 4	2	Panneau d'allumage
9	175 009-0653 1	2	Rondelle
10	900 502-0000 8	2	Ecrou B
11	900 605-0000 8	2	Rondelle à ressort
12	900 600-0000 8	2	Rondelle
13	156 801-2233 0	2	Rotax
14	900 242-0401 2	4	Vis 4 x 12
15	177 305-0492 0	1	Cuquet cdt
16	177 200-2233 2	1	Lanceur cdt
17	900 241-0401 0	1	Vis 4 x 10
18	177 214-2013 0	1	Rondelle
19	177 215-0492 0	1	Poulie
20	177 226-0653 0	1	Corde
21	177 228-0653 0	1	Poignée
22	177 220-0653 0	1	Ressort spiral
23	177 209-2233 1	1	Balle
24	177 221-2233 2	1	Guide-corde
25	890 312-0623 1	1	Étiquette


Clé No.	Numéro de pièce	Qté	Désignation
3-5	130 010-2233 0	1	Joint
6	900 500-0000 5	2	Écrou 5
7	130 017-2723 0	1	Isolateur
8	900 242-0602 0	2	Vis 5 x 20
9	130 016-0623 0	1	Joint
10	123 000-2723 0	1	Calorateur
11	130 300-0603 1	1	Étui filtre
12	178 810-0502 0	1	Passé-lige
13	178 816-0693 0	1	Entroise
14	178 815-0672 0	1	Vélet, starter
15	130 021-2723 0	2	Vis
16	130 310-0663 0	1	Filtre à air
17	890 121-2143 0	1	Étiquette
18	130 307-2723 0	1	Couvercle
19	900 242-0401 8	2	Vis 4 x 18
20	101 014-2233 0	2	Goujon
21	145 510-2233 0	1	Joint
22	900 242-0601 0	1	Vis 5 x 10
23	145 810-2233 0	1	Pot d'échappement
24	145 842-2233 0	1	Rondelle
25	433 020-0083 0	2	Écrou de blocage
26	145 906-2233 0	1	Couvercle
27	900 242-0401 0	3	Vis 4 x 10

— CAPOTS, FILTRE A AIR, POT D'ÉCHAPPEMENT



— RÉSERVOIR A CARBURANT

Clé No.	Numéro de pièce	Qté	Désignation
4-3	900 603-0000 5	1	Rondelle
8	132 007-0763 0	1	Tuyau de carburant
9	-132 115-0492 0	1	Passé-lige
10	131 200-2133 0	1	Plongeur d'essence
11	131 600-2723 0	1	Bouchon cdt
12	-890 154-1273 0	1	Étiquette
13	-131 314-2233 0	1	Soupape
14	131 010-2723 0	1	Réservoir de carburant
16	131 925-2233 0	3	Coussin
18	305 110-2233 1	1	Support
4-19	900 242-0601 4	2	Vis 5 x 14
20	131 928-2233 0	1	Support
21	131 917-2233 0	1	Bande
22	131 931-2233 0	1	Entroise
23	900 242-0602 5	1	Vis 5 x 25
24	900 500-0000 5	1	Écrou 5
25	900 242-0601 2	1	Vis 5 x 12



Clé No.	Numéro de pièce	Qté	Désignation
5-5	610 011-2283 0	1	Axe de transmission
6	381 201-0893 0	2	Poignée avant
7	900 500-0000 5	2	Écrou 5
8	900 600-0000 5	2	Rondelle
9	900 220-0604 0	2	Vis
11	900 100-0601 8	1	Boulon
12	669 012-0333 0	1	Entroise
13	301 207-0893 0	1	Crochet
21	890 317-0913 1	1	Étiquette
23	610 206-2283 0	1	Carter cdt
24	-610 105-0893 0	5	Bague
25	175 005-2283 0	1	Tambour
26	900 702-0002 8	1	Criclip
27	900 802-0600 1	2	Roulement à billes
5-28	900 701-0001 2	1	Criclip
29	610 202-2283 1	1	Carter d'embrayage
30	900 242-0601 6	4	Vis 5 x 16
31	900 242-0602 0	4	Vis 5 x 20
32	610 906-2283 0	1	Coussin
33	610 905-2283 0	1	Coussin
34	900 142-0602 5	1	Boulon
36	301 600-2433 0	1	Cannele
37	-301 305-2433 0	1	Crochet

Remarque: 36 Inclusive 37.

— TUBE, POIGNÉE, HARNAIS




Table with 4 columns: Clé No., Numéro de pièce, Q'té, Désignation. Lists various mechanical parts like gears, bearings, and shafts.

Remarques: ** comprend les No. 5 à 32 ** comprend les No. 10 et 36 à 41




Table with 4 columns: Clé No., Numéro de pièce, Q'té, Désignation. Lists parts for the support and bracket assembly, including bearings, rollers, and shafts.





Table with 4 columns: Clé No., Numéro de pièce, Q'té, Désignation. Lists parts for the carburetor, including float valves, needles, and jets.



ECHO / modèles SRAC-200 et 300 (adaptation houe-bineuse)

Table for SRAC-200 with columns: Key No., Part Number, Q'ty, Description. Lists parts like housing gears, screws, washers, and blades.

Table for SRAC-300 with columns: Key No., Part Number, Q'ty, Description. Lists parts like housing gears, screws, washers, and blades.