


PARTS LIST

RIDING MOWER

12/30 (76cm)

31622

Read and keep this parts list book for future reference.
This parts list book contains drawings and part numbers
necessary to obtain repair parts.
See the back cover for repair part ordering information.



Record the following information about your unit. This information is necessary when ordering parts or in case of loss or theft.

WHERE PURCHASED: _____

DATE PURCHASED: Month _____ Day _____ Year _____

MODEL NO.: _____ DATE OF MANUFACTURE: _____




BUILT IN THE

USA

MODEL 31622x42A

REPAIR PARTS
CHASSIS & HOOD



P-83781

MODEL 31622x42A

REPAIR PARTS CHASSIS & HOOD


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seal	91965	30	Support, Grill	91723E700
2	Plate Assembly, Switch	91963Z	31	Screw	26x252
3	Spring, Compression	164x26	32	U-Nut	28x57
4	Spring, Seat	91964	33	Locknut, Flange	15x84
5	Slide, Spring	91822	34	Fastener, Plastic	193x1
6	Bolt, Shoulder	9x38	35	Screw	26x249
7	Support, Seal	92334E700	36	Mat	91900
8	Lockwasher	18x16	37	Tray, Battery	91695
9	Bolt, Hex	1x45	38	Cap. Console	92443E700
10	Locknut, Flange	15x98	39	Channel Assembly	91857E700
11	Bracket, Pivot	91729E700	40	Screw	20x154
12	Rod, Pivot	91730E700	41	Shd. Battery	91941
13	Cap. Push On	26x23	42	Plate, Shift Lever Adjuster	92360 BC
14	Screw, Tap	26x270	43	U-Nut	28x72
15	Fender, Apron	91724E700	44	Locknut	15x120
16	Hood	91802E244	45	Bolt, Shoulder	9x36
17	Grille, Upper	91736	46	Washer, Rubber	91751
18	Lens, Right	91734	47	Eyelet	91733
19	Lens, Left	91735	48	Panel, Grille	91800
20	Fender	91716E244	50	Trim, Edge	21765
21	Console Assembly	92361E700	—	Instruction Book (English)	F-93717
22	Screw	26x263	—	Instruction Book (French)	F-93717 FR
23	Dash Panel	93174E700	—	Repair Parts Book	F-93781
24	Bearing, Steering	93135	—	Decal, Left Hood	44x3681
25	Screw	26x238	—	Decal, Right Hood	44x3682
26	Bearing	93155	—	Decal, Top Console - Warning	44x1946
28	Grill, Lower	91722E244	—	Decal, Shift Pattern	44x2714
29	Frame Assembly	92500E700			

* Included with Key No. 21.

F-93711

MODEL 31622x42A

REPAIR PARTS
MOTION DRIVE



P-83781

MODEL 31622x42A


REPAIR PARTS MOTION DRIVE

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Guide, Belt	91754Z	28	Shift Lever & Yoke Assembly	92315Z
2	Locknut, Flange	15x84	29	Washer	17x148
3	Nut, Flange	15x78Z	30	Plate, Belt Guide	92501E700
4	Bolt, Hex	1x124	31	Bolt, Hex	1x82
5	Grip	91079	32	Lockwasher	18x32
6	Screw	26x214	33	Washer	17x180
7	Rod, Control	91727E700	34	Transaxle - Peerless 915**	—
8	Guide, Bracket	91825E700	35	Bolt, Hex	1x98
9	Screw	26x249	36	Bolt, Carriage	2x53
10	Clutch and Brake Pedal	21544	37	Bracket, Transaxle Torque	92270E700
11	Lever Assembly	91852E700	38	Woodruff Key	20697
12	Rod, Clutch	91508Z	39	Key, Square	21553
13	Nut, Adjustable	21920	40	Washer	17x100
14	Pin, Collar	30x20	41	Spacer, Transaxle	97x100Z
15	Bracket, Support	91713E700	42	Tire*	91923
16	Latch, Park Brake	91712Z	—	Tube	407049
17	Spring, Brake Extension	185x95	43	Wheel & Tire Assembly	92288-601
18	Washer	17x47Z	44	Stein, Valve	24373
19	Bracket Assembly, Idler	92029Z	45	Washer	17x115
20	Ring, Retainer	11x7	46	E-Ring	11x3
21	Bolt, Shoulder	9x39	47	Washer	17x146Z
22	Spring, Drive Extension	105x76	48	Locknut, Hex	15x43
23	Pulley, Motion Drive	91107	49	Hub Cap (Optional)	24582
24	Pulley, Backside Idler	91179	50	Nut, Flange	15x88
25	Belt, Motion Drive	37x61 37x67	51	Guide, Belt	20619
26	Knob, Shift Lever	91975	52	Frame Assembly	92500E700
27	Tolerance Ring	92008			

*When you order a tire make sure to give the brand name of the tire so that the tread pattern on the tire will match.
For information on Replacement Parts see the Central Parts Distributor in your area

MODEL 31622x42A

REPAIR PARTS
STEERING



F 93781

MODEL 31622x42A

REPAIR PARTS STEERING


Key No.	Description	Part No.
1	Wheel, Steering	92078
2	Nut, Hex	15x118
3	Bolt, Hex	1x86
4	Post, Steering	917142
5	Bolt, Hex	1x74
6	Screw	25x249
7	Bracket, Sector **	91716E700
8	Gear, Pinion	402075
9	Bearing **	91758
10	Bolt, Hex **	1x84
11	Locknut, Flange	15x87
13	Gear, Sector	402075
14	Bracket, Sector **	91708E700
15	Link, Drag	91749E700
16	Bolt, Hex	1x138
17	Support, Rear Axle	91702E700
18	Rod, Tie	90034E700
19	Pin, Cotter	30x49
20	Bearing	00035
21	Washer	17x57
22	Pin, Cotter	30x20
23	Washer	17x113
24	Spindle Assembly, Right	91828E700
25	Spindle Assembly, Axle & Left	91827SE
26	Support, Front Axle	91701E700
27	Tire	91012
—	Tube	407047
28	Stem, Valve	24373
29	Bearing, Wheel	91334
30	Washer	17x115
31	Wheel & Tire Assembly	92287-601
32	Bearing **	92097
33	Locknut, Flange **	15x113
36	Spacer, Pin **	92280
38	Hub Cap, (Optional)	24582

*When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.
**These parts are included when you order part number 402075 (Key Number 8 or 13)

E. 93781

MODEL 31622x42A

REPAIR PARTS
MOWER SUSPENSION



A-93781


MODEL 31622x42A

REPAIR PARTS MOWER SUSPENSION

Key No.	Description	Part No.
1	Grip	55449
2	Lever, Blade Control	91781Z
3	Bolt, Hex	25x3
4	Locknut, Hex	15x67
5	Lever Assembly, Switch	91P17E700
6	Bolt, Carriage	25x3
7	Spring, Torsion	166x32
8	Bracket, Adjuster Rod	92066E700
9	Nut, Flange	15x79
10	Nut, Adjusting	92131
11	Bracket, Adjuster Rod	92133E700
12	Pin, Hair	31x4
14	Washer	17x67
15	Pin, Pull	90827Z
17	Lever, Lower Blade Control	91787E700
18	Rod, Blade Control	92283Z
19	Plate, Adjuster	91741E700
20	Washer	17x103
22	Lifter Assembly	92135E700
23	Knob, Steel	91261
24	Grip	91398
25	Spring, Compression	164x21
26	Handle Assembly	91623E700
27	Screw	26x49
28	Link, Suspension	92064E700
30	Washer	17x91Z
31	Cover, Lift Lever (Optional)	92157
32	Screw	26x263
33	Nut, Adjusting	21920

MODEL 31622x42A

REPAIR PARTS
MOWER HOUSING



MODEL 31622x42A


REPAIR PARTS MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Rod, PTO	92283Z	30	Bracket Assembly, Right Lifter	92206E700
2	Locknut	15x100	31	Link	92064E700
3	Lockwasher	15x33	32	Nut, Flange	15x68
4	Locknut, Flange	15x84	33	Guide, Belt	91797E700
5	Pulley, Spined	91951	34	Nut, Hex	15x82
6	Pulley, Idler	91801	35	Hanger, Front	92202E700
7	Belt, Mower Drive	J7x74	37	Screw	25x44
8	Mandrel	91922	38	Rod, Hanger	92273Z
9	Spacer	91903	39	Washer	17x57
10	Housing, Mandrel	55962	40	Bracket, Front Hanger	92203E700
11	Bolt, Shoulder	9x30	41	Bolt, Carriage	2x53
12	Washer	17x46Z	42	Bolt	1x85
13	Screw	26x249	43	Screw	26x216
14	Pin, Cotter	30x20	44	Bolt	1x46
15	Bracket, Pivot	92209E700	45	Adapter, Blade	91926
16	Spring, Extension	15x91	46	Blade	55793E701
17	Indicator, Plastic	92163	47	Washer, Belleville	17x165
18	Support, Pivot Bracket	92208E700	48	Washer	17x165
19	Spring, Extension	15x90	49	Nut, Hex	15x100
20	Rod, Adjusting	91748Z	50	Deflector, Chute	55971
21	Nut, Adjustable	92131	51	Rod, Deflector	21197Z
22	Nut, Flange	15x79	52	Spring, Torsional	166x4
23	Support, Idler Arm	92211E700	53	Cap, Push On	24x23
24	Guide, Belt	20619	54	Hinge, Deflector	56213E700
25	Arm Assembly, Idler	92221	55	Locknut	15x43
26	Plate, Adjusting	91741E700	57	Bolt, Carriage	2x64
27	Washer	17x103Z	58	Wingnut	14x83
28	Pin, Hair	31x4	1-60	Mower Housing, Complete	403344
29	Bracket Assembly, Left Lifter	92207E700			

S
Q

MODEL 31622x42A

REPAIR PARTS ELECTRICAL SYSTEM



1-43751


MODEL 31622x42A

REPAIR PARTS
ELECTRICAL SYSTEM

Key No.	Description	Part No.
1	Switch, Seal Sensor	91031
2	Locknut	15456
3	Bolt, Hex	1x382
4	Battery	91414
—	Acid, Battery (Electrolyte)	55702
5	Cable, Battery Ground	24x9
6	Screw	26x249
7	Cable, Red Battery	24x12
8	Solenoid	24285
10	Nut, Hex	15x105
11	Washer, Shakeproof	19x40
12	Switch, Ignition	92377
13	Key, Ignition	20729
14	Harness, Chassis Wire	250x43
15	Fuse	54212
16	Holder, Fuse	407075
17	Switch, PTO	91299
18	Screw	26x233
19	Switch, Clutch	24273
20	Screw	25x2
21	Socket, Light	92372
22	Bulb, Light	90084
23	Harness, Light Wire	250x40
24	Cover, Terminal	54148

MODEL 31622x42A

REPAIR PARTS
ENGINE MOUNT



TS
IT

MODEL 31622x42A

REPAIR PARTS ENGINE MOUNT

Key No.	Description	Part No.
1	Fuel Cap	92317
2	Fuel Tank	91869
3	Hose Clamp	91174
4	Fuel Line	90871
5	Hose Clamp	91714
6	Screw	26x214
7	Screw	26x201
8	Throttle Control	91983
9	Engine*	—
10	Bolt	1x134
11	Shield, Heat	91277
12	Muffler	91271
13	Gasket	91309
14	Washer	19x6
15	Bolt, Engine Mount	25x7
16	Pulley, Slack	92318Z
17	Washer	17x170
18	Lockwasher	19x35
19	Bolt Hex	1x140

*The engine model, type and code numbers are on the engine. All parts to the engine are available from a Briggs & Stratton Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.