




REPAIR PARTS MANUAL
MODEL NO. 917-259440
Lawn Tractor


CRAFTSMAN®

168667 1.13.99
PRINTED IN U.S.

REPAIR PARTS

TRACTOR - -MODEL NO. 917.259440


SCHEMATIC



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

ELECTRICAL



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	144925	Battery 12 Volt 25 AMP Wet
2	74760412	Bolt Hex Hd 1/4-20 Unc X 3/4
16	153664	Switch Interlock Push-In
19	STD551125	Washer Lock 1/4
20	73350400	Nut Jam Hex 1/4-20 Unc
21	166182	Harness Asm Light W/4152J
22	4152J	Bulb Light #1156
24	4799J	Cable Starter 6Ga 11" Red
25	165987	Cable Battery Crd 56" Red
26	166180	Fuse 15 Amp
27	STD541425	Nut Keps Hex 1/4-20 Unc
28	127725X	Cable Ground 6Ga 18" Black
29	160784	Switch Plunger Normal Op Olive
30	140301	Switch Ignition 4Pos W/Lights
31	124211X	Nut Ignition #125
32	141226	Cover Switch Ignition #121
33	109310X	Key Ign Molded
40	166158	Harness Ign Crd Elect
41	71110408	Bolt Flk Fin Hex 1/4-20 Unc X 1/2
42	131563	Cover Terminal Red
43	145673	Solenoid
44	73640400	Nut Keps Blk Hex 1/4-20 Unc
45	122822X	Ammeter Rectangular 15 amp
50	154963	Switch PTO 3PDT Red Delta 96
51	140405	Ring Retainer PTO
52	141940	Protection Wire Loop
58	165943	Buzzer Crd
59	166299	Switch FBI CRD
65	STD611005	Screw Sltp #10-16 x 1/2 Ty-Ab
66	17490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
70	166668	Harness Engine B&S Reg W/AFTSO
80	146685	Harness Clutch EVX
81	109748X	Relay Asm

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

CHASSIS AND ENCLOSURES



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

CHASSIS AND ENCLOSURES

KEY NO.	PART NO.	DESCRIPTION
1	165480	Chassis Assembly
2	165606	Drawbar
3	17490612	Screw, Thd. Roll. 3/8-16 x 3/4
4	STD551025	Washer 13/32 x 3/4 x 16 Gauge
5	155272	Bumper Hood/Dash
6	155923	Saddle
8	126471X	Clip Insulator 13/32 Mtg. Hole
9	154587X011	Dash Slksr
10	STD533710	Bolt, Carriage 3/8-16 x 3/4
11	155927	Panel, Dash, L.H.
12	145660	Clip, Tinnerman Grille P/L
13	155934X010	Panel, Asm. Dash R.H.
14	17490608	Screw Thdrol 3/8-16 x 1/2
15	74180512	Screw, Machine, Truss Head 5/16-18 UNC x 3/4
16	STD541431	Nut
17	144983X558	Hood Assembly
18	126938X	Bumper Hood
24	STD523710	Bolt
25	19131312	Washer 13/32 x 13/16 x 12 Gauge
26	STD541437	Nut
28	145198X558	Grille PL
29	155217X599	Lens, Grille
30	165714X558	Fender
31	165156	Bracket, Fender Support
33	145244X558	Footrest, L.H.
34	145243X558	Footrest, R.H.
35	STD533107	Bolt
37	17490508	Screw Thdrol 5/16-18 x 1/2 TYT
38	139886	Pivot Bracket Assembly, L.H.
39	139887	Pivot Bracket Assembly, R.H.
51	73800400	Nut Lock w/Insert 1/4-20 UNC
52	19091416	Washer 9/32 x 7/8 x 16 Ga.
53	145201	Bracket, Grille LH
54	161464	Screw Hex WSHD 8-18 x 7/8
55	145202	Bracket, Grille RH
57	STD522507	Bolt, Fin Hex 1/4-20 UNC x .75
102	2751R	Clip line Fule 13/32 Mtg Hole


KEY NO.	PART NO.	DESCRIPTION
140	158418	Bracket Front Suspension
145	156524	Rod Pivot Chassis/Hood
162	165672	Bracket Exten Chassis Lh CRD
163	165673	Bracket Exten Chassis Rh CRD
164	165605	Support Battery CRD
165	165742X428	Cover Battery CRD Lt
167	165779	Support Asm. Backplate WLDMNT
168	72050412	Bolt, RDHD SHT NK 1/4-20 x 1-1/2
169	123976X	Nut, Lock 1/4 LGE FLG Gr. 5 Zinc
170	165607	Cover, Backplate Plastic Black
171	74520640	Bolt, Fin Hex 3/8-16 x 2-1/2 Gr. 5
172	19132016	Washer 13/32 x 1-1/4 x 16 Ga.
173	STD541437	Nut, Keys Hex 3/8-16 UNC
174	165939	Bracket Switch FBI CRD
175	166212	Guard Door Rear CRD
176	128600	Pin Hinge Pivot
177	132796	Spring Bagger Top LH Black
178	STD560997	Pin Cotter 3/32 x 3/4 Cad Zinc
179	165942	Rod Pivot FBI CRD
180	74760516	Bolt Hex HD 5/16-18 UNC x 1
181	STD541431	Nut Crownlock 5/16-18
182	138200	Washer .385 x .625 x 11 Ga.
183	STD551037	Washer 13/32 x 13/16 x 16 Ga.
184	166129	Bracket Actuator Bagger CRD
185	165940	Tube Lever Switch FBI CRD
186	160793	Latch Asm Mulch/Bagger
187	2029J	Nut Weld .327/.304 #10-24
188	19061216	Washer #10
189	STD551110	Washer Lock #10
190	71161010	Screw Truss Hd Phil 10-24 x 5/8
192	17490624	Screw Thdrol 3/8-16 x 1-1/2
193	17720410	Screw Hex Thd Cut 1/4-20 x 5/8
194	17060612	Screw 3/8-16 x .75
--	5479J	Plug, Button

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

DRIVE



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

DRIVE


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle (See Breakdown)	63	145868	Pulley, Clutch elect EVX 1"
2	146682	Peerless 206-546	65	STD551143	Washer
3	165999	Spring Brake Return	66	154778	Keeper, Belt Engine F-Proof
4	12000028	Pulley Transaxle	74	137057	Spacer, Axle
5	121520X	Ring Retainer #5100-62	75	121749X	Washer 25/32 x 1-1/4 x 16 Ga.
8	165619	Strap Torque 30 Degrees	76	STD581075	Ring, E
9	167162	Rod, Shift Fender Adjust Lt	77	123583X	Key, Square
10	STD561210	Clutch Ele EVX 80 W/Hard Brake	78	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
11	105701X	Pin, Cotter 1/8 x 1	79	STD580025	Key Woodruff #9 3/16 x 3/4
13	74550412	Wash Plate Sht .388 Square Hole	80	145090	Arm Shift Front 20" Tires
14	STD551125	Bolt 1/4-28 Unf Gr 8 w/Patch	82	123782X	Spring, Torsion
16	STD541431	Washer, Lock Hvy Helical	83	10171216	Washer 17/32 x 3/4 x 16 Ga.
18	STD523710	Nut Lock Hex W/Wsh 5/16-18 Unc	84	165621	Link, Shift
19	STD541437	Bolt Hex 3/8-16 UNC x 1 Gr.5	96	STD624003	Spring, Retainer 1"
20	150280	Nut Lock Hex W/Wsh 3/8-16 Unc	100	19111216	Washer 11/32 x 3/4 x 16 Ga.
21	106933X	Bolt, Hex 7/16-20 x 4-1/4 5 Ga 1.38	112	19091210	Washer 9/32 x 3/4 x 10 Ga
22	165811	Knob Rd 1/2-13 Plstc Thds Blk	145	74490540	Bolt Hex FGHD 5/16-18 x Gr 5
23	154978	Rod, Brake CRD Pmst	150	165850	Bushing, Bellcrank Grnd Dr
24	STD541237	Bracket asm Clutch Mtg. EVX 97	151	19133210	Washer 13/32 x 2 x 10 Ga.
25	106888X	Nut	153	74760516	Bolt Hex Hd 5/16-18 Unc x 1
26	STD551037	Spring, Rod, Brake	156	166002	Washer Srted 5/16ID x 1.125
27	STD561210	Washer 13/32 x 13/16 x 16 Ga.	158	165589	Bracket Shift Mount
28	145204	Pin, Cotter 1/8 x 3/4	159	165494	Hub Tapered Flange Shift Lt
29	124236X	Rod, Parking Brake	160	19292010	Washer 29/32 x 1-1/4 x 16 Ga.
30	130807	Cap, Parking Brake	161	72140400	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
32	STD523107	Bracket, Mfg. Transaxle	162	73680400	Nut Crownlock 1/4-20 Unc
33	STD533107	Bolt Hex 5/16-18 UNC x 3/4	163	74780416	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
34	165496	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4	164	19091010	Washer 5/8 x .281 x 10 Ga.
35	120183X	Shaft, Asm Pedal Foot CRD	165	165623	Bracket Pivot Lever
36	STD551062	Bearing, Nylon	166	166880	Screw 5/16-18 x 5/8
37	STD571810	Washer 21/32 x 1 x 16 Ga.	167	165588	Bracket Support Shift CRD
38	165936	Pin, Roll 3/16 x 1"	168	165492	Boit Shoulder 5/16-18 x .561
39	74760644	Pulley Flat Composite 3.06"	171	17490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
40	4470J	Bolt Fin Hex 3/8-16 x 2-3/4	172	165635	Shaft Shift Front CRD
42	19131312	Spacer, Split 395 x 59 Bzp	177	165932	Keeper Flat Idler 3.06" CRD
47	127783	Washer 13/32 x 13/16 x 12 Ga.	178	165933	Keeper Belt Idler 1.88" CRD
48	154407	Pulley, Idler, V Groove Plstic	179	120958X	Washer Sintered
49	123205X	Bellcrank Clutch Grnd Drv	180	165630	Pulley Flat Idler 1.88"
50	STD523715	Retainer, Belt Style Spring	181	165797	Bracket Idler Ground Drive CRD
51	STD541437	Bolt Hex Hd 3/8-16 UNC x 1-1/2	182	165634	Keeper Belt 2.5" Od V-Idler CRD
52	STD541431	Nut, Crownlock 3/8-16 UNC	183	165626	Pulley V-Idler 2.50" Od CRD
53	105710X	Nut Crownlock 5/16-18	184	17490644	Screw Hexwsh Thdrol 3/8-16 x 2-3/4
55	105709X	Link, Clutch 7.66	187	17490620	Screw Thdrol 3/8-16 x 1-1/4 TT
56	STD523712	Spring, Return, Clutch	188	110436X	Bushing Snap Split
57	165631	Bolt, Hex 3/8-16 UNC x 1-1/4			
61	17490612	V-Belt Kev 111" Pmst CRD			
62	8883R	Screw, Thdrol 3/8-16 x 3/4 Ty-TT			
		Cover, Pedal			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

STEERING ASSEMBLY



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

STEERING ASSEMBLY


KEY NO.	PART NO.	DESCRIPTION
1	139768	Steering Wheel
2	137094	Front Axle Assembly
3	157479	Spindle Assembly, L.H.
4	157478	Spindle Assembly, R.H.
5	6266H	Bearing, Race, Thrust, Hardened
6	121748X	Washer 25/32 x 1-5/8 x 16 Gauge
7	19272016	Washer 27/32 x 1-1/4 x 16 Gauge
8	12000029	Ring, Klip
10	154432	Link, Drag
11	STD551137	Washer, Lock
13	167118	Spacer Axle
15	73901000	Nut, Lock, Flange 5/8-11 UNC
17	156546	Shaft Assembly, Steering
18	57079	Washer, Thrust .515 x .750 x .033
19	160395	Support, Shaft
22	165857	Screw Hex Wshhd Torx
23	165851	Pittman Shaft Assembly
25	154406	Bracket, Steering
27	136874	Gear, Sector
29	17490612	Screw, Thd., Roll. 3/8-16 x 3/4
32	137347	Rod, Tie
36	155099	Bushing, Steering
37	152927	Screw TT #10-32 x 5 x 3/8 Flange
38	139769	Cap Wheel Steering
39	19133808	Washer 13/32 x 2-3/8 x 8 Gauge
40	STD541537	Nut Lock Center 3/8-24 Unf
41	100711L	Adaptor, Steering Wheel
42	145054	Boot, Steering Dash P/L Mtl
43	121749X	Washer 25/32 x 1-1/4 x 16 Gauge
44	153720	Extension Steering Non-Adjust
46	121232X	Cap, Spindle
47	6855M	Fitting, Grease
51	STD541431	Nut Lock Hex W/Ins 5/16-18 UNC
54	STD523112	Bolt Fin Hex 5/16-18 UNC x 1-1/4
62	167902	Kit, Steering Assembly, Service
63	STD523710	Bolt Fin Hex 3/8-16 unc. x 1 Gr. 5
65	154780	Spacer Axle
66	154404	Bearing Arm Pittman
67	74781044	Bolt Fin Hex 5/8-11unc x 2-3/4
68	154429	Brace Axle
74	109850X	Joint Asm Ball Rh Service
75	109851X	Joint Asm Ball Lh Service
76	137156	Rod Tie Ball J Adj. VGT Service
77	73700600	Nut Hex Jam 3/8-24 Unf Lh
78	73360600	Nut Hex Jam 3/8-24
79	19182012	Washer 13/32 x 1-1/4 x 12 Ga
80	74950612	Bolt Hex Nylon 3/8-16 x 3/4

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

SEAT ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION
1	140122	Seat
2	140551	Bracket Pnt Pivot Seat (blk)
5	145006	Clip Push In Hinged
7	124181X	Spring Seat Cprsn 2 250 Blk Zi
8	17490616	Screw Thdrol 3/8-16 X 1 Ty-tt
9	19131614	Washer 13/32 X 1 X 14 Ga
10	155925	Pan Pnt Seat (blk)
11	166369	Knob Seat Adj Wingnut
12	121246X	Bracket Pnt Mounting Switch
13	121248X	Bushing Snap Blk Nyl 50 Id


KEY NO.	PART NO.	DESCRIPTION
14	72050412	Bolt Rdhd Sht Nk 1/4-20x1-1/2
15	134300	Spacer Split .28 X .96 Zinc
16	121250X	Spring Cprsn
17	123976X	Nut Lock 1/4 Lge Flg Gr 5 Zinc
21	153236	Bolt Shoulder 5/16-18 Unc-2A
22	73800500	Nut Hex Lock w/lns 5/16-18
24	19171912	Washer 17/32 X 1-3/16 X 12 Ga.
25	127018X	Bolt Shoulder 5/16-18 X 62

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440


DECALS



KEY NO.	PART NO.	DESCRIPTION
1	145498	Decal Read Owner's Manual Sym
2	165393	Decal Hp Engine
3	163200	Decal Hood Rh
4	163202	Decal Hood Lh
5	166960	Decal Bypass Fender
6	126187X	Decal 100 DBA
8	145437	Decal Europe Stand Ce
9	163204	Decal Fender Logo
10	145005	Decal Bat Dan/Poi P/L Sym Wpn
11	145494	Decal Mower Cut Finger Symbol
12	159737	Decal Brake/Clutch Symbol Lt
13	166959	Decal Warn Back Plate CRD
14	159736	Decal Chassis Hot Muffler

KEY NO.	PART NO.	DESCRIPTION
15	166961	Decal Oper Bag Presence CRD
16	162598	Decal Drawbar Load Limit
17	140837	Decal Saddle Brake Parking
18	133179	Decal Mower QC System
19	166963	Decal Console CRD White
20	168663	Decal Fender 6/36 Sears Euro
21	166286	Decal Deck Sch 92 CRD
23	163249	Decal Panel Dash
	138311	Decal Lift Handle
	157199	Pad Footrest
	168665	Manual Operator's (Euro)
	168666	Manual Operator's (Scand)
	168667	Manual Parts

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	59192	Cap Value Tire
2	65139	Stem Value
3	106222X	Tire F Ts 15 X 6 0 - 6 Service
4	59904	Tube Inner Front #35060
5	106732X427	Rim Asm 6"front White Service
6	278H	Fitting Grease
7	9040H	Bearing Flange
8	106108X427	Rim Asm 8" rear White Service
9	106268X	Tire R Ts 18 x 9.5-8 Service
10	7152J	Tube Rear 9 5 X 8 Service
11	104757X	Cap Axle Blk 1 50 X 1 00
--	144334	Sealant, Tire (10 oz. tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

ENGINE



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

ENGINE


KEY NO.	PART NO.	DESCRIPTION
1	162158	Control Throt /Ch Lh
2	17720410	Screw Hex Thd Cut 1/4-20x5/8 T
3	-----	Engine (See Breakdown) Briggs Model 287707
4	137352	Muffler Exhaust B&S Lt
13	165291	Gasket 1 313 Id Tin Plated
14	13280324	Nipple Pipe 3/8 Npt X 3"
15	13200300	Elbow Std 90 Degree 3/8-18 Npt
16	STD551237	Washer Lock Ext Tooth 3/8
23	159880	Shield Browning/Debris Guard
29	137180	Arrestor Spark
31	109202X	Tank Fuel 1.25 Fr
32	158990	Cap Asm Fuel
33	123487X	Clamp Hose Blk
35	17490512	Screw, Thdrol 5/16-18 x 3/4 Tyt
37	137040	Line Fuel 20"
38	-----	Plug Oil Drain (Order From Engine Manufacturer)
44	17490412	Screw Hexwsh Thdrol 1/4-20x3/4
46	19091416	Washer 9/32 X 7/8 X 16ga
62	STD551131	Washer Lock Hvy Flcl Spr 5/16
66	127951	Stop Throttle 3000 Rpm
72	71070512	Screw Hex Hd Cap 5/16-18x3/4
78	17490620	Screw Thdrol 3/8-16x1-1/4 Tytt
81	128861	Nut Flange 1/4-20 Starter Nut

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

MOWER LIFT



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

MOWER LIFT


KEY NO.	PART NO.	DESCRIPTION
1	159460	Washer Asm Inner Spring W/ Plunger
2	159471	Shaft Asm. Lift
3	105767X	Pin Groove
4	STD581062	E Ring #5133-62
5	19211621	Washer 21/32 x 1 x 21 Ga.
6	120183X	Bearing Nylon
7	125631X	Grip Handle
8	122365X	Button Plunger Red
11	165829	Link Asm Lift L.H.
12	165831	Link Asm Lift R.H.
13	STD624008	Retainer Spring
15	127218	Link Front
16	73350800	Nut Jam Hex 1/2-13 Unc
17	130171	Trunnion Blk Zinc
18	73680800	Nut Crownlock 1/2-13 Unc
19	139868	Arm Suspension Mower
20	163552	Retainer Spring
31	140302	Bearing, Pvt. Lift. Spherical
32	73540600	Nut Crownlock 3/8-24

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

MOWER



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

MOWER


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	165552	Housing Asm. Mower 92 CRD	30	157722	Screw Thd Rolling Washer Head
2	STD533107	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4	31	129963	Washer Spacer Mower Vented
3	165569	Bracket Asm. S-Bar Chass 92 CRD	32	153531	Mandrel Pulley 36 & 46
4	165558	Bracket Bar Sway Deck 92 CRD	33	137266	Nut Flg Top Lock Cntr B 9/16
5	STD624008	Retainer Spring	34	165239	Bracket Gauge Wheel Lf 92 CRD
6	165557	Bar Sway 92 CRD	36	146763	Pulley Idler V-Groove Dim 4.25
8	850857	Bolt 3/8-24 x 1.25 Gr8 Patched	37	STD551037	Washer 11/32 x 13/16 x 16 Ga
9	STD551137	Washer Lock Hvy 3/8 Unplated	40	STD541437	Nut Crown Lock 3/8-16 Unc
10	140296	Washer Hard Blade Mower vented	44	165724	Cover Mandrel Lh 92 CRD
11	165560	Blade 3-1 Lh 92 CRD	45	165556	Cover Mandrel Rh 92 CRD
12	129895	Bearing Ball #6204 (Mandrel)	46	137729	Screw Thd Roll 1/4-20 x 5/8
13	137645	Shaft Asm. W/Lower Bearing	55	165445	Arm Idler 92 CRD
14	128774	Housing Mandrel Vented (Machd)	56	122052X	Spacer Retainer PM Mower
15	110485X	Bearing Ball Mandrel	61	165945	Spring Tension Belt
16	165561	Blade 3-1 Rh 92 CRD	68	165555	Hex-Belt 92 Mower 105AA
17	STD533712	Bolt Carriage 3/8-16 x 1-1/4	69	165482	Shaft Asm W/Lwr Brg Rh Thd CRD
18	STD533710	Bolt Rdhd Sqnk 3/8-16 x 1 Gr5	84	156085	Keeper Belt Idler
19	132827	Bolt Shoulder 5/16-18 Thd Form	124	72110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr5
20	165484	Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd	128	153390	Washer Felt
21	STD541431	Nut Crown Lock 5/16-18	130	STD533107	Bolt Rdhdsqnk 5/16-18 Unc x 3/4
22	165243	Bracket Idler Sprt RR 92 CRD	131	165661	Chute Bagger CRD 92cm
23	165446	Bracket Idler Sprt RF 92 CRD	--	130794	Mandrel Asm Service
24	165242	Bracket Suspension LF 92 CRD	--	165579	Mandrel Asm CRD Lh Threads SVC
25	165244	Bracket Suspension RF 92 CRD	--	165578	Deck Mower Complete
26	165237	Brace Support Susp Frt CRD			
27	165568	Bracket Asm. Susp RR 92 CRD			
28	165567	Bracket Asm. Susp LR 92 CRD			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

BAGGER



REPAIR PARTS

TRACTOR- -MODEL NO. 917.259440

BAGGER


KEY NO.	PART NO.	DESCRIPTION
1	165249	Tube Handle Bagger CRD
2	72140416	Bolt Carriage 1/4-20 x 2.0 Gr.5
3	123976X	Nut Lock 1/4 Lge Flg Gr. 5 Zinc
4	165693	Handle Grab Plastic Black
5	74981024	Screw Pan Head #10-24 x 1.50 Blk
6	74981032	Screw Pan Hd
7	73401000	Nut Wiz Lock Hex Serr/Hd 10-24
8	165715X558	Cover Bagger Plastic CRD
9	72140418	Bolt Carriage 1/4-20 x 2.25 Gr.5
10	165716	Support AsmWldmnt Bagger CRD
11	165719	Bracket Support Upper Bag CRD
12	165735 *	Bracket Pivot Bagger L CRD
13	STD533707	Bolt Rdhd Sht Sqnk 3/8-16 x 3/4
14	74520640	Bolt Hex 3/8-16 x 2 1/2 Gr.5
16	73900600	Nut Lock Flg 3/8-16 Unc
17	STD533107	Bolt Rdhd Sht Sqnk 5/16 -18 Unc x 3/4
18	19112016	Washer 11/32 x 1.25 x 16 Ga.
19	STD541431	Nut Lock Hex W/Ins 5/16-18 Unc Pl
20	165736	Bracket Pivot Bagger RH CRD
21	165780	Bag Asm CRD
22	165781	Bracket Side Bagger CRD
23	165782	Tube Upper Bagger CRD
24	165783	Tube Pivot Bagger CRD
25	165784	Tube Front Bagger CRD
26	165785	Tube Lower Bagger CRD
27	165786	Grommet Extruded Cut1/8
28	165787	Strip Handle Black
29	165839	Plate Stop Bagger handle CRD
30	72140410	Bolt Carriage 1/4-20 x 1 Gr.5
31	STD624000	Retainer Spring 1" Zinc/Cad
32	126875X	Rivet Rd Hd Drilled 3/8 Dia

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR -- MODEL NUMBER 917.259440

PEERLESS PMST TRANSAXLE - MODEL NUMBER 206-546



KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 772147	Transaxle Cover	42 792073A	Screw 1/4-20 x 1-1/4"
2 780086A	Needle Bearing 5/8"	42A 792085A	Screw 1/4-20 x 2-1/4"
3 770128	Transaxle Case	43 792075	Locknut 5/16-24
4B 776406	Countershaft	44 790025	Brake Pad Holder
5 776409	Output Shaft	45 786066	Spacer .2625 x 1.0
6 778364	Spur Gear (38 teeth)	46 786086	Brake Lever Bracket
6A 778369	Spur Gear (15 teeth-steel)	47 774690	Axle (11-15 1/8" long)
7 778330	Spur Gear (11 teeth)	48 774691	Axle (16-1 1/2" long)
8 792180	Shift Key	49 778336	Spur Gear (30 teeth)
9 784352	Shift Collar	50 778338	Spur Gear (27 teeth)
10 784378	Shift Rod & Fork	51 778340	Spur Gear (24 teeth)
11 778334	Bevel Gear (30 teeth)	52 778342	Spur Gear (22 teeth)
12 778309	Input Bevel Pinion (13 teeth)	53 778352	Spur Gear (19 teeth)
13 778368	Bevel Gear (13 teeth) (Incl. 14)	54 778350	Spur Gear (16 teeth)
14 778368	Bevel Pinion (13 teeth) (Incl. 13)	56 778335	Spur Gear (10 teeth-steel)
15 778370	Ring Gear (43 teeth)	57 778337	Spur Gear (13 teeth)
17 786188	Drive Pin	58 778339	Spur Gear (16 teeth)
18 786102	Spacer 1.130 X .695	59 778341	Spur Gear (18 teeth)
20 792077A	Ball 5/16" dia	60 778351	Spur Gear (21 teeth)
21 792078	Set Screw 3/8-16 x 3/8"	61 778349	Spur Gear (24 teeth)
22 792079	Spring .310 OD x .625 L	65 780139	Flat Washer .563 ID x .062W
25 792073A	Screw 1/4-20 x 1-1/4" 17	66 776422	Input Shaft
25A 792177	Screw 1/4-20 x 1-3/8" 2	67 776396	Shifter & Brake Shaft
26 792125	Retaining Ring (pkg of 2)	69 792179	Retaining Ring
27 792035	Retaining Ring	70 786197	Spacer .890
28 788040	Retaining Ring	71 788069	Square Cut Ring
29 780072	Thrust Washer .627ID x .031W	71B 788092	"O" Ring
29A 780160	Thrust Washer .563 ID x .031W	76 780090	Flat Washer 1.128 ID x .058W
29B 780051	Thrust Washer .762 ID x .031W	77 788078A	Inverted Retaining Ring
29C 780199	Anti-Rotation Washer .632	79 792144	Spring .430 OD x .5000 L
30 780108	Cup Washer 1.127ID x .032W	82 778363	Bevel & Spur Gear (30 & 13 teeth)
31 780001	Flat Washer .750ID x .056W(Use As Needed)	83 778338	Spur Gear (27 teeth)
31A 780195	Flat Washer .750ID x .062W	85 792154	Oil Fill Plug
32 788083	Oil Seal 5/8"	87 788089A	Oil Seal 9/16"
34 780194	Bushing .563	150 788093A	Liquid Gasket RTV Silicone
35 780193	Flanged Bushing 5/8" ID 2	157 788088A	Oil Seal 3/4"
35A 780197	Flanged Bushing .751 2	180 730229A	Gear Oil 80W90
36 790075	Brake Disk	900 794715	Replacement 206-546 Transaxle
37 790007	Brake Pad Plate		
38 799021	Brake Pad (pkg of 2)		
39 786026	Dowel Pin 5/16 x 3/4		
40 792076A	Flat Washer .312 ID x .059W		
41 790094	Brake Lever		

Parts must be ordered from Tecumseh Products Co.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm