

	BV 32	1997-05 02	4
---	-------	------------	---

www.emc-motoculture.com

BV 32

RESERVELAR
SPARE PARTS
ERSATZTEILE
PIECES DE RECHANGE
PIEZAS DE REPUESTO
RICAMBI
PEÇAS SOBRESSELENTE

MODEL NUMBER BV32

PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE
501 66 78-01			530 02 91-15								
503 11 70-01			530 02 91-16								
504 13 08-07			530 02 91-17								
504 13 08-08			530 02 91-19								
504 13 09-06			530 02 91-29								
504 21 00-50			530 02 91-30								
505 52 01-25			530 02 91-44								
505 52 01-27			530 02 91-45								
530 00 16-24			530 02 91-73								
530 00 17-33			530 02 91-76								
530 01 09-60			530 02 91-82								
530 01 40-16			530 02 92-27								
530 01 40-33			530 02 92-28								
530 01 41-56			530 02 92-95								
530 01 41-57			530 02 93-95								
530 01 41-60			530 02 94-04								
530 01 41-62			530 02 99-88								
530 01 43-39			530 03 00-75								
530 01 43-47			530 03 21-02								
530 01 43-62			530 03 21-08								
530 01 51-26			530 03 50-16								
530 01 51-62			530 03 51-51								
530 01 52-54			530 03 51-78								
530 01 53-06			530 03 51-88								
530 01 54-41			530 03 52-03								
530 01 54-96			530 03 52-19								
530 01 56-35			530 03 52-64								
530 01 56-47			530 03 52-68								
530 01 56-67			530 03 74-92								
530 01 56-72			530 03 75-95								
530 01 57-02			530 03 78-64								
530 01 57-69			530 03 78-65								
530 01 57-71			530 03 79-34								
530 01 57-75			530 03 84-03								
530 01 57-87			530 03 85-08								
530 01 57-88			530 03 91-37								
530 01 57-89			530 03 91-89								
530 01 58-13			530 04 76-96								
530 01 58-15			530 04 77-36								
530 01 58-16			530 04 91-85								
530 01 58-18			530 06 92-32								
530 01 58-40			530 06 92-47								
530 01 58-43			530 06 92-70								
530 01 58-49			530 06 92-77								
530 01 58-52			530 06 92-93								
530 01 58-72			530 06 92-94								
530 01 58-86			530 06 93-48								
530 01 60-64			530 06 94-86								
530 01 60-80			530 06 95-72								
530 01 91-58			530 06 96-28								
530 01 91-64			530 06 96-44								
530 01 91-65			530 06 96-70								
530 01 91-66			530 06 97-14								
530 01 91-67			530 09 47-10								
530 01 91-78			530 09 47-12								
530 01 92-32			530 09 51-16								
530 02 38-17			530 09 51-17								
530 02 47-72			530 34 79-87								
530 02 58-75			534 79 05-00								
530 02 69-94											
530 02 75-23											
530 02 75-69											
530 02 75-93											
530 02 75-94											
530 02 75-97											
530 02 90-72											
530 02 91-10											
530 02 91-11											
530 02 91-12											
530 02 91-13											
530 02 91-14											

www.mnc-motoculture.com


Model BV 32



KEY PART NO. NO.


DESCRIPTION

- 1 530 09 51-16 Collection Bag W/Strap
- 2 530 09 51-17 Collection Bag Elbow Tube
- 3 530 06 92-70 Vacuum Tube Ass'y.
- 4 530 03 85-08 Tube and Nozzle Ass'y.



Carburetor Assembly

WT-141




KEY PART NO. NO.

DESCRIPTION

- 1 504 13 08-08 *+ Metering Diaphragm
- 2 530 03 51-51 *+ Metering Diaphragm Gasket
- 3 530 03 50-16 * Metering Lever Pin Screw
- 4 530 03 52-68 Mixture Needle
- 5 504 21 00-50 Mixture Needle Spring
- 8 504 13 08-07 Fuel Pump Diaphragm
- 9 504 13 09-06 *+ Fuel Pump Gasket
- 10 530 03 52-03 *+ Idle Speed Screw
- 11 501 66 78-01 Idle Speed Spring
- 12 505 52 01-25 * Metering Lever Pin
- 13 505 52 01-27 * Metering Lever
- 14 530 03 51-88 * Metering lever Spring
- 15 503 11 70-01 * Inlet Needle Valve
- 16 530 03 51-78 Fuel Inlet Screen
- 17 530 03 52-64 * Carb. Kwik Repair Kit (* Indicates Contents)
- 18 530 03 52-19 * Carb. Gasket/Diaphragm Kit (+Indicates Contents)

WT-141A #530-069644




KEY PART NO. NO.

DESCRIPTION

- 1 530 06 96-70 Carburetor Repair Kit (*Indicates Contents)
- 2 530 03 84-03 Limiter Cap

Model BV 32

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Model BV 32

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	530 09 47-12	Handle	59	530 01 51-26	Key
2	530 02 69-94	Front Isolator	60	530 01 09-60	Connecting Rod Ass'y
3	530 02 91-11	Spacer	61	530 01 57-88	Spacer
4	530 01 56-35	Screw	62	530 03 21-03	Inner Bearing
5	530 02 91-30	Rear Isolator	63	530 01 57-87	Retaining Ring
6	530 01 58-13	Screw	64	530 01 91-58	Crankshaft Seal
7	530 02 90-72	Trigger	65	530 03 21-02	Outer Bearing
8	530 03 75-95	Assist Handle Ass'y	66	530 01 57-89	Retaining Ring
9	530 02 92-28	Spark Arrestor Clamp	67	530 01 40-16	Crankcase
10	530 02 99-88	Exhaust Deflector Ass'y	68	530 03 91-89	Flywheel
11	530 01 58-40	Pin	69	530 34 79-87	Washer
12	534 79 05-00	Nut	70	530 02 38-17	Spring
13	530 03 78-64	Shroud-Right	71	530 02 91-76	Spacer
14	530 03 79-34	Shroud-Left	72	530 01 41-56	Crankcase/Crankshaft Ass'y
16	530 06 95-72	Switch	73	530 01 60-80	Screw
17	530 02 91-29	Isolator	74	530 01 54-96	Screw
18	530 02 92-95	Isolator	75	530 02 75-23	Retainer
19	530 01 58-43	Screw	76	530 06 94-86	Starter Pulley (Incl.73)
20	530 01 41-62	Fuel Tank Ass'y	77	530 02 93-95	Starter Spring
21	530 01 43-47	(Incl.#21,22 & 106)	78	530 06 97-14	Fan Housing Kit
22	530 01 43-62	Fuel Cap (w/retainer)			(Incl. 71,73-77, 79, 82-84, 86 & 105)
23	530 01 41-60	Fuel Pick-up Ass'y	79	530 02 75-69	Starter Handle
24	530 03 78-65	Handle Cover	80	530 02 91-17	Throttle Lock Button
25	530 02 91-12	Cover	81	530 01 57-69	Screw
26	530 02 94-04	Air Filter	82	530 03 21-08	Bearing
27	530 06 92-93	Air Baffle	83	530 02 91-10	Spacer
28	530 02 91-16	Muffler	84	530 01 58-86	Screw
29	530 02 91-16	Spring	85	530 01 91-67	"O" Ring
30	530 03 00-75	Spark Plug (RCJ-8Y)	86	530 02 91-82	Eyelet
31	530 00 16-24	Screw	87	530 02 92-27	Spark Arrestor Screen
32	530 06 96-28	Cylinder	88	530 01 57-02	"C" Clip
33	530 02 91-45	Lead Wire	89	530 02 91-19	Roll Pin
34	530 03 91-37	Ignition Module	90	530 09 47-10	Blower Housing (Upper)
35	530 01 58-16	Screw			Band
36	530 01 91-78	Gasket	91	530 02 91-73	Impeller (Includes Hub)
37	530 02 58-75	Piston Ring	92	530 01 41-57	Deflector & Clamps
38	530 06 92-77	Piston Kit (Incl.#36,38 & Pin)	93	530 01 43-39	Ass'y
39	530 01 51-62	Retainer	94	530 01 58-18	Washer
40	530 01 53-06	Screw	95	530 01 54-41	Washer
41	530 02 91-44	Ground Wire	96	530 00 17-33	Nut
42	530 01 58-49	Screw	97	530 04 77-36	Blower Housing (Lower)
43	530 01 52-54	Wave Washer			(Incl. 100-103 & door)
44	530 01 58-52	Spacer	98	530 02 47-72	Spring
45	530 02 91-14	Choke Shutter	99	530 02 75-97	Spring
46	530 01 57-75	Screw	100	530 01 56-67	Spring
47	530 03 74-92	Cable Assembly	101	530 01 56-47	Pin
48	530 02 91-15	Plate	102	530 01 58-15	Screw
49	530 06 96-44	Carburetor (Wt 141A w/Limiter Cap)	103	530 01 56-72	Spring
50	530 01 91-64	Gasket	104	530 06 93-48	Spark Arrestor Kit
51	530 01 91-65	Seal	105	530 06 92-32	Rope Kit
52	530 01 57-71	Screw	106	530 06 92-47	Line Kit
53	530 02 91-13	Ground Wire	108	530 06 92-94	Gasket Kit (Incl.35,49 50 & 54)
54	530 04 76-96	Reed Block			Screw
55	530 01 91-66	Gasket	109	530 01 58-72	Air Dam Sponge
56	530 02 75-93	Reed Valve	111	530 04 91-85	Muffler Gasket
57	530 02 75-94	Reed Stop	112	530 01 92-32	
58	530 01 60-64	Screw			
	530 01 40-33	Crankshaft			