





Section: PARK MOWER DECK 92M BLADES

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

2939

1	2	1134-5049-01	Bearing box assy			
2	1	1134-3725-04	.Spacer			
3	2	9549-0020-00	.Ball bearing			
4	8	9997-0865-12	Screw			
5	8	9739-0831-22	Nut			
6	2	1134-5052-04	Blade shaft			
7	2	1134-3725-04	Spacer			
8	2	1134-5130-01	Bearing cover			
11	4	9997-0820-16	Screw			
12	4	9747-0831-02	Lock nut			
13	1	1134-9073-01	Blade bar assy		Sats 2 st/kit of 2	
14	2	1134-9074-01	.Blade kit assy		2 knivar/2 blade ti	
15	1	1134-9054-01	..Shear bolt kit		6 bultar/6 bolts+nu	
16	2	1134-4479-01	..Shoulder bolt			
17	2	9712-0831-02	..Lock nut			

www.emc-motoculture.com




Section: PARK MOWER DECK 92M CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----


2939

1	1	1134-4536-01	Height adj. quadran			
2	2	9959-0816-16	Screw			
3	2	9739-0831-22	Nut			
4	1	1134-4291-03	Height adjust plate			
5	1	9945-0816-16	Screw			
6	1	1134-5215-01	Height adj.lever as		Inkl. pos 11 - 18,	
7	1	1134-2427-01	Spacer			
8	1	9997-0840-16	Screw			
9	1	9747-0831-02	Lock nut			
10	1	1134-3113-03	Spacer			
11	1	1134-3010-02	.Locking quadrant			
12	1	9997-0620-16	.Screw			
13	1	9747-0631-02	.Lock nut			
14	1	1134-3262-01	.Compression spring			
15	1	1134-3009-01	.Locking key			
16	1	1134-3041-01	.Control rod			
17	1	1134-3051-01	.Locking knob			
18	1	9406-0006-00	.Handle			
19	2	1134-4296-02	Pivot arm			
21	2	1134-4298-02	Spacer			
22	2	9897-0850-12	Screw			
23	2	9699-0028-02	Flat washer			
24	2	9747-0831-02	Lock nut			
25	2	9699-0056-02	Flat washer			
26	2	1134-4894-03	Push rod			
27	2	1134-4294-04	Push rod			
28	8	9675-0012-02	Locking washer			
29	1	1134-4304-01	Adjusting plate-L.H			
30	1	1134-4304-02	Adjusting plate-R.H			
31	2	9959-0816-16	Screw			
32	2	9739-0831-22	Nut			
33	2	1134-4307-01	Catch			
34	2	9699-0025-02	Washer			
35	2	9599-0054-02	Cotter pin			
36	1	1134-5114-01	Spacer			



Section: PARK MOWER DECK 92M FRAME

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
2939						
1	1	1134-4888-01	Casing			
2	2	1134-4323-01	Guide plate			
3	4	9897-0616-16	Carriage bolt			
4	4	9739-0631-22	Nut			
5	1	1134-4320-06	Lift bracket			
6	1	9959-0820-16	Screw			
7	1	9739-0831-22	Nut			
12	1	1134-4890-01	Front axle			
13	1	1134-9024-01	Bearing		Sats 4 st/kit of 4	
14	1	1134-4292-01	Bearing holder			
15	1	1134-4292-02	Bearing holder			
16	2	9959-0816-16	Screw			
17	2	9739-0831-22	Nut			
18	2	1134-4284-01	Wheel			
19	4	1134-4319-01	Bearing			
20	2	1134-4318-01	Wheel axle			
21	2	9997-0812-02	Screw			
22	2	9739-0831-22	Nut			
23	1	1134-5892-01	Rear axle			
24	1	1134-9024-01	Bearing		Sats 4 st/kit of 4	
25	2	1134-4689-01	Support			
26	2	9959-0616-16	Screw			
27	2	9747-0631-02	Lock nut			
28	1	1134-5180-01	Bracket-LH			
29	1	1134-5180-02	Bracket-RH			
30	4	9959-0816-16	Screw			
31	4	9739-0831-22	Nut			
37	1	1134-5600-01	Mower deck arm-LH			
38	1	1134-5600-02	Mower deck arm-RH			
39	2	9997-1016-16	Screw			
40	2	9699-0030-02	Flat washer			
42	1	1134-4688-02	Lift spring assy		Inkl. pos 43 - 49	
43	1	1134-4574-01	Spring assy			
44	1	1134-4577-01	Spring pivot			
45	1	9997-0825-16	Screw			
46	1	9747-0831-02	Lock nut			
47	1	9997-0835-12	Screw			
48	1	9747-0831-02	Lock nut			
49	2	1134-4481-01	Wing nut			
52	1	9997-0620-16	Screw			
53	1	9739-0631-22	Nut			
97	2	9402-3523-01	Side decal			



Section: PARK MOWER DECK 92M TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

2939

1	1	1134-5229-01	Transmission plate			
2	1	1134-4887-01	Transmission cover			
4	2	9699-0028-02	Flat washer			
5	2	9747-0831-02	Lock nut			
6	1	9942-0612-16	Screw			
7	2	1134-3679-01	Toothed belt pulley			
8	1	1134-3597-01	.Reinforcement			
9	2	9997-0625-16	.Screw			
10	2	9747-0631-02	.Lock nut			
11	2	1134-0323-01	Key		L = 25 mm	
12	2	9699-0104-02	Washer			
13	2	9699-0121-02	Flat washer			
14	2	9712-1231-02	Lock nut			
15	1	1134-5601-01	Belt pulley			
16	1	9549-0019-00	Ball bearing			
17	2	1134-4321-01	Toothed pulley			
18	1	9549-0019-00	Ball bearing			
19	1	1134-3725-01	Spacer			
20	4	9997-0650-12	Screw			
21	1	1134-4314-01	Shaft			
22	1	9997-1065-12	Screw			
23	2	9699-0030-02	Flat washer			
24	1	9739-1031-22	Nut			
25	1	1134-4667-02	Plate			
26	4	9959-0816-16	Screw			
27	4	9739-0831-22	Nut			
28	1	1134-4885-01	Tension arm			
29	2	9897-0825-16	Screw			
31	2	9699-0036-02	Flat washer			
32	2	9739-0831-22	Nut			
39	1	1134-4686-01	Tension roller			
40	1	1134-4316-03	Shaft			
41	1	9997-1040-12	Screw			
42	1	9699-0030-02	Flat washer			
43	1	1134-4775-01	Lock nut			
44	1	1134-9075-01	Drive belt		= 9585-0130-01	
45	1	9585-0131-01	Toothed belt			
46	4	9699-0025-02	Washer			
47	1	9699-0060-02	Flat washer			
48	1	1134-4900-01	Belt guide			
49	2	9945-0816-16	Screw			
53	4	9747-0631-02	Lock nut			