





Section: VILLA MOWER DECK 85M BLADES

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
2916						
6	2	1134-3679-01	Toothed belt pulley			
7	1	1134-3597-01	.Reinforcement			
8	2	9997-0625-16	.Screw			
9	2	9747-0631-02	.Lock nut			
10	2	9699-0030-02	Flat washer			
13	1	9600-0150-03	Key			
14	6	9699-0104-02	Washer			
15	2	9712-1031-02	Nut			
18	1	9600-0150-02	Key			
19	1	1134-9030-01	Toothed belt		= 9585-0071-00	
27	1	1134-3014-01	Belt tensioner			
28	1	9959-0820-16	Screw			
29	1	1134-3035-01	Belt pulley			
32	1	9739-0831-22	Nut			
33	2	1134-3841-01	Bearing box assy			
35	1	9549-0019-00	.Ball bearing			
36	1	9549-0020-00	.Ball bearing			
37	1	1134-0051-05	.Spacer			
38	2	1134-3768-01	Bearing cover			
39	2	1134-3725-01	Spacer			
40	1	1134-3767-01	Blade shaft			
46	1	1134-3767-02	Blade shaft			
47	8	9945-0825-16	Screw			
48	1	1134-9050-01	Blade bar assy		Sats 2 st/pkg of 2	
49	2	1134-9053-01	.Blade kit		2 knivar/2 blade ti	
50	1	1134-9054-01	..Shear bolt kit		6 bultar/6 bolts+nu	
52	2	9997-0816-16	..Screw			
53	2	9712-0831-02	..Lock nut			
57	4	9997-0820-16	Screw			
58	4	9747-0831-02	Lock nut			



Section: VILLA MOWER DECK 85M FRAME CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
2916						
1	2	1134-3031-01	Spacer			
2	1	1134-3038-01	Belt guard			
3	2	9997-1055-12	Screw			
5	3	9836-9512-12	Screw			
6	1	1134-3037-01	Transmission cover			
7	2	9945-0816-16	Screw			
8	1	1134-3017-01	Frame			
9	1	1134-3042-01	Spring			
10	1	1134-1605-02	Chain			
11	1	1134-1889-01	Eyebolt			
12	1	9699-0100-02	Washer			
13	1	1134-3033-01	Hose			
16	1	1134-0304-05	Shaft			
17	2	9935-1020-16	Screw			
18	8	1134-2406-01	Guard roller			
19	2	1134-2405-01	Casing wheel			
20	4	1134-3047-01	Spacer			
20A	2	9699-0104-02	Washer		Shims-ej ill/not il	
22	1	1134-3025-01	Casing-yellow			
23	1	1134-3029-01	Stop bracket			
24	1	1134-3015-02	Adjusting bracket-L			
24A	1	1134-3015-01	Adjusting bracket-R		Ej ill/not ill.	
25	13	9959-0820-16	Screw			
26	13	9739-0831-22	Nut			
27	1	1134-3016-02	Bracket-L.H.			
27A	1	1134-3016-01	Bracket-R.H.		Ej ill/not ill.	
30	2	1134-2907-03	Pivoting plate			
31	6	1134-0240-00	Shoulder screw			
32	1	1134-2411-01	Bracket			
33	1	1134-3013-01	Shaft			
34	2	1134-1833-02	Rod			
35	4	9675-0012-02	Locking washer			
36	1	1134-3011-01	Height adj. quadran			
37	1	1134-3039-01	Height adjust lever			
38	1	1134-2427-01	Spacer			
40	1	9997-0825-16	Screw			
41	7	9747-0831-02	Lock nut			
42	1	1134-3010-01	Locking quadrant			
43	1	9997-0620-16	Screw			
44	1	9747-0631-02	Lock nut			
45	1	1134-3262-01	Compression spring			
47	1	1134-3009-01	Locking key			
48	1	1134-3047-01	Control rod			
49	1	1134-3051-01	Locking knob			
50	1	9406-0006-00	Handle			
51	1	1134-3026-02	Height measure plat			