




Section: VILLA MOWER DECK 107M BLADE SYSTEM


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

2930

2934

1	2	1134-5049-01	Bearing box assy			
2	1	1134-3725-04	.Spacer			
3	2	9549-0020-00	.Ball bearing			
4	8	9997-0865-12	Screw			
5	8	9739-0831-22	Nut			
6	1	1134-5052-04	Blade shaft			
7	2	1134-3725-04	Spacer			
8	2	1134-3768-01	Bearing cover			
9	1	1134-5052-03	Blade shaft			
11	4	9997-0820-16	Screw			
12	4	9747-0831-02	Lock nut			
13	1	1134-9072-01	Blade bar assy		Sats 2 st/Kit of 2	
14	1	1134-9074-01	.Blade kit assy (CW		Clockwise rotation	
15	1	1134-9054-01	..Shear bolt kit		6 bultar/6 bolts+nu	
16	2	1134-4479-01	..Shoulder bolt			
17	2	9712-0831-02	..Lock nut			

www.emc-motoculture.com




Section: VILLA MOWER DECK 107M CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----


2930

1	1	1134-4290-01	Height adj. quadran			
2	2	9959-0816-16	Screw			
3	2	9739-0831-22	Nut			
4	1	1134-4291-02	Height adj. plate			
5	1	9945-0816-16	Screw			
6	1	1134-3039-01	Height adjust lever			
7	1	1134-2427-01	Spacer			
8	1	9997-0840-16	Screw			
9	1	9747-0831-02	Lock nut			
10	1	1134-3113-03	Spacer			
11	1	1134-3010-01	Locking quadrant			
12	1	9997-0620-16	Screw			
13	1	9747-0631-02	Lock nut			
14	1	1134-3262-01	Compression spring			
15	1	1134-3009-01	Locking key			
16	1	1134-3041-01	Control rod			
17	1	1134-3051-01	Locking knob			
18	1	9406-0006-00	Handle			
19	2	1134-4296-02	Pivot arm			
21	2	1134-4298-02	Spacer			
22	2	9897-0850-12	Screw			
23	2	9699-0028-02	Flat washer			
24	2	9747-0831-02	Lock nut			
25	2	9699-0056-02	Flat washer			
26	2	1134-4894-02	Push rod			
27	2	1134-4294-02	Push rod			
28	8	9675-0012-02	Locking washer			
29	1	1134-4304-01	Adjusting plate-L.H			
30	1	1134-4304-02	Adjusting plate-R.H			
31	2	9959-0816-16	Screw			
32	2	9739-0831-22	Nut			
33	2	1134-4307-01	Catch			
34	2	9699-0025-02	Washer			
35	2	9599-0054-02	Cotter pin			



Section: VILLA MOWER DECK 107M FRAME

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2930					
	2934					
1	1	1134-4889-01	Casing			
2	2	1134-4323-01	Guide plate			
3	4	9897-0616-16	Carriage bolt			
4	4	9739-0631-22	Nut			
5	1	1134-4320-01	Lift bracket			
6	1	9959-0820-16	Screw			
7	1	9739-0831-22	Nut			
10	1	1134-4905-01	Guide bar			
11	2	9836-9530-12	Screw			
12	1	1134-4890-01	Front axle			
13	1	1134-9024-01	Bearing kit		Sats 4 st/kit of 4	
14	1	1134-4292-01	Bearing holder			
15	1	1134-4292-02	Bearing holder			
16	4	9959-0816-16	Screw			
17	4	9739-0831-22	Nut			
18	2	1134-4284-01	Wheel			
19	4	1134-4319-01	Bearing			
20	2	1134-4318-01	Wheel axle			
21	2	9997-0812-02	Screw			
22	2	9739-0831-22	Nut			
23	1	1134-4876-01	Rear axle			
24	1	1134-9024-01	Bearing kit		Sats 4 st/kit of 4	
25	2	1134-4689-01	Support			
26	2	9959-0616-16	Screw			
27	2	9747-0631-02	Lock nut			
28	1	1134-4299-01	Wheel attachment-L.			
29	1	1134-4299-02	Wheel attachment-R.			
30	4	9959-0816-16	Screw			
31	4	9739-0831-22	Nut			
32	2	1134-3434-01	Roller			
33	2	1134-0041-05	Bushing			
35	2	9898-1060-12	Screw			
36	2	9739-1031-22	Nut			
37	1	1134-4544-01	Mower deck arm-L.H.			
38	1	1134-4544-02	Mower deck arm-R.H.			
39	2	9997-1016-16	Screw			
40	2	9699-0030-02	Flat washer		10 x 26 x 2.0	
41	2	9699-0104-02	Washer		17 x 30 x 3.0	
42	1	1134-4688-02	Lift spring assy		Inkl. pos 43 - 49	
43	1	1134-4574-01	.Spring assy			
44	1	1134-4577-01	.Spring pivot			
45	1	9997-0825-16	.Screw			
46	1	9747-0831-02	.Lock nut			
47	1	9997-0835-12	.Screw			
48	1	9747-0831-02	.Lock nut			
49	2	1134-4481-01	.Wing nut			
50	1	1134-9026-01	Bearing bush kit		Sats 4 st/kit of 4	
51	2	9501-0502-00	Grease joint			
52	2	1134-4745-01	Spacer washer			
97	2	9402-3486-01	Side decal			
98	1	9402-3124-00	Warn. label "Danger		US, CA	



Section: VILLA MOWER DECK 107M TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2930					
	2934					
1	1	1134-4875-01	Transmission plate			
2	1	1134-4865-01	Transmission cover			
3	3	1134-3632-01	Clips-belt guide			
4	2	9699-0028-02	Flat washer			
5	2	9747-0831-02	Lock nut			
6	1	9942-0612-16	Screw			
7	1	9699-0060-02	Flat washer			
8	2	1134-3679-01	Toothed belt pulley			
9	1	1134-3597-01	.Reinforcement			
10	2	9997-0625-16	.Screw			
11	2	9747-0631-02	.Lock nut			
12	1	1134-0323-01	Key		L = 25 mm	
13	1	1134-0323-04	Key		L = 40 mm	
14	2	9699-0104-02	Washer			
15	2	9699-0121-02	Flat washer		12.5 x 35 x 3 mm	
16	2	9712-1231-02	Lock nut		M12	
17	1	1134-4732-01	Belt pulley		Ø = 163.5 mm	
18	1	1134-4537-01	Tension arm			
19	2	9897-0825-16	Screw			
20	2	9699-0036-02	Flat washer			
21	2	9739-0831-22	Nut			
22	1	1134-3053-01	Tension roller			
23	1	1134-4316-03	Shaft			
24	1	9997-1040-12	Screw			
25	1	9699-0030-02	Flat washer			
26	1	1134-4775-01	Lock nut			
27	1	1134-9068-01	V-belt		= 9585-0127-01	
28	1	9585-0133-01	Toothed belt			
29	1	9699-0035-02	Flat washer			
30	1	1134-4747-01	Belt guide			
31	2	9945-0816-16	Screw			