


# SPARE PARTS CATALOGUE

MODEL - THT 210

## HT25

**Jonsered**


FIG.1 ENGINE



REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER	REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER
	FIG.1 ENGINE						
01-001	157-06500-91	1					
01-002	018-06540-21	1					
01-003	001-06500-90	1					
01-004	994-16050-201	2					
01-007	017-06500-20	1					
01-008	041-00601-21	1					
01-009	030-06500-90	1					
01-010	037-06500-20	1					
01-011	039-01620-20	2					
01-012	046-06500-80	1					
01-013	999-62081-225	1					
01-021	072-06500-90	1					
01-022	090-06500-20	1					
01-023	999-66122-269	2					
01-024	999-61600-100	2					
01-025	330-00200-21	V					
01-025	330-00200-22	V					
01-025	330-00200-23	V					
01-025	330-00200-24	V					
01-026	599-00601-20	1					
01-027	153-21532-90	1					
01-028	994-16040-226	2					
01-030	994-14050-301	3					
01-031	155-21523-80	1					
01-032	992-01080-011	1					
01-033	992-10080-012	1					
01-034	991-01080-011	1					
01-035	100-02100-20	2					
01-036	250-06500-20	1					
01-037	178-06500-80	1					
01-038	167-21532-80	1					

www.emc-motoculture.com


FIG.2 ENGINE COMPONENTS



REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER	REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER
	FIG.2 ENGINE COMPONENTS						
02-003	738-0650H-20	1					
02-004	737-06500-20	1					
02-005	133-06500-20	1					
02-006	704-06500-90	1					
02-007	992-01050-011	2					
02-008	990-51050-503	2					
02-011	112-0650H-80	1					
02-012	780-06097-20	1					
02-013	774-06097-20.	1					
02-015	839-02010-20	1					
02-016	798-06500-90	1					
02-017	203-0604A-20	1					
02-018	783-06097-20	1					
02-019	785-06410-20	1					
02-020	994-15040-162	3					
02-021	751-06500-20	1					
02-022	721-06504-90	1					
02-024	994-14040-081	2					
02-025	403-06500-20	1					
02-026	404-06500-90	1					
02-027	994-16050-252	2					
02-030	402-06500-20	1					
02-031	455-0651E-90	1					
02-033	999-67015-000	1					
02-035	423-06500-80	1					
02-036	470-06500-20	2					
02-037	528-0650T-20	1					
02-038	992-04080-031	1					
02-039	476-01700-20	1					
02-040	992-10050-012	2					
02-041	990-11050-602	2					
02-043	446-06500-20	1					
02-044	452-06500-20	1					
02-045	380-0637C-20	1					
02-047	277-0634F-90	1					
02-050	223-06500-90	1					
02-051	680-00731-20	1					
02-052	675-04042-80	1					
02-053	591-0650H-21	1					
02-055	659-00801-20	2					
02-058	994-63050-185	2					
02-061	990-72045-164	1					
02-062	994-25040-128	2					
02-063	595-0003D-90	1					
02-065	790-06097-20	1					
02-066	788-06500-20	1					
02-086	626-32810-20	1					


[www.emc-motoculture.com](http://www.emc-motoculture.com)

# FIG.3 CARBURETOR



REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER	REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER
	FIG.3 CARBURETOR						
03-001	548-25140-20	2					
03-005	539-25120-20	1					
03-007	489-25100-20	1					
03-008	488-25145-80	1					
03-010	550-25100-20	1					
03-011	599-2000W-41	1					
03-013	577-25100-20	1					
03-014	576-25100-20	1					
03-015	523-25100-20	1					
03-016	522-25100-20	1					
03-017	578-25007-20	1					
03-018	575-25140-80	1					
03-019	475-25001-20	1					
03-020	474-25001-80	1					
03-021	476-25004-20	1					
03-022	548-25101-20	4					

# FIG.4 GEAR CASE & HANDLE





REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER	REF. NO.	PARTS NUMBER	Q'ty	SERIAL NUMBER
	FIG.4 GEAR CASE & HANDLE			04-056	990-73045-124	4	
04-001	300-33160-80	1		04-057	250-33160-20	1	
04-002	993-50015-002	1		04-058	990-73045-124	1	
04-003	999-61600-200	1		04-061	210-33160-21	1	
04-004	999-61600-202	1		04-062	040-33160-80	1	
04-005	288-33180-80	1		04-063	992-01050-011	2	
04-006	305-33160-20	1		04-065	994-14050-401	2	
04-007	075-33160-20	1		04-067	198-11600-80	1	
04-008	101-33160-22	2		04-069	138-33171-20	1	
04-009	307-33180-20	1		04-071	992-10060-012	2	
04-010	303-33160-20	1		04-072	991-01060-011	2	
04-011	630-33160-20	1		04-073	164-07007-00	1	
04-012	122-33168-20	1		04-075	036-29331-50	1	
04-013	136-33160-20	1		04-076	813-20000-20	1	
04-014	990-52060-165	2		04-081	992-01060-011	3	
04-015	120-33168-20	2					
04-016	085-33160-20	2					
04-017	129-33202-20	5					
04-018	124-33202-21	5					
04-019	123-33202-20	5					
04-021	994-61040-104	8					
04-022	300-32250-80	1					
04-023	990-51060-143	2					
04-025	050-33160-20	1					
04-026	170-33160-80	1					
04-027	258-11650-20	1					
04-028	994-31030-101	1					
04-029	230-33160-20	1					
04-030	231-33160-20	1					
04-031	232-33160-20	1					
04-033	051-33160-20	1					
04-035	765-32120-20	1					
04-036	990-72045-164	6					
04-037	058-33160-20	1					
04-038	992-00060-011	2					
04-039	991-01060-011	1					
04-040	990-21060-501	1					
04-041	266-32750-20	2					
04-042	276-32710-20	2					
04-043	368-32057-20	2					
04-045	994-14050-301	2					
04-046	294-33160-21	1					
04-047	885-06500-80	1					
04-048	925-33160-20	1					
04-050	249-33160-20	1					
04-051	276-32710-20	2					
04-052	266-32750-20	2					
04-053	368-32057-20	2					
04-055	994-14050-301	2					