

**J01**

**JONISERED**


**JGR 38DN**

Serial No.

[www.enclonotoculture.com](http://www.enclonotoculture.com)

**J01-01**


**JGR 38DN CYLINDER/PISTON/CRANK/SHAFT**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	157-0097A-90	1	
002	018-01700-21	1	
004	001-0143C-90	1	
005	994-61050-184	4	
007	017-01380-20	1	
008	041-04000-20	2	
009	030-0143C-90	1	
010	037-01400-20	1	
011	039-00000-20	2	
015	046-01350-82	1	
016	999-62091-325	1	
017	068-10100-20	1	

# J01-02


## JGR 38DN CRANK CASE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
018	071-02007-20	V	
018	071-02007-21	V	
018	071-02007-22	V	
018	071-02007-23	V	
018	071-02007-24	V	
021	072-0138A-90	1	
022	999-61600-200	1	
023	999-61620-200	1	
024	999-66122-206	1	
025	999-66152-500	1	
026	090-01380-20	1	
028	994-14050-251	4	
035	359-10112-20	1	
036	798-0166R-90	1	
038	790-0162V-20	1	
039	788-0138A-20	1	
041	167-22006-90	1	
042	191-01434-90	1	
044	994-16040-226	2	
045	112-0136B-20	1	
047	994-14050-181	4	
048	132-01300-20	1	
049	203-0604A-20	1	
050	167-20531-80	1	
051	264-20517-21	1	
052	560-20517-20	1	
055	155-21733-80	1	
056	992-01080-011	1	
057	981-01080-01	1	
058	164-07004-01	1	


# J01-03

## JGR 38DN ENGINE-1



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
021	403-0143C-20	1	
022	404-0143C-90	1	
025	994-16050-221	2	
026	402-0602K-21	1	
027	659-00801-20	3	
028	455-0143C-90	1	
034	994-15050-181	3	
040	591-0143G-20	1	
041	675-01630-90	1	
042	680-00731-20	1	
043	223-0622U-90	1	
044	595-0130W-91	1	
070	091-01300-20	1	
076	626-32550-20	1	


# J01-04 JGR 38DN ENGINE-2



REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
001	738-01380-21	1	
004	133-01380-21	1	
005	704-0143C-90	1	
006	992-01060-011	2	
007	990-53060-603	2	
010	359-10112-20	2	
011	290-0136U-80	2	
012	358-10112-20	2	
013	357-0136U-20	2	
014	342-0138A-20	1	
019	994-16040-161	2	
020	994-16040-251	1	
062	994-15040-121	2	
065	994-15050-251	1	
077	132-0130A-20	1	

**J01-05**


**JGR 38DN RECOIL STARTER**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	762-0136U-90	1	
001	772-0136U-80	1	
002	779-0136U-20	1	
003	774-0162V-20	1	
005	839-02010-20	1	
006	783-0136U-20	1	
008	785-01620-20	1	
009	795-01620-20	1	

**J01-06**


**JGR 38DN AIR CLEANER**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	410-0138A-93	1	
001	452-01380-91	1	
004	423-01380-82	1	
005	453-0637C-20	1	
006	470-0602N-20	1	
007	446-01380-20	1	
011	476-01700-20	1	
012	528-01380-21	1	
013	992-04080-031	1	
014	994-14050-571	2	
016	380-0637C-20	1	

**J01-07**

**JGR 38DN CARBURETOR**




REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
002	575-25152-80	1	
003	489-25100-20	1	
004	550-25100-20	1	
005	431-0634C-20	1	
006	476-25004-20	1	
007	488-25120-90	1	
008	539-25120-20	1	
010	475-25038-20	1	
011	577-25100-20	1	
012	576-25100-20	1	
013	474-25001-80	1	
014	514-25100-20	2	
015	548-25101-20	4	
016	614-25137-20	1	
017	599-2000W-43	1	
018	613-25100-20	1	
019	544-25120-20	1	
201	578-25007-20	1	



**J01-08**


**JGR 38DN CLUTCH CASE**



REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
001	289-01370-80	1	
002	999-61600-102	2	
003	993-50012-002	1	
004	374-0631A-20	1	
005	599-0165A-80	1	
006	990-51050-103	1	
008	994-61050-204	1	
010	331-33699-20	1	
011	990-23060-221	4	
012	992-10060-012	4	
013	994-14050-122	3	
015	739-33681-20	1	
016	992-10050-012	2	
017	990-21050-101	2	
025	249-0165A-21	1	

# J01-09


## JGR 38DN OPERATION PIPE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	343-33699-20	1	
002	341-37488-80	1	
003	347-37356-90	5	
042	335-37307-20	1	
043	334-37352-21	2	
044	994-62050-304	2	
046	315-37304-20	1	
063	165-33130-20	1	
064	994-61050-254	4	
066	506-37623-20	1	
067	507-37623-20	1	
068	510-37352-20	1	
069	508-37623-20	1	
071	994-81060-254	2	
072	336-33411-82	1	
074	460-33111-20	1	
075	502-37415-21	1	
091	746-37379-90	1	
092	501-37822-20	1	
095	870-38401-90	1	
098	253-38400-20	1	
100	832-38400-20	1	
101	880-38401-20	1	
103	322-38400-20	1	
106	993-46040-202	2	
107	994-31050-303	1	
108	991-01050-043	1	
120	885-38401-80	1	

# J01-10

## JGR 38DN GEAR CASE/GUARD



REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
001	300-37134-90	1	
002	994-61050-254	2	
004	993-51024-002	1	
005	993-50009-002	1	
006	999-61609-002	1	
007	999-61609-000	1	
009	300-3330B-20	1	
011	990-51050-103	1	
012	994-23080-100	1	
013	999-61628-000	1	
015	304-37134-20	1	
016	999-61620-103	1	
017	993-51032-002	1	
018	310-37623-20	1	
019	311-37300-20	1	
021	308-33410-20	1	
022	312-33386-20	1	
023	324-37350-20	1	
025	067-37134-20	1	
026	994-81060-254	1	
028	442-33699-20	2	
029	441-3741M-20	1	
030	445-37380-20	1	
031	447-37127-20	1	
032	797-37380-21	1	
034	994-14050-121	1	
035	301-37134-00	1	
036	991-01050-011	1	