




# **REPAIR PARTS MANUAL**

## **MODEL NO. MBA1396 (MBA1396C)**

### **Lawn Tractor**

---

# **Mr. Bricolage**

# HOW TO USE THIS MANUAL

This manual is designed to provide the customer with a means to identify the parts on his/her tractor when ordering repair parts. The illustrations may or may not represent the actual assemblies; therefore, it is not recommended to use this manual as a guide to assemble or disassemble the tractor. Some hardware and parts are drawn larger in order to more readily identify them.

Each tractor has its own model number.

The model number for your tractor can be found on the fender under the seat.


When ordering parts, always give the following information:

- Product - "Tractor"
- Model Number - MBA1396 (MBA1396C)
- Part Number
- Part Description

## TABLE OF CONTENTS


|                         |              |
|-------------------------|--------------|
| <b>SCHEMATIC .....</b>  | <b>3</b>     |
| <b>ELECTRICAL .....</b> | <b>4-5</b>   |
| <b>CHASSIS.....</b>     | <b>6-7</b>   |
| <b>DRIVE.....</b>       | <b>8-9</b>   |
| <b>STEERING .....</b>   | <b>10-11</b> |
| <b>SEAT .....</b>       | <b>12</b>    |
| <b>DECALS .....</b>     | <b>13</b>    |
| <b>ENGINE.....</b>      | <b>14</b>    |
| <b>MOWER LIFT .....</b> | <b>15</b>    |
| <b>MOWER DECK .....</b> | <b>16-17</b> |

# TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00 SCHEMATIC



# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
ELECTRICAL



## REPAIR PARTS


TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                          |
|------------|--------------|--------------------------------------|
| 1          | 532 16 34-65 | Battery 12 Volt 28 AMP               |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20unc X 3/4          |
| 8          | 532 17 66-89 | Box Battery                          |
| 16         | 532 17 61-38 | Switch Interlock Push-In             |
| 21         | 532 17 56-85 | Harness Asm. Light                   |
| 22         | 532 00 41-52 | Bulb Light                           |
| 24         | 532 12 47-80 | Cable Battery 6 Ga 11" red           |
| 25         | 532 14 61-47 | Cable Battery 6 Ga 44" red w/16 wire |
| 26         | 532 17 51-58 | Fuse 20 AMP                          |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc              |
| 28         | 532 12 47-73 | Cable Ground 6 Ga 12" black          |
| 29         | 532 12 13-05 | Switch Plunger Nc Gray               |
| 30         | 532 17 55-67 | Switch Ign                           |
| 33         | 532 14 04-01 | Key Ign Molded Generic               |
| 40         | 532 17 97-20 | Harness Ign.                         |
| 41         | 871 11 04-08 | Bolt Blk Fin Hex 1/4 - 20 x 1/2      |
| 42         | 532 13 15-63 | Cover Terminal Red                   |
| 43         | 532 17 88-61 | Solenoid                             |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular          |
| 52         | 532 14 19-40 | Protection Wire Loop                 |
| 90         | 532 18 04-49 | Cover Terminal Battery               |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
CHASSIS AND ENCLOSURES



# REPAIR PARTS


TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
CHASSIS AND ENCLOSURES

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 17 46-20 | Chassis Stamping                  |
| 2       | 532 17 65-54 | Drawbar                           |
| 3       | 817 06 06-12 | Screw 3/8-16x3/4                  |
| 5       | 532 15 52-72 | Bumper Hood/Dash                  |
| 6       | 532 18 25-34 | Saddle                            |
| 8       | 532 12 64-71 | Clip Insulator                    |
| 9       | 532 18 54-80 | Dash P/L                          |
| 10      | 872 14 06-08 | Bolt Carriage 3/8-16 x 1          |
| 11      | 532 17 49-96 | Panel Dash Lh                     |
| 12      | 532 14 56-60 | Clip Tinnerman                    |
| 13      | 532 18 17-19 | Panel Dash Rh                     |
| 15      | 874 18 05-12 | Screw Mach Trhd 5/16-18 Unc x 3/4 |
| 16      | 873 51 05-00 | Nut Keps 5/16-18 Unc              |
| 17      | 532 16 84-03 | Hood LT/PL                        |
| 18      | 532 18 49-21 | Bumper Hood                       |
| 24      | 874 78 06-16 | Bolt Fin Hex 3/8-16 Unc x 1 Gr 5  |
| 25      | 819 13 13-12 | Washer 13/32 X 13/16 X 12 Ga      |
| 26      | 873 80 06-00 | Nut Lock Hex W/Ins 3/8-16 Unc     |
| 28      | 532 17 97-77 | Grille/Lens                       |
| 29      | 532 17 59-02 | Lens LT/PL                        |
| 30      | 532 18 55-44 | Fender                            |
| 31      | 532 13 66-19 | Bracket Support Fender            |
| 33      | 532 18 55-45 | Footrest LH                       |
| 34      | 532 18 55-46 | Footrest RH                       |
| 35      | 872 11 06-06 | Bolt Rdhd 3/8-16 x 3/4            |
| 37      | 817 49 05-08 | Screw Thdrol 6/16-18 x 1/2 TYT    |
| 38      | 532 17 57-10 | Bracket, Asm. Pivot, Mower Rear   |
| 51      | 873 80 04-00 | Nut Lock Hex W/Ins 1/4-20         |
| 52      | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.        |
| 53      | 532 14 46-97 | Bracket Grille LH                 |
| 54      | 532 16 14-64 | Screw Hex Wshd 8-18 x 7/8         |
| 55      | 532 14 46-96 | Bracket Grille RH                 |
| 57      | 874 78 04-12 | Bolt Hex 1/4-20 x 3/4             |
| 145     | 532 15 65-24 | Rod Pivot Chassis/Hood            |
| 205     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2         |
| 206     | 532 17 01-65 | Bolt Shoulder 5/16-18 TT          |
| 208     | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2         |
| 209     | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4    |
| 212     | 532 15 64-94 | Insert Lens Reflect               |
| 213     | 532 00 54-79 | Plug Button                       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
DRIVE



# REPAIR PARTS

**TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
DRIVE**


| KEY PART<br>NO. | NO.          | DESCRIPTION                                                                   |
|-----------------|--------------|-------------------------------------------------------------------------------|
| 1               | -----        | Transaxle, Peerless 205-544C<br>(Order Parts From Transaxle Manu-<br>factuer) |
| 2               | 532 14 66-82 | Spring Return Brake T/a Zinc                                                  |
| 3               | 532 12 36-66 | Pulley Transaxle 18" tires                                                    |
| 4               | 812 00 00-28 | Ring Retainer # 5100-62                                                       |
| 5               | 532 12 15-20 | Strap Torque 30 Degrees                                                       |
| 6               | 817 06 05-12 | Screw Thdrol 5/16-18 X 3/4 TYT                                                |
| 7               | 532 16 22-40 | Plate Bracket Shift Saddle                                                    |
| 8               | 532 13 16-79 | Rod Shift Saddle                                                              |
| 10              | 876 02 04-16 | Pin Cotter 1/8 X 1 Cad                                                        |
| 11              | 532 10 57-01 | Washer Plate Shf 388 Sq Hole                                                  |
| 12              | 819 15 12-16 | Washer 15/32 x 3/4 x 16 Ga.                                                   |
| 13              | 874 55 04-12 | Bolt 1/4-28 Unf Gr 8 W/Patch                                                  |
| 14              | 810 04 04-00 | Washer Lock Hvy Helical 1/4                                                   |
| 18              | 874 78 06-16 | Bolt, Fin Hex 3/8-16 UNC x 1 Gr. 5                                            |
| 19              | 873 80 06-00 | Nut Lock 3/8-16 Unc                                                           |
| 21              | 532 10 69-33 | Knob                                                                          |
| 22              | 532 13 08-04 | Rod Brake Blk Zinc 26 840                                                     |
| 24              | 873 35 06-00 | Nut Hex Jam 3/8-16 Unc                                                        |
| 25              | 532 10 68-88 | Spring Rod Brake 2 00 Zinc                                                    |
| 26              | 819 13 13-16 | Washer 13/32 X 13/16 X 16 Ga                                                  |
| 27              | 876 02 04-12 | Pin Cotter 1/8 X 3/4 Cad                                                      |
| 28              | 532 17 57-65 | Rod Brake Parking LT/YT                                                       |
| 29              | 532 07 16-73 | Cap Brake Parking Black                                                       |
| 30              | 532 17 49-73 | Bracket Mtg Transaxle                                                         |
| 32              | 874 76 05-12 | Bolt Hex Hd 5/16-18unc X 3/4                                                  |
| 34              | 532 17 55-78 | Shaft Asm Pedal Foot                                                          |
| 35              | 532 12 01-83 | Bearing Nylon Blk 629 Id                                                      |
| 36              | 819 21 16-16 | Washer 21/32 X 1 X 16 Ga                                                      |
| 37              | 532 12 49-63 | Pin Roll 3/16 X 1"                                                            |
| 38              | 532 17 91-14 | Pulley Composite                                                              |
| 39              | 874 76 06-48 | Bolt Fin Hex 3/8-16 unc X 3                                                   |
| 41              | 532 17 55-56 | Keeper Belt Idler Flat                                                        |
| 47              | 532 12 77-83 | Pulley Idler V Groove Plastic                                                 |
| 48              | 532 15 44-07 | Bellcrank Clutch Grnd Drv Stl                                                 |
| 49              | 532 12 32-05 | Retainer Belt Style Spring                                                    |
| 50              | 872 11 06-12 | Bolt Carr Sh 3/8-16unc X 1-1/2 Gr.5                                           |

| KEY PART<br>NO. | NO.          | DESCRIPTION                    |
|-----------------|--------------|--------------------------------|
| 51              | 873 68 06-00 | Nut Crownlock 3/8-16 Unc       |
| 52              | 873 68 05-00 | Nut Crownlock 5/16-18 Unc      |
| 53              | 532 10 57-10 | Link Clutch                    |
| 55              | 532 10 57-09 | Spring Return Clutch 6 75      |
| 56              | 817 06 06-20 | Screw 3/8-16 x 1-1/4           |
| 57              | 532 13 08-01 | V-Belt Ground Drive 95 25      |
| 59              | 532 16 96-91 | Keeper Belt Span Ctr           |
| 61              | 817 12 06-14 | Screw 3/8-16 x .875            |
| 62              | 532 12 48-72 | Cover Pedal                    |
| 63              | 532 18 02-19 | Engine Pulley LT/YT            |
| 64              | 871 17 07-64 | Bolt Hex                       |
| 65              | 810 04 07-00 | Washer Lock Hvy Hlcl Spr 7/16  |
| 66              | 532 15 47-78 | Keeper Belt Engine Foolproof   |
| 70              | 532 18 02-18 | Guide Belt Mower Drive RH      |
| 74              | 532 13 70-57 | Spacer Axle                    |
| 75              | 532 12 17-49 | Washer 25/32 X 1 1/4 X 16 Ga   |
| 76              | 812 00 00-01 | E-ring #5133-75                |
| 77              | 532 12 35-83 | Key Square 2 0 X 1845/ 1865    |
| 78              | 532 12 17-48 | Washer 25/32 X 1-5/8 X 16 Ga   |
| 79              | 532 12 50-96 | Key Woodruff #9 3/16 x 3/4     |
| 96              | 532 12 47-88 | Retainer Spring 1"             |
| 112             | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.     |
| 113             | 532 12 72-85 | Strap Torque LT                |
| 116             | 872 14 06-08 | Bolt Rdhd Sq Neck 3/8-16 x 1   |
| 120             | 873 90 06-00 | Nut Lock Flg. 3/8-16           |
| 145             | 874 49 05-40 | Bolt Hex Flg Hd 5/16-18 Gr 5   |
| 150             | 532 17 54-56 | Spacer Retainer                |
| 151             | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga.      |
| 170             | 532 17 83-94 | Keeper Belt T/A                |
| 202             | 872 11 06-14 | Bolt RDHD 3/8-16 x 1-3/4 Gr 5  |
| 212             | 532 14 52-12 | Nut Hex Flg Lock               |
| 250             | 817 06 06-12 | Screw 3/8-16 x .75             |
| 263             | 817 00 05-12 | Screw Hexwsh Thdr 3/8-16 x 3/4 |
| 269             | 532 18 24-02 | Guard Muffler OHV B&S RH       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
STEERING ASSEMBLY



# REPAIR PARTS


TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
STEERING ASSEMBLY

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 13 97-68 | Wheel Steering                 |
| 2       | 532 17 51-31 | Axle Asm                       |
| 3       | 532 16 98-40 | Spindle Asm LH                 |
| 4       | 532 16 98-39 | Spindle Asm RH                 |
| 5       | 532 12 49-31 | Bearing Race Thrust Harden     |
| 6       | 532 12 17-48 | Washer 25/32 X 1-5/8 X 16 Ga   |
| 7       | 819 27 20-16 | Washer 27/32 X 1-1/4 X 16 Ga   |
| 8       | 812 00 00-29 | Ring Klip #t5304-75            |
| 9       | 532 12 49-37 | Bearing Col Strg Blk           |
| 10      | 532 17 51-21 | Link Drag                      |
| 11      | 810 04 06-00 | Washer Lock Hvy Hlcl Spr 3/8   |
| 12      | 873 94 08-00 | Nut Hex Jam Toplock 1/2-20 Unf |
| 13      | 532 13 65-18 | Spacer Brg Axle Front          |
| 15      | 532 14 52-12 | Nut Hex Flange Lock            |
| 17      | 532 18 06-41 | Shaft Asm Strg                 |
| 26      | 532 12 68-47 | Bushing Link Drag Blk LR       |
| 28      | 819 13 14-16 | Washer 13/32 X 7/8 X 16 Ga     |
| 29      | 817 06 06-12 | Screw 3/8-16x3/4               |
| 30      | 876 02 04-12 | Pin Cotter 1/8 X 3/4 Cad       |
| 32      | 532 13 04-65 | Rod Tie Wire Form 19 75 Mech   |
| 36      | 532 15 50-99 | Bushing Strg                   |
| 37      | 532 15 29-27 | Screw                          |
| 38      | 532 14 01-75 | Insert Cap Strg Wh             |
| 39      | 819 18 38-12 | Washer 9/16 X 2-3/8 x 12       |
| 40      | 532 12 47-01 | Lock nut                       |
| 41      | 532 10 07-11 | Adaptor Wheel Strg             |
| 42      | 532 16 96-33 | Boot Steering Shaft            |
| 43      | 532 12 17-49 | Washer 25/32 X 1-1/4 X 16 Ga   |
| 44      | 532 18 06-40 | Extension Steering Shaft LR/LT |
| 46      | 532 12 12-32 | Cap Spindle Fr Top Blk         |
| 47      | 532 18 32-26 | Fitting Grease                 |
| 51      | 873 54 04-00 | Nut Crownlock 1/4-28           |
| 54      | 871 13 04-20 | Bolt Hex 1/4-28 Unf            |
| 65      | 532 16 03-67 | Spacer Brace Axle              |
| 67      | 872 14 06-18 | Bolt, Rdhd Sqnk 3/8-16 x 2-1/4 |
| 68      | 532 16 98-27 | Axle, Brace                    |
| 71      | 532 17 51-46 | Steering Asm.                  |
| 82      | 532 16 98-35 | Bracket Susp Chassis Front     |
| 85      | 532 13 38-35 | Fastener Christmas Tree        |
| 88      | 532 17 51-18 | Bolt Shoulder 7/16-20          |
| 91      | 532 17 55-53 | Clip Steering                  |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
SEAT ASSEMBLY




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 17 53-90 | Seat                           |
| 2       | 532 14 05-51 | Bracket Pivot Seat 8 720       |
| 3       | 871 11 06-16 | Bolt Fin Hex 3/8-16unc X 1     |
| 4       | 819 13 16-10 | Washer 13/32 X 1 X 10 Ga       |
| 5       | 532 14 50-06 | Clip Push-In                   |
| 6       | 873 80 06-00 | Nut Hex w/Ins. 3/8-16 Unc      |
| 7       | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi |
| 8       | 817 00 06-16 | Screw 3/8-16 X 1-1/2           |
| 9       | 819 13 16-14 | Washer 13/32 X 1 X 14 Ga.      |
| 10      | 532 18 24-93 | Pan Seat                       |
| 12      | 532 12 12-46 | Bracket Mounting Switch        |
| 13      | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id     |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 14      | 872 05 04-12 | Bolt Rdhd Sqnk 1/4-20x1-1/2    |
| 15      | 532 13 43-00 | Spacer Split 28x 96 Yel Zinc   |
| 16      | 532 12 12-50 | Spring Cprsn 1 27 Blk Pnt      |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr 5 Zinc |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 Unc      |
| 22      | 873 80 05-00 | Nut Hex Lock W/Ins 5/16-18     |
| 23      | 871 11 08-14 | Bolt Hex                       |
| 24      | 819 17 19-12 | Washer 17/32 X 1-3/16 X 12 Ga. |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 X 62     |
| 26      | 810 04 08-00 | Washer Lock Hvy HLCL SPR 1/2   |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm

# REPAIR PARTS


TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
DECALS



| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 16 79-70 | Decal Steering Wheel            |
| 2       | 532 14 08-37 | Decal Saddle Brake Parking      |
| 3       | 532 17 16-68 | Decal Hood                      |
| 4       | 532 17 58-06 | Decal Fender                    |
| 5       | 532 18 47-66 | Decal HP Engine                 |
| 6       | 532 18 04-32 | Decal Europe Stand CE           |
| 8       | 532 18 21-66 | Decal Mower Cutfinger           |
| 10      | 532 14 54-98 | Decal Read Owner's Manual Syms. |
| 11      | 532 15 97-36 | Decal Chassis Hot Muffler       |
| 12      | 532 15 97-37 | Decal Brake/ Clutch Symbol Lt   |

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 13      | 532 13 49-99 | Decal Deck Enviro               |
| 14      | 532 13 68-32 | Decal V-Belt Schematic          |
| 20      | 532 14 50-05 | Decal Bat Dan/Psn               |
| --      | 532 16 25-98 | Decal Drawbar                   |
| --      | 532 13 83-11 | Decal Handle Lift Height Adjust |
| --      | 532 18 51-49 | Manual Operator's (Euro.)       |
| --      | 532 18 42-75 | Manual Parts                    |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 10 62-22 | Tire F Ts 15 X 6 0 - 6 Service    |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 18 33-37 | Rim Asm 6"front White Service     |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 18 33-38 | Rim Asm 8"rear White Service      |
| 9       | 532 12 46-35 | Tire R Ts 18x8.5-8 C Service      |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 X 1 00          |
| --      | 532 14 43-34 | Sealant, Tire ( 10 oz. Tube)      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
ENGINE




| KEY NO. | PART NO.     | DESCRIPTION                                                           |
|---------|--------------|-----------------------------------------------------------------------|
| 1       | 532 17 05-51 | Control Th/ch Flag                                                    |
| 2       | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                                        |
| 3       | -----        | Engine B&S Model No. 21A807<br>(Order Parts From Engine Manufacturer) |
| 4       | 532 17 97-58 | Muffler LT B&S 12/12.5/13HP                                           |
| 13      | 532 16 52-91 | Gasket Eng 1 313 Id Tin Plated                                        |
| 14      | 532 14 84-56 | Tube Drain Oil Easy                                                   |
| 16      | 811 05 06-00 | Washer Lock Ext Tooth 3/8                                             |
| 23      | 532 16 98-37 | Shield Brn/Dbr Guard                                                  |
| 25      | 532 18 09-45 | Control Choke                                                         |
| 26      | 873 92 06-00 | Nut Keps 3/8-24 Unf                                                   |
| 29      | 532 13 71-80 | Kit Spark Arrestor (Flat Scrn)                                        |
| 31      | 532 10 92-02 | Tank Fuel Front                                                       |

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 32      | 532 14 05-27 | Cap Asm Fuel W/sym Vented         |
| 33      | 532 12 34-87 | Clamp Hose Black                  |
| 37      | 532 13 70-40 | Line Fuel 20"                     |
| 38      | 532 18 16-54 | Plug Drain Oil Easy               |
| 40      | 532 12 40-28 | Bushing Snap Nyl Blk Fuel Line    |
| 44      | 817 67 04-12 | Screw Hexwsh Thdrol 1/4-20x3/4    |
| 45      | 817 00 06-12 | Screw Hex Wsh Thdrol 3/8-16 x 3/4 |
| 46      | 819 09 14-16 | Washer 9/32 X 7/8 X 16 Ga         |
| 62      | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16     |
| 72      | 871 07 05-12 | Screw Hexhd Cap 5/16-18 x 3/4     |
| 78      | 817 06 06-20 | Screw 3/8-16x1-1/4                |
| 81      | 873 51 04-00 | Nut 1/4-20                        |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
MOWER LIFT




| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 15 94-60 | Wire Asm Inner/Spring W/plunger |
| 2       | 532 15 94-71 | Shaft Asm Lift                  |
| 3       | 532 10 57-67 | Pin Groove                      |
| 4       | 812 00 00-02 | E Ring #5133-62                 |
| 5       | 819 21 16-21 | Washer PLTD 21/32 X 1 X 21ga    |
| 6       | 532 12 01-83 | Bearing Nylon Blk 629 Id        |
| 7       | 532 10 94-13 | Grip Handle                     |
| 8       | 532 12 45-26 | Button Plunger Black            |
| 11      | 532 13 98-65 | Link Lift LH                    |
| 12      | 532 13 98-66 | Link Lift RH                    |
| 13      | 532 12 46-70 | Retainer Spring                 |

| KEY NO. | PART NO.     | DESCRIPTION              |
|---------|--------------|--------------------------|
| 15      | 532 17 32-88 | Link Front               |
| 16      | 873 35 08-00 | Nut Jam Hex 1/2-13 Unc   |
| 17      | 532 17 56-89 | Trunnion                 |
| 18      | 873 80 08-00 | Nut Lock W/wsh 1/2-13unc |
| 19      | 532 13 98-68 | Arm Suspension Rear      |
| 20      | 532 16 35-52 | Spring, Retainer         |
| 31      | 532 16 98-65 | Bearing Pvt. Lift        |
| 32      | 873 54 06-00 | Nut Crownlock 3/8-24     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00  
MOWER DECK



# REPAIR PARTS

**TRACTOR - MODEL NO. MBA1396 (MBA1396C), PRODUCT NO. 964 79 24-00**  
**MOWER DECK**

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 17 02-80 | Mower Deck Assembly             |
| 2       | 872 14 05-06 | Bolt                            |
| 3       | 532 13 80-17 | Bracket Assembly, Sway Bar      |
| 4       | 532 16 99-70 | Bracket Sway Bar Deck           |
| 5       | 532 12 46-70 | Retainer Spring                 |
| 6       | 532 17 80-24 | Bar Sway                        |
| 8       | 532 85 08-57 | Bolt, Hex 3/8-24 x 1.25 Gr. 8   |
| 9       | 810 03 06-00 | Washer, Lock Hvy Hlcl 3/8       |
| 10      | 532 14 02-96 | Washer, Hardened                |
| 11      | 532 13 84-97 | Blade, Mower 38                 |
| 13      | 532 13 76-45 | Shaft Assembly, Mandrel, Vented |
| 14      | 532 12 87-74 | Housing, Mandrel, Vented        |
| 15      | 532 11 04-85 | Bearing, Ball, Mandrel          |
| 16      | 532 17 44-93 | Stripper, Vented Mower Deck     |
| 19      | 532 13 28-27 | Bolt, Shoulder                  |
| 21      | 873 68 05-00 | Nut Crownlock 5/16-18           |
| 23      | 532 13 76-07 | Bracket, Mower Deflector        |
| 24      | 532 10 53-04 | Cap, Sleeve                     |
| 25      | 532 12 37-13 | Spring, Torsion, Deflector      |
| 26      | 532 11 04-52 | Nut, Push                       |
| 27      | 532 17 59-43 | Shield, Deflector               |
| 28      | 819 11 10-16 | Washer 11/32 x 5/8 x 16 Ga.     |
| 29      | 532 10 67-35 | Rod, Hinge                      |
| 30      | 532 17 39-84 | Screw Thdrol                    |
| 31      | 532 12 99-63 | Washer, Spacer                  |
| 32      | 532 15 35-32 | Pulley, Mandrel                 |
| 33      | 532 17 83-42 | Nut, Toplock, Flanged           |
| 36      | 532 13 14-94 | Pulley, Idler, Flat             |
| 40      | 873 68 06-00 | Nut Crownlock 3/8-16            |
| 45      | 532 12 47-88 | Retainer, Spring                |
| 53      | 532 13 08-40 | Brake Assembly                  |
| 54      | 532 17 85-15 | Washer, Hardened                |
| 55      | 532 13 38-40 | Idler Arm Assembly              |
| 56      | 532 16 57-23 | Spacer, Retainer                |
| 67      | 532 10 69-32 | Knob RD 3/8-16 Plstc Thd        |
| 68      | 532 18 02-14 | Belt                            |

| KEY NO. | PART NO.     | DESCRIPTION                                                                               |
|---------|--------------|-------------------------------------------------------------------------------------------|
| 69      | 876 02 03-12 | Pin, Cotter 3/32 x 3/4                                                                    |
| 86      | 532 12 50-74 | Runner, LH                                                                                |
| 87      | 532 12 87-72 | Runner, RH                                                                                |
| 88      | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga                                                                |
| 89      | 819 13 16-12 | Washer 13/32 x 1 x 12 Ga                                                                  |
| 96      | 873 93 06-00 | Nut Centerlock 3/8-16                                                                     |
| 97      | 874 93 06-20 | Bolt 3/8-16 x 1-1/4                                                                       |
| 98      | 810 04 06-00 | Washer Lock 3/8                                                                           |
| 99      | 819 13 20-16 | Washer 13/32 x 1-1/4 x 16 Ga.                                                             |
| 100     | 532 13 56-51 | Nut Wing                                                                                  |
| 101     | 532 13 28-03 | Cover Mulch 38"                                                                           |
| 107     | 532 13 35-02 | Spacer, Retainer                                                                          |
| 108     | 532 13 35-03 | Stiffener, Idler Arm                                                                      |
| 109     | 874 76 06-40 | Bolt, Hex Head 3/8-16 x 2-1/2                                                             |
| 110     | 532 14 25-87 | Upstop Deck Front 38                                                                      |
| 113     | 817 06 05-12 | Screw 5/16-18 x 3/8                                                                       |
| 122     | 532 13 12-89 | Rod, Brake, LH                                                                            |
| 123     | 532 16 99-71 | Rod, Brake, RH                                                                            |
| 146     | 532 16 58-91 | Bolt Carriage Idler                                                                       |
| 148     | 532 16 90-22 | Spring Return Idler                                                                       |
| 149     | 532 16 58-98 | Retainer Spring Yellow Zinc                                                               |
| 150     | 819 09 12-16 | Washer 9/32 x 3/4 x 16 Ga.                                                                |
| 151     | 532 16 96-70 | Bracket Clutch                                                                            |
| 152     | 532 17 27-58 | Cable Clutch 38 In                                                                        |
| 153     | 532 16 96-74 | Washer Flat 3/8" Type B                                                                   |
| 154     | 532 16 96-75 | Spring Retainer                                                                           |
| 155     | 532 16-96-71 | Spring Retention Lever                                                                    |
| 156     | 532 16 96-72 | Spacer                                                                                    |
| 157     | 532 16 96-69 | Rod Clutch                                                                                |
| 158     | 817 72 04-08 | Screw Hex Thd Cut 1/4-20x1/2                                                              |
| --      | 532 13 07-94 | Mandrel Assembly (Includes Housing, Shaft, and Shaft Hardware Only - Pulley Not Included) |
| --      | 532 18 13-80 | Mower Deck, Complete                                                                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## SERVICE NOTES

[www.emc-motoculture.com](http://www.emc-motoculture.com)



Issued January 1980  
Revised January 1991

# SERVICE POLICY WARRANTY



## LIMITED WARRANTIES FOR NEW PEERLESS GEAR POWER TRAIN COMPONENTS

### A. Products Warranted

Peerless Gear and Machine Division of Tecumseh Products Company ("Tecumseh"), subject to the limitations contained below, will, at its option, repair or replace, without charge for parts or labor only, any part of a new Power Train Component (which as used herein means and includes the transaxle, gear box, transmission, differential and right angle drives, and any part of the Power Train Component), EXCEPT any new Power Train Component incorporated in equipment used for commercial or rental purposes, which is found upon examination by any Tecumseh Authorized Service Outlet or by Tecumseh's factory in Grafton, Wisconsin, to be DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP if received by Tecumseh or a Tecumseh Authorized Service Outlet for such examination within TWO YEARS from the date of sale to the original consumer purchaser of Peerless Series 820, 900, 910, 915, 920, 930 transaxles and Series 1100 angle drive and ONE YEAR for all other Peerless products. New Power Train Components incorporated in equipment used for commercial purposes are warranted in the same manner and to the same extent EXCEPT such Power Train Components are warranted for NINETY (90) DAYS ONLY, and must be received by Tecumseh or by a Tecumseh Authorized Service Outlet for such examination within 90 days from the date of sale to the original purchaser. New Power Train Components incorporated in equipment used for rental purposes are warranted in the same manner and to the same extent EXCEPT such Power Train Components are warranted for THIRTY (30) DAYS ONLY, and must be received by Tecumseh or a Tecumseh Authorized Service Outlet within 30 days from the date of sale to the original purchaser.

### B. Products And Items Not Warranted

1. Alterations or Modifications of Power Train Components.
2. Accidents, Normal Maintenance, Failure to follow the Original Equipment Manufacturer's Manual.

This warranty covers only parts of new Power Train Components which are found upon examination to be defective in material or workmanship as delivered to the original purchaser. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, failure to follow the instructions contained in an Instruction Manual for the operation of the Power Train Component and parts. The cost of normal maintenance and replacement of service items which are not defective shall be paid for by the original purchaser.

### C. Securing Warranty Service

Warranty service can be arranged for by contacting either a Tecumseh Authorized Service Outlet (any Tecumseh Registered Service Dealer, Tecumseh Authorized Service Distributor, or Tecumseh Central Warehouse Distributor) or by contacting Tecumseh, c/o Service Manager, Engine and Transmission Group Service Division, 900 North Street, Grafton, Wisconsin 53024. Warranty service can only be performed by a Tecumseh Authorized Service Outlet or by Tecumseh at its factory in Grafton, Wisconsin. At the time of requesting warranty service, evidence must be presented of the date of sale to the original purchaser. The purchaser shall pay any charges for making service calls and/or for transporting the product to and from the place where the inspection and/or warranty work is performed. The purchaser shall be responsible for any damage or loss incurred in connection with the transportation of Power Train Components and/or part(s) of the Power Train Components submitted for inspection and/or warranty work.

### D. Limitation of Damages and Implied Warranties

The foregoing EXPRESSED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. Neither Tecumseh nor any of its affiliates makes any warranties, representations or promises, written or oral, as to the quality of the Power Train Component or any of its parts, other than as set forth herein.

ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, TO THE EXTENT THAT EITHER MAY APPLY TO ANY PART(S) OF POWER TRAIN COMPONENTS, SHALL BE LIMITED IN DURATION TO THE PERIODS OF THE EXPRESSED WARRANTIES DEFINED IN PARAGRAPH A HEREOF. IN NO EVENT WILL TECUMSEH BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES AND/OR EXPENSES. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state.

### E. No Dealer Warranty

Tecumseh neither assumes nor authorizes any other person, natural or corporate, to assume for Tecumseh any other obligations or liabilities in connection with or with respect to any part(s) of a Power Train Component. The seller or dealer of part(s) of a Power Train Component has no authority, whatsoever, to make any representations or promises on behalf of Tecumseh or to modify the terms or limitations of Tecumseh's warranty in any way.

[www.emc-motoculture.com](http://www.emc-motoculture.com)

**Mr.Bricolage**