







## Section: PARK COMPACT ACCESSORY BAGS

| Pos.      | Quantity | Spare part No | Description         | Kit | Notes              | New |
|-----------|----------|---------------|---------------------|-----|--------------------|-----|
| 6101 6103 |          |               |                     |     |                    |     |
| 0         | 1        | 1134-4249-05  | Assembly parts      |     | Inkl. pos 1 - 15   |     |
| 0         | 1        | 1134-4249-06  | Assembly parts      |     | Inkl. pos 1 - 17   |     |
| 2         | 1        | 1134-4541-01  | .Spark plug wrench  |     | 5/8" (16 mm)/21 mm |     |
| 3         | 1        | 1111-2113-01  | .Rod                |     |                    |     |
| 4         | 1        | 9595-0262-00  | .Locating pin       |     |                    |     |
| 5A        | 1        | 9699-0103-02  | .Flat washer        |     | 0.5 mm             |     |
| 5B        | 1        | 9699-0114-02  | .Flat washer        |     | 1.0 mm             |     |
| 6         | 2        | 1134-4185-01  | .Flange washer      |     |                    |     |
| 7         | 2        | 9959-0820-16  | .Screw              |     |                    |     |
| 8         | 2        | 1134-4481-01  | .Wing nut           |     |                    |     |
| 9         | 2        | 9699-0062-02  | .Flat washer        |     |                    |     |
| 10        | 2        | 1134-4734-01  | .Ignition key       |     |                    |     |
| 12        | 2        | 9997-0820-16  | .Screw              |     |                    |     |
| 13        | 1        | 1134-5512-01  | .Towing plate       |     |                    |     |
| 14        | 2        | 9959-0820-16  | .Screw              |     |                    |     |
| 15        | 2        | 9739-0831-22  | .Nut                |     |                    |     |
| 16        | 1        | 1134-5482-01  | .Gear shift lever   |     |                    |     |
| 17        | 1        | 1134-2551-01  | .Knob               |     |                    |     |
| 30        | 1        | 1134-3771-72  | Folder w.manuals    |     |                    |     |
| 31        | 1        | 8211-0209-11  | .Safety regulations |     |                    |     |
| 31        | 1        | 8211-1023-01  | .Owner's manual     |     |                    |     |
| 31        | 1        | 8211-1024-01  | .Assembly instructi |     |                    |     |
| 31        | 1        | 8211-0277-04  | .Service book       |     |                    |     |
| 31        | 1        | 8211-2002-03  | .Warranty card      |     |                    |     |

## Section: PARK COMPACT BODY WORK

| Pos. | Quantity | Spare part No | Description  | Kit                | Notes              | New |
|------|----------|---------------|--------------|--------------------|--------------------|-----|
| 6101 | 6103     |               |              |                    |                    |     |
| 1    | 1        | 1             | 1134-5263-02 | Engine hood-yellow |                    |     |
| 2    | 7        | 7             | 9838-9530-12 | Screw              |                    |     |
| 3    | 1        | 1             | 1134-9028-01 | Rubber strap kit   | Sats 3 st/kit of 3 |     |
| 4    | 1        | 1             | 9632-0516-00 | Pop rivet          |                    |     |
| 5    | 1        | 1             | 9699-0120-02 | Washer             |                    |     |
| 6    | 1        | 1             | 1134-5264-01 | Engine cover-grey  |                    |     |
| 7    | 1        | 1             | 1134-5308-01 | Mud guard LH-grey  |                    |     |
| 8    | 1        | 1             | 1134-5308-02 | Mud guard RH-grey  |                    |     |
| 9    | 4        | 4             | 9893-0616-16 | Screw              |                    |     |
| 10   | 4        | 4             | 1134-4176-01 | Clips              |                    |     |
| 11   | 2        | 2             | 1134-0225-00 | Support plate      |                    |     |
| 12   | 6        | 6             | 9945-0816-16 | Screw              |                    |     |
| 13   | 4        | 4             | 9699-0056-02 | Flat washer        |                    |     |
| 14   | 1        | 1             | 1134-5306-01 | Bumper, front-LH   |                    |     |
| 15   | 1        | 1             | 1134-5306-02 | Bumper, front-RH   |                    |     |
| 16   | 4        | 4             | 9893-0616-16 | Screw              |                    |     |
| 17   | 2        | 2             | 1134-4176-01 | Clips              |                    |     |
| 18   | 1        | 1             | 1134-5305-01 | Front plate-lower  |                    |     |
| 19   | 2        | 2             | 9893-0616-16 | Screw              |                    |     |
| 20   | 1        |               | 1134-5320-01 | Front-upper        |                    |     |
| 20   |          | 1             | 1134-5320-02 | Front-upper        |                    |     |
| 21   | 2        | 2             | 9946-0525-16 | Screw              |                    |     |
| 22   | 1        | 1             | 1134-5265-01 | Hood support       |                    |     |
| 23   | 4        | 4             | 9893-0616-16 | Screw              |                    |     |
| 24   | 1        | 1             | 1134-3970-05 | Moulding-LH, grey  |                    |     |
| 25   | 1        | 1             | 1134-3970-02 | Moulding-RH, grey  |                    |     |
| 26   | 2        | 2             | 9893-0616-16 | Screw              |                    |     |
| 99   |          | 1             | 1134-5592-02 | Label kit          |                    |     |
| 99   | 1        |               | 1134-5592-01 | Label kit          |                    |     |






## Section: PARK COMPACT EL. EQUIPMENT


| Pos.      | Quantity | Spare part No | Description  | Kit                 | Notes | New |
|-----------|----------|---------------|--------------|---------------------|-------|-----|
| 6101 6103 |          |               |              |                     |       |     |
| 1         | 1        | 1             | 1134-4804-01 | Battery             |       |     |
| 2         | 1        |               | 1134-5323-01 | Harness             |       |     |
| 2         |          | 1             | 1134-5324-01 | Harness             |       |     |
| 2A        | 1        | 1             | 1134-3496-06 | .Fuse               | 20A   |     |
| 3         | 1        | 1             | 1134-5343-01 | Battery bracket     |       |     |
| 4         | 3        | 3             | 9852-8013-16 | Screw               |       |     |
| 5         | 2        | 2             | 9699-0060-02 | Flat washer         |       |     |
| 6         | 1        | 1             | 1134-2962-01 | Solenoid assy       |       |     |
| 7         | 2        | 2             | 9852-8013-16 | Screw               |       |     |
| 8         | 2        | 2             | 9794-5131-02 | .Nut                |       |     |
| 9         | 1        | 1             | 1134-4093-01 | Ignition switch     |       |     |
| 10        | 1        | 1             | 1134-4749-01 | Nut                 |       |     |
| 11        | 1        | 1             | 1134-5245-01 | Battery strap       |       |     |
| 12        | 1        | 1             | 1134-2167-01 | Cable               |       |     |
| 13        | 1        | 1             | 1134-0234-02 | Battery cable ( + ) |       |     |
| 14        | 1        | 1             | 1134-2310-01 | Guard cap           |       |     |
| 15        | 1        | 1             | 9795-3531-02 | Nut                 |       |     |
| 16        | 15       | 15            | 9579-0003-00 | Cable holder        |       |     |
| 20        | 1        |               | 1134-2871-03 | Relay               |       |     |
| 21        | 1        |               | 9852-8013-16 | Screw               |       |     |
| 25        |          | 1             | 1134-3399-02 | Switch              |       |     |
| 26        |          | 2             | 9997-0520-16 | Screw               |       |     |
| 27        |          | 2             | 9747-0531-02 | Nut                 |       |     |
| 28        |          | 1             | 9400-0231-00 | Splicer             |       |     |

www.emc-motoculture.com



## Section: PARK COMPACT ENGINE

| Pos.      | Quantity | Spare part No | Description  | Kit                 | Notes             | New |
|-----------|----------|---------------|--------------|---------------------|-------------------|-----|
| 6101 6103 |          |               |              |                     |                   |     |
| 1A        | 2        | 4             | 9997-0840-16 | Screw               | L = 40 mm         |     |
| 1B        | 1        |               | 9997-0845-12 | Screw               | L = 45 mm         |     |
| 1C        | 1        |               | 9997-0875-12 | Screw               | L = 75 mm         |     |
| 2         | 4        | 4             | 9739-0831-22 | Nut                 |                   |     |
| 3A        | 1        |               | 1134-5370-01 | Muffler             |                   |     |
| 3B        | 1        |               | 1134-5369-01 | Muffler             |                   |     |
| 4         | 1        | 1             | 1134-0433-00 | Muffler gasket      |                   |     |
| 5         | 2        | 2             | 1134-4930-01 | Screw               |                   |     |
| 6         | 1        | 1             | 9959-0820-16 | Screw               |                   |     |
| 7         | 1        | 1             | 9739-0831-22 | Nut                 |                   |     |
| 8         | 1        | 1             | 1134-5390-01 | Tow bar bracket     |                   |     |
| 9         | 4        | 4             | 9959-0820-16 | Screw               |                   |     |
| 10        | 4        | 4             | 9739-0831-22 | Nut                 |                   |     |
| 11        | 1        | 1             | 1134-4978-01 | Oil drain pipe assy |                   |     |
| 12        | 1        | 1             | 1134-4976-01 | .Plug               |                   |     |
| 13        | 1        | 1             | 1134-4977-01 | .Copper washer      |                   |     |
| 14        | 1        | 1             | 1134-4999-01 | Engine pulley       |                   |     |
| 15        | 1        | 1             | 1134-5000-01 | Engine pulley       |                   |     |
| 16        | 1        | 1             | 9600-0251-01 | Key                 | L = 2 1/2"        |     |
| 17        | 1        | 1             | 1134-5017-01 | Washer              |                   |     |
| 18        | 1        | 1             | 9987-5332-16 | Screw               |                   |     |
| 19        | 1        | 1             | 1134-4757-06 | Fuel tank assy      | Inkl. pos 20 - 24 |     |
| 20        | 1        | 1             | 1134-2877-03 | .Fuel tank cap      |                   |     |
| 21        | 1        | 1             | 1134-3224-01 | .Fuel shut-off valv |                   |     |
| 22        | 1        | 1             | 1134-3225-01 | .Grommet            |                   |     |
| 23        | 1        | 1             | 1134-2975-01 | .Fuel hose          | L = 520 mm        |     |
| 24        | 1        | 1             | 9578-0023-02 | .Hose clamp         |                   |     |
| 25        | 1        | 1             | 1134-5340-01 | Fuel tank bracket   |                   |     |
| 26        | 2        | 2             | 9959-0820-16 | Screw               |                   |     |
| 27        | 2        | 2             | 9739-0831-22 | Nut                 |                   |     |
| 28        | 2        | 2             | 1134-5346-01 | Fuel tank loop      |                   |     |
| 29        | 2        | 2             | 9747-0631-02 | Lock nut            |                   |     |
| 30        | 1        | 1             | 9579-0003-00 | Cable holder        |                   |     |
| 40        | 1        | 1             | 9578-0023-02 | Hose clamp          |                   |     |




## Section: PARK COMPACT FOOT CONTROLS

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|-------------|-----|-------|-----|
|------|----------|---------------|-------------|-----|-------|-----|

6101


|    |   |              |                      |  |                    |  |
|----|---|--------------|----------------------|--|--------------------|--|
| 1  | 1 | 1134-4247-01 | Brake/clutch pedal   |  |                    |  |
| 2  | 1 | 1134-9024-01 | .Bearing             |  | Sats 4 st/kit of 4 |  |
| 3  | 1 | 1134-3410-02 | Brake cable          |  |                    |  |
| 4  | 1 | 1134-3403-01 | Wire holder          |  |                    |  |
| 5  | 1 | 1134-3280-01 | Spring               |  |                    |  |
| 6  | 1 | 1134-3974-01 | Spring               |  |                    |  |
| 7  | 1 | 1134-4058-01 | Cable                |  |                    |  |
| 8  | 1 | 1134-2991-01 | Eye bolt             |  |                    |  |
| 9  | 1 | 9739-0531-22 | Nut                  |  |                    |  |
| 10 | 1 | 9747-0531-02 | Nut                  |  |                    |  |
| 13 | 1 | 1134-3974-01 | Spring               |  |                    |  |
| 14 | 1 | 1134-3400-01 | Angle plate          |  |                    |  |
| 15 | 2 | 9959-0816-16 | Screw                |  |                    |  |
| 16 | 2 | 9739-0831-22 | Nut                  |  |                    |  |
| 17 | 1 | 1134-2021-01 | Clamp                |  |                    |  |
| 18 | 1 | 1134-4048-02 | Gear shifter arm     |  |                    |  |
| 19 | 1 | 9699-0060-02 | Flat washer          |  |                    |  |
| 20 | 1 | 9987-5016-16 | Screw                |  |                    |  |
| 21 | 1 | 1134-5353-01 | Brake rod            |  |                    |  |
| 22 | 1 | 1134-2786-01 | Plastic knob         |  |                    |  |
| 23 | 1 | 1131-1497-01 | Spring               |  |                    |  |
| 24 | 1 | 1134-4002-01 | Brake rod attachment |  |                    |  |
| 25 | 3 | 9838-9516-12 | Screw                |  |                    |  |
| 26 | 1 | 9570-0001-00 | Elbow link           |  |                    |  |
| 27 | 2 | 9739-0531-22 | Nut                  |  |                    |  |

www.emc-motoculture.com




## Section: PARK COMPACT FRAME

| Pos.      | Quantity | Spare part No | Description  | Kit                 | Notes | New |
|-----------|----------|---------------|--------------|---------------------|-------|-----|
| 6101 6103 |          |               |              |                     |       |     |
| 1         | 1        | 1             | 1134-5315-02 | Frame-front         |       |     |
| 2         | 1        | 1             | 1134-3963-02 | .Clevis             |       |     |
| 3         | 1        | 1             | 1134-0031-00 | .Pivot shaft stop   |       |     |
| 4         | 1        | 1             | 9595-0262-00 | .Locating pin       |       |     |
| 5         | 1        | 1             | 1134-2171-01 | Spring              |       |     |
| 6         | 2        | 2             | 9501-0500-00 | Grease joint        |       |     |
| 8         | 1        | 1             | 1134-5313-01 | Frame-rear          |       |     |
| 9         | 2        | 2             | 9547-0001-00 | .Bearing            |       |     |
| 10        | 2        | 2             | 9501-0500-00 | Grease joint        |       |     |
| 11        | 1        | 1             | 1134-3968-02 | Centre shaft (188 m |       |     |
| 13        | 2        | 2             | 9699-0035-02 | Flat washer         |       |     |
| 14        | 2        | 2             | 9959-1020-16 | Screw               |       |     |
| 16        | 1        | 1             | 1134-5294-01 | Floor plate         |       |     |
| 17        |          | 1             | 1134-5514-01 | Floor mat           |       |     |
| 17        | 1        |               | 1134-5513-01 | Floor mat           |       |     |
| 18        | 2        | 2             | 9893-0616-16 | Screw               |       |     |
| 20        | 2        | 2             | 9945-0816-16 | Screw               |       |     |
| 21        | 2        | 2             | 9959-0820-16 | Screw               |       |     |
| 22        | 2        | 2             | 9739-0831-22 | Nut                 |       |     |
| 28        | 1        | 1             | 1134-4975-01 | Rubber block        |       |     |
| 29        | 1        | 1             | 9950-0570-12 | Screw               |       |     |
| 30        | 2        | 2             | 9739-0531-22 | Nut                 |       |     |
| 31        | 1        | 1             | 1134-5337-01 | Bumper-rear         |       |     |
| 32        | 2        | 2             | 1134-0240-00 | Shoulder screw      |       |     |
| 33        | 2        | 2             | 1134-4242-01 | Spacer washer       |       |     |
| 34        | 2        | 2             | 9665-0002-00 | Bowed washer        |       |     |
| 35        | 2        | 2             | 9747-0831-02 | Lock nut            |       |     |
| 36        | 2        | 2             | 9943-0516-16 | Screw               |       |     |
| 37        | 2        | 2             | 1134-5345-01 | Attachment          |       |     |
| 38        | 1        | 1             | 1134-5344-01 | Battery shelf       |       |     |
| 39        | 4        | 4             | 9945-0816-16 | Screw               |       |     |



## Section: PARK COMPACT HAND CONTROLS

| Pos.      | Quantity | Spare part No | Description  | Kit            | Notes          | New |
|-----------|----------|---------------|--------------|----------------|----------------|-----|
| 6101 6103 |          |               |              |                |                |     |
| 1         | 1        | 1             | 1134-5363-01 | Control lever  |                |     |
| 2         | 1        | 1             | 1134-2551-01 | Knob           |                |     |
| 3         | 1        | 1             | 1134-3790-02 | Bearing        |                |     |
| 4         | 1        |               | 9699-0090-02 | Flat washer    | 8.4 x 18 x 1.5 |     |
| 4         |          | 1             | 9699-0056-02 | Flat washer    | 8.4 x 24 x 2.0 |     |
| 5         | 1        | 1             | 4231-0013-00 | Spring         |                |     |
| 6         | 1        | 1             | 1134-5368-01 | Dashboard      |                |     |
| 7         | 1        | 1             | 9400-0312-01 | Micro switch   |                |     |
| 8         | 4        | 4             | 9946-0525-16 | Screw          |                |     |
| 9         | 1        | 1             | 1134-3573-05 | Control cable  |                |     |
| 20        | 1        | 1             | 1134-5465-01 | Throttle lever |                |     |
| 21        | 1        | 1             | 1134-4078-01 | Knob           |                |     |
| 22        | 1        | 1             | 1134-5464-01 | Bracket        |                |     |
| 23        | 1        | 1             | 1134-0240-00 | Shoulder screw |                |     |
| 24        | 2        | 2             | 1134-4242-01 | Spacer washer  |                |     |
| 25        | 1        | 1             | 9694-0001-00 | Washer         |                |     |
| 26        | 1        | 1             | 9747-0831-02 | Lock nut       |                |     |
| 27        | 1        | 1             | 1134-4197-02 | Throttle cable |                |     |
| 28        | 1        | 1             | 9500-9991-00 | Cable clamp    |                |     |
| 29        | 1        | 1             | 9943-0516-16 | Screw          |                |     |
| 40        | 1        |               | 1134-5459-01 | Gear shift arm |                |     |
| 41        | 1        |               | 1134-0240-00 | Shoulder screw |                |     |
| 42        | 1        |               | 9696-0013-01 | Bowed washer   |                |     |
| 43        | 1        |               | 9739-0831-22 | Nut            |                |     |
| 44        | 1        |               | 1134-2766-07 | Control cable  |                |     |
| 45        | 1        |               | 1134-5518-01 | Angle bracket  |                |     |
| 46        | 2        |               | 9897-0616-16 | Carriage bolt  |                |     |
| 47        | 2        |               | 9739-0631-22 | Nut            |                |     |
| 50        | 1        |               | 9570-0001-00 | Elbow link     |                |     |
| 51        | 2        |               | 9739-0531-22 | Nut            |                |     |




## Section: PARK COMPACT PEDAL LIFT

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|-------------|-----|-------|-----|
|------|----------|---------------|-------------|-----|-------|-----|

6101 6103


|    |   |   |              |                 |  |  |
|----|---|---|--------------|-----------------|--|--|
| 1A | 1 |   | 1134-5462-01 | Bracket         |  |  |
| 1B |   | 1 | 1134-4117-01 | Bracket         |  |  |
| 2  | 2 | 2 | 1134-2684-01 | Bearing         |  |  |
| 3  | 1 | 1 | 1134-4945-01 | Lift catch assy |  |  |
| 7  | 1 | 1 | 9404-0027-01 | .O-ring         |  |  |
| 8  | 1 | 1 | 9650-0039-04 | .Lock ring      |  |  |
| 9  | 1 | 1 | 9595-0276-01 | .Locating pin   |  |  |
| 10 | 1 | 1 | 9997-0640-12 | .Screw          |  |  |
| 11 | 1 | 1 | 9747-0631-02 | .Lock nut       |  |  |
| 13 | 1 | 1 | 9897-0820-16 | .Screw          |  |  |
| 14 | 1 | 1 | 9747-0831-02 | Lock nut        |  |  |
| 15 | 1 | 1 | 1134-4860-01 | Lift fork       |  |  |
| 16 | 2 | 2 | 1134-0240-00 | Shoulder screw  |  |  |
| 17 | 1 | 1 | 1134-4938-01 | Lift pedal      |  |  |
| 18 | 2 | 2 | 9997-0625-16 | Screw           |  |  |
| 19 | 2 | 2 | 9739-0631-22 | Nut             |  |  |
| 20 | 1 | 1 | 4231-0013-00 | Spring          |  |  |

www.emc-motoculture.com




## Section: PARK COMPACT POWER TAKE-OFF

| Pos. | Quantity | Spare part No | Description       | Kit | Notes          | New |
|------|----------|---------------|-------------------|-----|----------------|-----|
|      | 6101     |               |                   |     |                |     |
|      | 6103     |               |                   |     |                |     |
| 1    | 1        | 1134-5548-01  | Spacer            |     |                |     |
| 2    | 1        | 1134-5109-01  | Tension wheel arm |     |                |     |
| 3    | 1        | 1134-1770-01  | Tension roller    |     |                |     |
| 4    | 1        | 1134-1888-04  | Spacer            |     |                |     |
| 5    | 1        | 1134-5111-01  | Spring            |     |                |     |
| 6    | 1        | 9699-0056-02  | Flat washer       |     |                |     |
| 7    | 1        | 9739-0831-22  | Nut               |     |                |     |
| 8    | 1        | 9997-0855-12  | Screw             |     |                |     |
| 10   | 1        | 1134-1769-02  | Belt pulley assy  |     |                |     |
| 11   | 1        | 1134-0051-09  | .Spacer           |     |                |     |
| 12   | 2        | 9549-0019-00  | .Ball bearing     |     |                |     |
| 13   | 1        | 1134-5112-01  | Spring attachment |     |                |     |
| 14   | 2        | 9945-0816-16  | Screw             |     |                |     |
| 15   | 1        | 1134-5110-01  | Hook              |     |                |     |
| 16   | 2        | 9893-0616-16  | Screw             |     |                |     |
| 18   | 1        | 1134-2018-02  | Tension arm       |     |                |     |
| 19   | 1        | 1134-9027-01  | Tension roller    |     |                |     |
| 20   | 1        | 1134-9071-01  | V-belt            |     | = 9585-0129-01 |     |
| 21   | 1        | 9997-1030-16  | Screw             |     |                |     |
| 22   | 1        | 9799-1031-02  | Nut               |     |                |     |
| 23   | 1        | 1134-4111-01  | Brake arm         |     |                |     |
| 24   | 1        | 1134-4164-01  | Brake pad         |     |                |     |
| 25   | 1        | 9897-0825-16  | Screw             |     |                |     |
| 26   | 1        | 9747-0831-02  | Lock nut          |     |                |     |
| 27   | 1        | 1134-4162-01  | Brake rod         |     |                |     |
| 28   | 1        | 9675-0008-02  | Locking washer    |     |                |     |
| 29   | 1        | 1134-4170-01  | Nipple            |     |                |     |
| 30   | 1        | 9699-0025-02  | Washer            |     |                |     |
| 31   | 1        | 9747-0631-02  | Lock nut          |     |                |     |
| 32   | 1        | 4231-0013-00  | Spring            |     |                |     |
| 33   | 1        | 1134-4231-01  | Spring            |     |                |     |
| 34   | 1        | 1134-1565-10  | Spacer            |     |                |     |
| 35   | 1        | 9997-0865-12  | Screw             |     |                |     |
| 36   | 1        | 9699-0056-02  | Flat washer       |     |                |     |
| 37   | 1        | 9739-0831-22  | Nut               |     |                |     |
| 38   | 1        | 1134-4163-01  | Shoulder bolt     |     |                |     |
| 39   | 1        | 9747-1031-02  | Lock nut          |     |                |     |
| 40   | 1        | 1134-3958-01  | Belt guide        |     |                |     |
| 41   | 2        | 9893-0616-16  | Screw             |     |                |     |
| 42   | 1        | 1134-0041-03  | Collar            |     |                |     |
| 43   | 1        | 9997-1070-12  | Screw             |     |                |     |
| 44   | 1        | 9739-1031-22  | Nut               |     |                |     |
| 45   | 1        | 1134-3654-01  | Finger guard      |     |                |     |
| 46   | 2        | 9959-0612-16  | Screw             |     |                |     |
| 47   | 2        | 9739-0631-22  | Nut               |     |                |     |
| 48   | 1        | 9699-0090-02  | Flat washer       |     |                |     |
| 49   | 2        | 9699-0035-02  | Flat washer       |     |                |     |
| 50   | 1        | 9699-0035-02  | Flat washer       |     |                |     |




## Section: PARK COMPACT SEAT

| Pos. | Quantity | Spare part No | Description         | Kit | Notes     | New |
|------|----------|---------------|---------------------|-----|-----------|-----|
|      | 6101     |               |                     |     |           |     |
|      | 6103     |               |                     |     |           |     |
| 1    | 1        | 1134-5506-01  | Seat                |     |           |     |
| 3    | 1        | 1134-5301-01  | Seat plate          |     |           |     |
| 4    | 2        | 1134-0240-00  | Shoulder screw      |     |           |     |
| 5    | 2        | 9747-0831-02  | Lock nut            |     |           |     |
| 6    | 1        | 1134-5454-01  | Catch               |     |           |     |
| 7    | 1        | 9675-0012-02  | Locking washer      |     |           |     |
| 10   | 4        | 9893-0616-16  | Screw               |     |           |     |
| 11   | 1        | 1134-5300-01  | Rear plate          |     |           |     |
| 12   | 1        | 1134-5296-01  | Seat bracket-yellow |     |           |     |
| 13   | 1        | 1134-4256-01  | Seat spring         |     |           |     |
| 14   | 1        | 9924-1235-19  | Screw               |     |           |     |
| 15   | 1        | 9747-1231-02  | Lock nut            |     |           |     |
| 16   | 1        | 9997-0840-16  | Screw               |     |           |     |
| 17   | 1        | 1134-1565-06  | Spacer              |     |           |     |
| 18   | 1        | 1134-5302-01  | Spring              |     |           |     |
| 19   | 1        | 1134-5299-01  | Push plate          |     |           |     |
| 20   | 1        | 9699-0090-02  | Flat washer         |     |           |     |
| 21   | 1        | 9747-0831-02  | Lock nut            |     |           |     |
| 22   | 1        | 1134-3156-02  | Switch              |     |           |     |
| 26   | 2        | 9897-0880-12  | Screw               |     | L = 80 mm |     |
| 27   | 2        | 1134-1565-08  | Spacer              |     |           |     |
| 28   | 4        | 9897-0820-16  | Screw               |     | L = 20 mm |     |
| 29   | 6        | 9747-0831-02  | Lock nut            |     |           |     |




## Section: PARK COMPACT STEERING

| Pos. | Quantity | Spare part No | Description         | Kit | Notes              | New |
|------|----------|---------------|---------------------|-----|--------------------|-----|
|      | 6101     |               |                     |     |                    |     |
|      | 6103     |               |                     |     |                    |     |
| 1    | 1        | 1134-2820-06  | Chain               |     | 83 länk            |     |
| 2    | 1        | 1134-9084-01  | Steering cable assy |     | Sats vä+hö/kit l+r |     |
| 4    | 2        | 1134-2824-01  | Chain lock          |     |                    |     |
| 5    | 2        | 1134-3817-01  | Compression spring  |     |                    |     |
| 6    | 2        | 9699-0090-02  | Flat washer         |     |                    |     |
| 7    | 2        | 9747-0831-02  | Lock nut            |     |                    |     |
| 8    | 4        | 1134-2816-01  | Sprocket            |     |                    |     |
| 9    | 4        | 1134-0041-02  | Idler wheel bush    |     |                    |     |
| 10   | 4        | 9699-0035-02  | Flat washer         |     |                    |     |
| 11   | 2        | 9997-1050-16  | Screw               |     |                    |     |
| 12   | 2        | 9897-1040-12  | Screw               |     |                    |     |
| 13   | 4        | 9739-1031-22  | Nut                 |     |                    |     |
| 14   | 2        | 1134-9025-01  | Steering pulley-kit |     | Sats 2 st/kit of 2 |     |
| 15   | 2        | 1134-0041-01  | Bushing             |     |                    |     |
| 16   | 2        | 1134-3022-01  | Cable holder        |     |                    |     |
| 17   | 2        | 9997-1030-16  | Screw               |     |                    |     |
| 18   | 2        | 9739-1031-22  | Nut                 |     |                    |     |
| 19   | 1        | 1134-5349-01  | Steering console-ye |     |                    |     |
| 20   | 4        | 9897-0820-16  | Screw               |     |                    |     |
| 21   | 4        | 9739-0831-22  | Nut                 |     |                    |     |
| 22   | 1        | 1134-1305-05  | Steering column-low |     |                    |     |
| 23   | 2        | 1134-1901-01  | Bearing             |     |                    |     |
| 24   | 2        | 9893-0616-16  | Screw               |     |                    |     |
| 25   | 1        | 1134-2821-03  | Steering rod        |     |                    |     |
| 26   | 1        | 1134-2837-01  | Spacer              |     |                    |     |
| 27   | 1        | 1134-5496-01  | Steering wheel      |     |                    |     |



## Section: PARK COMPACT TRANSMISSION

| Pos. | Quantity | Spare part No | Description    | Kit | Notes          | New |
|------|----------|---------------|----------------|-----|----------------|-----|
| 6101 |          |               |                |     |                |     |
| 1    | 1        | 1134-9027-01  | Tension roller |     |                |     |
| 2    | 1        | 1134-2015-04  | Tension arm    |     |                |     |
| 3    | 1        | 1134-9013-01  | V-belt         |     | = 9585-0057-00 |     |
| 4    | 1        | 9799-1031-02  | Nut            |     |                |     |
| 5    | 1        | 9997-1030-16  | Screw          |     |                |     |
| 6    | 1        | 1134-4337-01  | Spring         |     |                |     |
| 7    | 1        | 1134-1565-01  | Spacer         |     |                |     |
| 8    | 1        | 1134-5282-01  | Transaxle assy |     | Dana 4360-198  |     |
| 9    | 4        | 9997-0865-12  | Screw          |     |                |     |
| 10   | 4        | 9747-0831-02  | Lock nut       |     |                |     |
| 11   | 1        | 1134-3182-01  | Belt pulley    |     |                |     |
| 13   | 1        | 9650-0016-04  | Lock ring      |     |                |     |
| 14   | 1        | 1134-2045-01  | Brake stop     |     |                |     |
| 15   | 1        | 1134-2986-01  | Bracket        |     |                |     |
| 17   | 2        | 9942-0820-16  | Screw          |     |                |     |
| 18   | 1        | 9959-0816-16  | Screw          |     |                |     |
| 19   | 2        | 9739-0831-22  | Nut            |     |                |     |
| 20   | 1        | 1134-5529-01  | Belt guide     |     |                |     |
| 21   | 1        | 9942-0820-16  | Screw          |     |                |     |
| 22   | 1        | 9699-0056-02  | Flat washer    |     |                |     |
| 26   | 1        | 1134-3289-02  | Belt guide     |     |                |     |
| 27   | 1        | 9739-0831-22  | Nut            |     |                |     |



## Section: PARK COMPACT WHEELS

| Pos. | Quantity | Spare part No | Description       | Kit | Notes               | New |
|------|----------|---------------|-------------------|-----|---------------------|-----|
|      | 6101     |               |                   |     |                     |     |
|      | 6103     |               |                   |     |                     |     |
| 1    | 2        | 1134-0075-01  | Front axle        |     |                     |     |
| 2    | 2        | 9595-0258-00  | Locating pin      |     |                     |     |
| 3    | 2        | 1134-4844-05  | Wheel hub assy    |     |                     |     |
| 3A   | 1        | 9501-0500-00  | .Grease joint     |     |                     |     |
| 4    | 1        | 1134-9026-01  | .Bearing bush kit |     | Sats 4 st/kit of 4  |     |
| 5    | 2        | 1134-5255-01  | Rim               |     |                     |     |
| 6    | 2        | 9545-0126-01  | Tyre              |     | 16 x 6.00 - 8       |     |
| 7    | 2        | 9545-0500-00  | Vallve            |     |                     |     |
| 8    | 6        | 9747-1031-02  | Lock nut          |     |                     |     |
| 9    | 6        | 9699-0035-02  | Flat washer       |     |                     |     |
| 10   | 8        | 1134-0341-01  | Washer            |     |                     |     |
| 11   | 2        | 9599-0080-02  | Cotter pin        |     |                     |     |
| 12   | 2        | 1134-4844-02  | Wheel hub         |     |                     |     |
| 13   | 2        | 1134-5255-01  | Rim               |     |                     |     |
| 14   | 2        | 9545-0126-01  | Tyre              |     | 16 x 6.00 - 8       |     |
| 15   | 2        | 9545-0500-00  | Vallve            |     |                     |     |
| 16   | 6        | 9747-1031-02  | Lock nut          |     |                     |     |
| 17   | 6        | 9699-0035-02  | Flat washer       |     |                     |     |
| 18   | 2        | 1134-4796-01  | Hub cap           |     |                     |     |
| 19   | 2        | 9947-0540-19  | Screw             |     |                     |     |
| 20   | 2        | 1134-2471-01  | Key               |     |                     |     |
| 21   | 2        | 9699-0042-02  | Flat washer       |     |                     |     |
| 22   | 2        | 9653-0001-04  | Lock ring         |     |                     |     |
| 25   | 2        | 9598-0003-02  | Spring pin        |     |                     |     |
| 26   | 2        | 9699-0042-02  | Flat washer       |     |                     |     |
| 99   |          | 9545-0203-00  | Inner tube        |     | Reservdel/spare par |     |