





Section: KANZAKI TRANSAXLE K46G (s/n 0042627-9999999)

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
K46G						
1	1	1134-4848-01	Transaxle assy		Kanzaki K46G	
2	1	1139-1470-01	Housing-upper			
3	1	1139-1402-01	Case-lower			
5	1	1139-1301-01	Tube			
6	2	1139-1336-01	Hose clamp			
8	2	1139-1150-01	Magnet			
9	1	1139-1341-01	Holder-magnet			
10	1	1139-1511-01	Pump shaft kit			
11	1	1139-1347-01	Spring			
12	1	1139-1251-01	Shaft-bypass			
13	1	1139-1189-01	Lever-bypass			
14	1	1139-1161-01	Ring			
15	1	1139-1275-01	Bore plug			
16	1	1139-1104-01	.Snap ring			
17	2	1139-1103-01	.Seal washer	S		
18	2	1139-1500-01	Drain bolt kit			
21	2	1139-1295-01	Tapping screw			
22	14	1139-0244-01	Tapping screw			
24	1	1139-1502-01	Center case assy			
25	1	1139-1158-01	Pin			
26	1	1139-1405-01	Filter	S		
27	3	1139-1294-01	Bolt			
28	2	1139-1339-01	Valve			
29	2	1139-1338-01	Spring			
30	2	1139-1346-01	Ball			
31	1	1139-1356-01	Cylinder block assy			
32	1	1139-1245-01	Spring			
33	1	1139-1246-01	Pump shaft			
34	3	1139-1146-01	.Ring			
35	1	1139-1116-01	.Ball bearing			
36	1	1139-1117-01	Housing			
37	1	1139-1501-01	Bearing			
38	1	1139-1139-01	Cylinder block assy			
39	1	1139-1160-01	Washer			
40	1	1139-1353-01	Motor shaft			
41	1	1139-1021-01	Snap ring			
42	1	1139-1272-01	Motor gear			
43	1	1139-1453-01	Bearing			
44	2	1139-1066-01	Metal thrust			
45	1	1139-1475-01	Swash plate assy			
46	1	1139-1362-01	Bearing			
49	1	1139-1354-01	Control shaft			
50	1	1139-1316-01	Fulcrum			
51	1	1139-1312-01	Spring			
52	1	1139-1409-01	Control arm			
53	1	1139-1325-01	Control lever			
54	1	1139-1408-01	Jerky plate			
55	1	1139-1102-01	Washer			
56	1	1139-1355-01	Cotter pin			
57	1	1139-1329-01	Pin			
58	1	1139-1285-01	Pin			
60	1	1139-1127-01	Nut			
61	1	1139-1404-01	Differential gear kit			
62	1	1139-1258-01	Final gear			
63	1	1139-1255-01	Collar			
64	1	1139-1256-01	Reduction shaft			


Section: KANZAKI TRANSAXLE K46G (s/n 0042627-9999999)

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
K46G						
65	2	1139-1398-01	Washer			
66	1	1139-1267-01	Reduction gear			
67	1	1139-1361-01	Final pinion			
68	1	1139-1344-01	Axle shaft-left			
69	1	1139-1345-01	Axle shaft-right			
70	2	1139-1078-01	Thrust washer			
71	2	1139-1163-01	Ring			
72	2	1139-1080-01	Seal	S		
73	2	1139-1164-01	Bushing			
74	2	1139-1414-01	.Bushing			
75	1	1139-1260-01	Brake shoe			
76	1	1139-1261-01	Brake arm			
77	1	1139-1320-01	Brake shaft			
78	1	1139-1411-01	Return spring			
79	1	1139-1264-01	Brake actuator			
80	1	1139-1282-01	Pin			
82	2	1139-1281-01	Pin			
83	1	1139-1248-01	Spline collar			
84	1	1139-1469-01	Pulley			
85	1	1134-4190-01	Fan			
86	1	1139-1266-01	Lock washer			
87	1	1139-1149-01	Snap ring			
90	1	1139-1280-01	Pin			
95	1	1139-1279-01	Pin			
98	1	1139-1306-01	Adapter			
99	1	1139-1443-01	Sealant	S		
102	1	1139-1276-01	Collar			
200	1	1139-1403-01	Seal kit		Märkta S/Marked S	
201	1	1139-1486-01	Repair kit			




Section: PARK COMPACT ASSEMBLY PARTS

Pos.	Quantity	Spare part No			Description	Kit	Notes	New
		6102						
	6101	6103	6104					
2	1	1	1	1134-6113-01	Battery screws			
4	1	1	1	9595-0262-00	Locating pin			
5A	1	1	1	9699-0103-02	Flat washer		0.5 mm	
5B	1	1	1	9699-0114-02	Flat washer		1.0 mm	
6	2	2	2	1134-4185-01	Flange washer			
7	2	2	2	9959-0820-16	Screw			
8	2	2	2	1134-4481-01	Wing nut			
9	4	4	4	9699-0056-02	Flat washer			
10	2	2	2	1134-4734-01	Ignition key			
12	2	2	2	9997-0820-16	Screw			
13	1	1	1	1134-5512-01	Towing plate			
14	2	2	2	9959-0820-16	Screw			
15	2	2	2	9739-0831-22	Nut			
18	2	2	2	9898-1035-16	Screw			
19	2	2	2	9739-1031-22	Nut			
31	1	1	1	8211-0950-80	Warranty card			
31	1	1	1	8211-0001-80	Owner's manual			
31	1	1	1	8211-0002-80	Owner's manual			
31	1	1	1	8211-0601-80	Assy instructions			
31	1	1	1	8211-0701-80	Safety regulations			
31	1	1	1	8211-0901-80	Service book			





Section: PARK COMPACT BODY WORK

Pos.	Quantity	Spare part No		Description	Kit	Notes	New
		6102					
	6101	6103	6104				
1	1	1	1	1134-5263-02	Engine hood-yellow		
2	7	7	7	9838-9530-12	Screw		
3	1	1	1	1134-9028-01	Rubber strap kit	Sats 1 st/kit of 3	
4	1	1	1	9632-0516-00	Pop rivet		
5	1	1	1	9699-0120-02	Washer		
6	1	1	1	1134-5264-01	Engine cover-grey		
7	1	1	1	1134-5308-01	Mud guard LH-grey		
8	1	1	1	1134-5308-02	Mud guard RH-grey		
9	4	4	4	9893-0616-16	Screw		
10	4	4	4	1134-4176-01	Clips		
11	2	2	2	1134-0225-00	Support plate		
12	6	6	6	9945-0816-16	Screw		
13	4	4	4	9699-0056-02	Flat washer		
14	1	1	1	1134-5306-01	Bumper, front-LH		
15	1	1	1	1134-5306-02	Bumper, front-RH		
16	2	2	2	9893-0616-16	Screw		
18	1	1	1	1134-5305-01	Front plate-lower		
19	2	2	2	9893-0616-16	Screw		
20	1			1134-5320-01	Front-upper		
20		1	1	1134-5320-02	Front-upper		
21	2	2	2	9946-0525-16	Screw		
22	1	1	1	1134-6241-01	Hood support		
23	3	3	3	9893-0616-16	Screw		
24	1	1	1	1134-3970-05	Moulding-LH, grey		
25	1	1	1	1134-3970-02	Moulding-RH, grey		
26	2	2	2	9893-0616-16	Screw		
27	2	2	2	9699-0060-02	Flat washer		
28	2	2	2	9747-0631-02	Lock nut		
29	2	2	2	9897-0616-16	Carriage bolt		
99	1			1134-6440-01	Label kit		
99		1		1134-6440-02	Label kit		
99			1	1134-6440-03	Label kit		




Section: PARK COMPACT EL. EQUIPMENT

Pos.	Quantity	Spare part No		Description	Kit	Notes	New
		6102					
	6101	6103	6104				
1	1	1	1	1134-4804-01	Battery		
2	1			1134-5768-01	Harness		
2		1	1	1134-5769-01	Harness		
2A	1	1	1	1134-3496-06	.Fuse	20A	
3	1	1	1	1134-5343-01	Battery bracket		
4	3	3	3	9852-8013-16	Screw		
5	2	2	2	9699-0060-02	Flat washer		
6	1	1	1	1134-2962-01	Solenoid assy		
7	2	2	2	9852-8013-16	Screw		
8	2	2	2	9794-5131-02	.Nut		
9	1	1	1	1134-4093-01	Ignition switch		
10	1	1	1	1134-4749-01	Nut		
11	1	1	1	1134-5245-01	Battery strap		
12	1	1	1	1134-2167-01	Cable		
13	1	1	1	1134-0234-02	Battery cable		
14	1	1	1	1134-2310-01	Guard cap		
15	1	1	1	9795-3531-02	Nut		
16	15	15	15	9579-0003-00	Cable holder		
20	1			1134-2871-03	Relay		
21	1			9852-8013-16	Screw		
22	1			9699-0099-02	Washer		
25		1	1	1134-3399-02	Switch		
26			2	9943-0516-16	Screw		
26		2		9997-0520-16	Screw		
27		2		9747-0531-02	Nut		




Section: PARK COMPACT ENGINE

Pos.	Quantity	Spare part No				Description	Kit	Notes	New
		6101	6102	6103	6104				
1	1					9997-0880-16		M8 x 80 mm	
1	3	4	4	4		9955-3725-16		3/8" UNC x 25 mm	
2	1					9739-0831-22		Nut	
3A	1	1				1134-5370-01		Muffler	
3B			1	1		1134-5369-01		Muffler	
4	1	1	1	1		1134-0433-00		Muffler gasket	
5	2	2	2	2		1134-4930-01		Screw	
6	1	1	1	1		9959-0820-16		Screw	
7	1	1	1	1		9739-0831-22		Nut	
8	1	1	1	1		1134-5390-01		Tow bar bracket	
9	4	4	4	4		9945-0816-16		Screw	
14	1	1	1	1		1134-6419-01		Engine pulley	
15	1	1	1	1		1134-6137-01		Engine pulley	
16	1	1	1	1		9600-0251-01		Key	L = 2 1/2"
17	1	1	1	1		1134-5017-01		Washer	
18	1	1	1	1		9987-5332-16		Screw	
19	1	1	1	1		1134-6618-01		Fuel tank	
20	1	1	1	1		1134-5532-01		Fuel tank cap	
21	1	1	1	1		1134-3224-01		Fuel shut-off valve	
22	1	1	1	1		1134-3225-01		Grommet	
23	1	1	1			1134-2975-01		Fuel hose	L = 520 mm
23				1		1134-2975-07		Fuel hose	L = 350 mm
24	1	1	1	1		9578-0023-02		Hose clamp	
25	1	1	1	1		1134-6627-01		Fuel tank bracket	
26	2	2	2	2		9959-0820-16		Screw	
27	2	2	2	2		9739-0831-22		Nut	
28	2	2	2	2		1134-5346-01		Fuel tank loop	
29	2	2	2	2		9747-0631-02		Lock nut	
30	1	1	1	1		9579-0003-00		Cable holder	
40	1	1	1	1		9578-0023-02		Hose clamp	
41	1	1	1	1		1134-5807-01		Oil drain assy	Pos 42-45 incl.
42	1	1	1	1		1134-5825-01		.Nipple	
43	1	1	1	1		9578-0023-04		.Hose clamp	
44	1	1	1	1		1134-3499-02		.Hose clamp	
45	1	1	1	1		1134-5826-01		.Plug	



Section: PARK COMPACT HAND CONTROLS


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6102					
	6103					
6101	6104					
1	1	1	1134-6301-01	Engagement lever		
2	1	1	1134-2551-01	Knob		
3	1	1	1134-3790-02	Bearing		
4	1	1	9699-0090-02	Flat washer		
5	1	1	4231-0013-00	Spring		
6	1	1	1134-5368-01	Dashboard		
7	1	1	9400-0312-01	Micro switch		
8	4	4	9946-0525-16	Screw		
9	1	1	1134-3573-05	Control cable		
20	1	1	1134-5465-01	Throttle lever		
21	1	1	1134-4078-01	Knob		
22	1	1	1134-5464-01	Bracket		
23	1	1	1134-0240-00	Shoulder screw		
24	2	2	1134-4242-01	Spacer washer		
25	1	1	9694-0001-00	Washer		
26	1	1	9747-0831-02	Lock nut		
27	1	1	1134-4197-03	Throttle cable		
28	1	1	9500-9991-00	Cable clamp		
29	1	1	9943-0516-16	Screw		
38	1		1134-2551-01	Knob		
39	1		1134-5482-01	Gear shift lever		
40	1		1134-5459-01	Gear shift arm		
41	1		1134-0240-00	Shoulder screw		
42	1		9696-0013-01	Bowed washer		
43	1		9739-0831-22	Nut		
44	1		1134-2766-07	Control cable		
45	1		1134-5518-01	Angle bracket		
46	2		9897-0616-16	Carriage bolt		
47	2		9739-0631-22	Nut		
50	1		9570-0001-00	Elbow link		
51	2		9739-0531-22	Nut		



Section: PARK COMPACT PEDAL LIFT


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		6102				
		6103				
	6101	6104				
1A	1	1134-5462-01	Bracket			
1B	1	1134-4117-01	Bracket			
2	2	1134-2684-01	Bearing			
3	1	1134-4945-01	Lift catch assy			
7	1	9404-0027-01	.O-ring			
8	1	9650-0039-04	.Lock ring			
9	1	9595-0276-01	.Locating pin			
10	1	9997-0640-12	.Screw			
11	1	9747-0631-02	.Lock nut			
13	1	9897-0820-16	.Screw			
14	1	9747-0831-02	Lock nut			
15	1	1134-4860-01	Lift fork			
16	2	1134-0240-00	Shoulder screw			
17	1	1134-4938-01	Lift pedal			
18	2	9997-0625-16	Screw			
19	2	9739-0631-22	Nut			
20	1	4231-0013-00	Spring			

www.emc-motoculture.com




Section: PARK COMPACT SEAT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6101	6103					
6102	6104					
1	1	1134-5506-01	Seat			
2	1	1134-6444-01	Seat			
3	1	1134-5301-01	Seat plate			
4	2	1134-0240-00	Shoulder screw			
5	2	9747-0831-02	Lock nut			
6	1	1134-5454-01	Catch			
7	1	9675-0012-02	Locking washer			
10	4	9893-0616-16	Screw			
11	1	1134-5300-01	Rear plate			
12	1	1134-5296-04	Seat bracket-yellow			
13	1	1134-4256-01	Seat spring			
14	1	9924-1235-19	Screw			
15	1	9747-1231-02	Lock nut			
16	1	9997-0840-16	Screw			
17	1	1134-1565-06	Spacer			
18	1	1134-5302-01	Spring			
19	1	1134-5299-01	Push plate			
20	1	9699-0090-02	Flat washer			
21	1	9747-0831-02	Lock nut			
22	1	1134-3156-02	Switch (grey)			
26	2	9897-0880-12	Screw		L = 80 mm	
27	2	1134-1565-08	Spacer			
28	4	9897-0820-16	Screw		L = 20 mm	
29	6	9747-0831-02	Lock nut			




Section: PARK COMPACT 2WD FRAME

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		6102					
	6101	6103					
1	1	1	1134-5315-03	Frame-front			
2	1	1	1134-3963-02	.Clevis			
3	1	1	1134-0031-00	.Pivot shaft stop			
4	1	1	9595-0262-00	.Locating pin			
5	1	1	1134-2171-01	Spring			
6	2	2	9501-0500-00	Grease joint			
7	1	1	1134-6466-01	Frame-rear			
8	1	1	1134-5705-01	.Spacer			
9	2	2	9547-0001-00	.Bearing			
10	2	2	9501-0500-00	.Grease joint			
11	1	1	1134-5988-01	Centre shaft			
13	2	2	9699-0035-02	Flat washer			
14	2	2	9959-1025-16	Screw			
16	1	1	1134-5294-01	Floor plate			
17		1	1134-6372-04	Floor mat			
17	1		1134-5513-02	Floor mat			
18	2	2	9893-0616-16	Screw			
19		2	9403-0048-70	Plug			
20	2	2	9945-0816-16	Screw			
21	2	2	9959-0820-16	Screw			
22	2	2	9739-0831-22	Nut			
28	1	1	1134-4975-01	Rubber block			
29	1	1	9950-0570-12	Screw			
30	2	2	9739-0531-22	Nut			
31	1	1	1134-5337-02	Bumper-rear, grey			
32	2	2	1134-0240-00	Shoulder screw			
33	2	2	1134-4242-01	Spacer washer			
34	2	2	9665-0002-00	Bowed washer			
35	2	2	9747-0831-02	Lock nut			
36	2	2	9943-0516-16	Screw			
37	2	2	1134-5345-01	Attachment			
38	1	1	1134-5344-01	Battery shelf			
39	4	4	9945-0816-16	Screw			




Section: PARK COMPACT 2WD POWER TAKE-OFF

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101					
	6102					
	6103					
1	1	1134-5548-01	Spacer			
2	1	1134-5109-01	Tension wheel arm			
3	1	1134-1770-01	Tension roller			
4	1	1134-1888-04	Spacer			
5	1	1134-5111-01	Spring			
6	1	9699-0056-02	Flat washer			
7	1	9739-0831-22	Nut			
8	1	9997-0855-12	Screw			
10	1	1134-1769-03	Centre pulley assy			
11	1	1134-0051-09	.Spacer			
12	2	9549-0019-00	.Ball bearing			
13	1	1134-5112-01	Spring attachment			
14	2	9945-0816-16	Screw			
15	1	1134-5110-01	Hook			
16	2	9893-0616-16	Screw			
18	1	1134-2018-02	Tension arm			
19	1	1134-9027-02	Tension roller grey			
20	1	1134-9071-01	V-belt		= 9585-0129-01	
21	1	9997-1030-16	Screw			
22	1	9799-1031-02	Nut			
23	1	1134-4111-01	Brake arm			
24	1	1134-4164-03	Brake pad			
25	1	9897-0825-16	Screw			
26	1	9747-0831-02	Lock nut			
27	1	1134-4162-01	Brake rod			
28	1	9675-0008-02	Locking washer			
29	1	1134-4170-01	Nipple			
30	1	9699-0025-02	Washer			
31	1	9747-0631-02	Lock nut			
32	1	4231-0013-00	Spring			
33	1	1134-4281-01	Spring			
34	1	1134-1565-10	Spacer			
35	1	9997-0860-16	Screw			
36	1	9699-0056-02	Flat washer			
37	1	9739-0831-22	Nut			
38	1	1134-4163-01	Shoulder bolt			
39	1	9739-1031-22	Nut			
40	1	1134-3958-01	Belt guide			
41	2	9893-0616-16	Screw			
42	1	1134-0041-03	Collar			
43	1	9997-1070-12	Screw			
44	1	9739-1031-22	Nut			
45	1	1134-3654-01	Finger guard			
46	2	9959-0612-16	Screw			
47	2	9739-0631-22	Nut			
48	1	9699-0090-02	Flat washer			
49	2	9699-0035-02	Flat washer			




Section: PARK COMPACT 2WD STEERING

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101					
	6102					
	6103					
1	1	1134-6374-06	Chain		83 länk	
2	1	1134-9084-01	Steering cable assy		Sats vathö/kit L+R	
4	2	1134-2824-02	Chain lock			
5	2	1134-3817-01	Compression spring			
6	2	9699-0090-02	Flat washer			
7	2	9747-0831-02	Lock nut			
8	4	1134-2816-01	Sprocket			
9	4	1134-0041-02	Idler wheel bush			
10	4	9699-0035-02	Flat washer			
11	2	9997-1050-16	Screw			
12	2	9897-1040-12	Screw			
13	4	9739-1031-22	Nut			
14	2	1134-9025-01	Steering pulley-kit		Sats 2 st/kit of 2	
15	2	1134-0041-01	Bushing			
16	2	1134-0046-00	Wire clamp			
17	2	9997-1030-16	Screw			
18	2	9739-1031-22	Nut			
19	1	1134-5349-01	Steering console-yel.			
20	4	9897-0820-16	Screw			
21	4	9739-0831-22	Nut			
22	1	1134-1305-05	Steering column-lower			
23	2	1134-1901-01	Bearing			
24	2	9893-0616-16	Screw			
25	1	1134-2821-03	Steering rod			
26	1	1134-2837-01	Spacer			
27	1	1134-5496-01	Steering wheel			




Section: PARK COMPACT 2WD WHEELS

Pos.	Quantity	Spare part No		Description	Kit	Notes	New
	6101	6102	6103				
1	2	2	2	1134-0075-01	Front axle		
2	2	2	2	9595-0258-00	Locating pin		
3	2	2	2	1134-4844-05	Wheel hub assy		
3A	1	1	1	9501-0500-00	.Grease joint		
4	1	1	1	1134-9026-01	.Bearing bush kit	Sets 4 st/kit of 4	
5			2	1134-4558-01	Rim		
5	2	2		1134-5255-01	Rim		
6			2	9545-0116-00	Tyre	16 x 7.50 - 8	
6	2	2		9545-0126-01	Tyre	16 x 6.00 - 8	
7	2	2	2	9545-0500-00	Valve		
8	6	6	6	9731-1031-22	Nut		
10	8	8	8	1134-0341-01	Washer		
11	2	2	2	9599-0080-02	Cotter pin		
12	2	2	2	1134-4844-02	Wheel hub		
13	2	2		1134-5255-01	Rim		
13			2	1134-4558-01	Rim		
14			2	9545-0116-00	Tyre	16 x 7.50 - 8	
14	2	2		9545-0126-01	Tyre	16 x 6.00 - 8	
15	2	2	2	9545-0500-00	Valve		
16	6	6	6	9731-1031-22	Nut		
18	2	2	2	1134-4796-01	Hub cap		
19	2	2	2	9947-0540-19	Screw		
20	2	2	2	1134-2471-01	Key	L = 58 mm	
21	2	2	2	9699-0042-02	Flat washer		
22	2	2	2	9653-0001-04	Lock ring		
24	2	2	2	9598-0003-02	Spring pin		
25	2	2	2	1134-3710-01	Tool attachment		
26	2	2	2	9699-0042-02	Flat washer		
99				9545-0203-00	Inner tube	Reservdel/spare part	



Section: PARK COMPACT HST 2WD FOOT CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6102					
	6103					
1	1	1134-4247-01	Brake/clutch pedal			
2	1	1134-9024-01	.Bearing		Sats 1st/kit of 4	
3	1	1134-3584-03	Brake/clutch cable			
4A	1	1134-6467-01	Cable holder			
5	2	9959-0820-16	Screw			
6	2	9739-0831-22	Nut			
7	1	1134-3974-01	Spring			
8	1	1134-6353-01	Drive pedal			
9	2	1134-6313-01	Bearing			
10	2	1134-2700-01	Bracket			
11	2	9959-0820-16	Screw			
12	2	9739-0831-22	Nut			
13	1	9997-0870-16	Screw			
14	1	9959-0820-16	Screw			
15	3	9739-0831-22	Nut			
16	1	1134-2766-05	Speed control cable			
17	2	9570-0001-00	Elbow link			
18	2	9739-0531-22	Nut			
19	2	9747-0531-02	Nut			
20	1	1134-6317-01	Cable holder			
21	2	9959-0620-16	Screw			
22	2	9739-0631-22	Nut			
23	1	1134-3395-01	Attachment			
24	2	9959-0820-16	Screw			
25	2	9739-0831-22	Nut			
26	1	1134-2021-01	Flange			
48	1	1134-5353-01	Brake rod			
49	1	1134-2786-01	Elastic knob			
50	1	1131-1497-01	Spring			
51	1	1134-4002-01	Brake rod attachment			
52	3	9838-9516-12	Screw			



Section: PARK COMPACT HST 2WD TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6102					
	6103					
1	1	1134-4000-02	Tension arm			
2	1	1134-3459-01	Tension roller			
3	1	9924-1035-16	Screw			
4	1	9799-1031-02	Nut			
5	1	1134-9058-01	V-belt		= 9585-0091-01	
6	1	9997-0625-16	Screw			
7	1	9739-0631-22	Nut			
7A	1	9747-0631-02	Lock nut			
8	1	1134-3377-02	Control rod			
9	1	4231-0013-00	Spring			
10	1	1134-4171-01	Pivot pin			
11	1	1134-4183-01	Compression spring			
12	2	1134-3456-01	Bushing			
13	1	9747-0631-02	Lock nut			
14	1	1134-1565-08	Spacer			
15	1	9997-0870-16	Screw			
16	1	9699-0056-02	Flat washer			
17	1	9747-0831-02	Lock nut			
18	1	1134-6414-01	Spring			
19	1	9699-0060-02	Flat washer			
20	1	1134-4848-01	Transaxle assy		Kanzaki K46G	
21	4	9960-0860-12	Screw			
22	4	9747-0831-02	Lock nut			
23	1	1134-3913-01	Strut			
24	1	9959-0825-16	Screw			
25	1	9997-0845-12	Screw			
26	1	9699-0090-02	Flat washer			
27	2	9747-0831-02	Lock nut			
28	1	9747-0631-02	Lock nut			
29	1	1134-2765-02	Oil tank			
30	1	1134-2777-02	Filler cap			
31	1	1134-2734-01	Vent plug			
32	1	1134-6778-01	Retainer strap			
33	2	9852-8013-16	Screw			
34	2	9699-0099-02	Washer			
35	2	9578-0023-04	Hose clamp			
36	1	1134-2779-07	Tube		L = 140 mm	
40	1	1134-4015-01	Pull rod			
41	1	1134-4014-01	Plastic button			
42	1	1134-4713-01	Bracket			
43	1	1134-2790-01	Rubber grommet			
44	1	9959-0820-16	Screw			
45	1	9739-0831-22	Nut			
46	1	9675-0009-02	Starlock			
51	1	1134-3289-02	Belt guide			
52	1	9959-0820-16	Screw			
53	1	9699-0056-02	Flat washer			
54	1	9739-0831-22	Nut			