






Section: PARK COMPACT ACCESSORY BAGS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6101 6103						
0	1	1134-4249-05	Assembly parts		Inkl. pos 1 - 15	
0	1	1134-4249-06	Assembly parts		Inkl. pos 1 - 17	
2	1	1134-4541-01	.Spark plug wrench		5/8" (16 mm)/21 mm	
3	1	1111-2113-01	.Rod			
4	1	9595-0262-00	.Locating pin			
5A	1	9699-0103-02	.Flat washer		0.5 mm	
5B	1	9699-0114-02	.Flat washer		1.0 mm	
6	2	1134-4185-01	.Flange washer			
7	2	9959-0820-16	.Screw			
8	2	1134-4481-01	.Wing nut			
9	2	9699-0062-02	.Flat washer			
10	2	1134-4734-01	.Ignition key			
12	2	9997-0820-16	.Screw			
13	1	1134-5512-01	.Towing plate			
14	2	9959-0820-16	.Screw			
15	2	9739-0831-22	.Nut			
16	1	1134-5482-01	.Gear shift lever			
17	1	1134-2551-01	.Knob			
30	1	1134-3771-72	Folder w.manuals			
31	1	8211-0209-11	.Safety regulations			
31	1	8211-1023-01	.Owner's manual			
31	1	8211-1024-01	.Assembly instructi			
31	1	8211-0277-04	.Service book			
31	1	8211-2002-03	.Warranty card			



Section: PARK COMPACT BODY WORK


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6101 6103						
1	1	1	1134-5263-02	Engine hood-yellow		
2	7	7	9838-9530-12	Screw		
3	1	1	1134-9028-01	Rubber strap kit	Sats 3 st/kit of 3	
4	1	1	9632-0516-00	Pop rivet		
5	1	1	9699-0120-02	Washer		
6	1	1	1134-5264-01	Engine cover-grey		
7	1	1	1134-5308-01	Mud guard LH-grey		
8	1	1	1134-5308-02	Mud guard RH-grey		
9	4	4	9893-0616-16	Screw		
10	4	4	1134-4176-01	Clips		
11	2	2	1134-0225-00	Support plate		
12	6	6	9945-0816-16	Screw		
13	4	4	9699-0056-02	Flat washer		
14	1	1	1134-5306-01	Bumper, front-LH		
15	1	1	1134-5306-02	Bumper, front-RH		
16	4	4	9893-0616-16	Screw		
17	2	2	1134-4176-01	Clips		
18	1	1	1134-5305-01	Front plate-lower		
19	2	2	9893-0616-16	Screw		
20	1		1134-5320-01	Front-upper		
20		1	1134-5320-02	Front-upper		
21	2	2	9946-0525-16	Screw		
22	1	1	1134-5265-01	Hood support		
23	4	4	9893-0616-16	Screw		
24	1	1	1134-3970-05	Moulding-LH, grey		
25	1	1	1134-3970-02	Moulding-RH, grey		
26	2	2	9893-0616-16	Screw		
99		1	1134-5592-02	Label kit		
99	1		1134-5592-01	Label kit		



Section: PARK COMPACT EL. EQUIPMENT


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101 6103					
1	1	1	1134-4804-01	Battery		
2	1		1134-5323-01	Harness		
2		1	1134-5324-01	Harness		
2A	1	1	1134-3496-06	.Fuse	20A	
3	1	1	1134-5343-01	Battery bracket		
4	3	3	9852-8013-16	Screw		
5	2	2	9699-0060-02	Flat washer		
6	1	1	1134-2962-01	Solenoid assy		
7	2	2	9852-8013-16	Screw		
8	2	2	9794-5131-02	.Nut		
9	1	1	1134-4093-01	Ignition switch		
10	1	1	1134-4749-01	Nut		
11	1	1	1134-5245-01	Battery strap		
12	1	1	1134-2167-01	Cable		
13	1	1	1134-0234-02	Battery cable (+)		
14	1	1	1134-2310-01	Guard cap		
15	1	1	9795-3531-02	Nut		
16	15	15	9579-0003-00	Cable holder		
20	1		1134-2871-03	Relay		
21	1		9852-8013-16	Screw		
25		1	1134-3399-02	Switch		
26		2	9997-0520-16	Screw		
27		2	9747-0531-02	Nut		
28		1	9400-0231-00	Splicer		

www.emc-motoculture.com




Section: PARK COMPACT ENGINE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6101 6103						
1A	2	4	9997-0840-16	Screw	L = 40 mm	
1B	1		9997-0845-12	Screw	L = 45 mm	
1C	1		9997-0875-12	Screw	L = 75 mm	
2	4	4	9739-0831-22	Nut		
3A	1		1134-5370-01	Muffler		
3B	1		1134-5369-01	Muffler		
4	1	1	1134-0433-00	Muffler gasket		
5	2	2	1134-4930-01	Screw		
6	1	1	9959-0820-16	Screw		
7	1	1	9739-0831-22	Nut		
8	1	1	1134-5390-01	Tow bar bracket		
9	4	4	9959-0820-16	Screw		
10	4	4	9739-0831-22	Nut		
11	1	1	1134-4978-01	Oil drain pipe assy		
12	1	1	1134-4976-01	.Plug		
13	1	1	1134-4977-01	.Copper washer		
14	1	1	1134-4999-01	Engine pulley		
15	1	1	1134-5000-01	Engine pulley		
16	1	1	9600-0251-01	Key	L = 2 1/2"	
17	1	1	1134-5017-01	Washer		
18	1	1	9987-5332-16	Screw		
19	1	1	1134-4757-06	Fuel tank assy	Inkl. pos 20 - 24	
20	1	1	1134-2877-03	.Fuel tank cap		
21	1	1	1134-3224-01	.Fuel shut-off valv		
22	1	1	1134-3225-01	.Grommet		
23	1	1	1134-2975-01	.Fuel hose	L = 520 mm	
24	1	1	9578-0023-02	.Hose clamp		
25	1	1	1134-5340-01	Fuel tank bracket		
26	2	2	9959-0820-16	Screw		
27	2	2	9739-0831-22	Nut		
28	2	2	1134-5346-01	Fuel tank loop		
29	2	2	9747-0631-02	Lock nut		
30	1	1	9579-0003-00	Cable holder		
40	1	1	9578-0023-02	Hose clamp		




Section: PARK COMPACT FRAME

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6101 6103						
1	1	1	1134-5315-02	Frame-front		
2	1	1	1134-3963-02	.Clevis		
3	1	1	1134-0031-00	.Pivot shaft stop		
4	1	1	9595-0262-00	.Locating pin		
5	1	1	1134-2171-01	Spring		
6	2	2	9501-0500-00	Grease joint		
8	1	1	1134-5313-01	Frame-rear		
9	2	2	9547-0001-00	.Bearing		
10	2	2	9501-0500-00	Grease joint		
11	1	1	1134-3968-02	Centre shaft (188 m		
13	2	2	9699-0035-02	Flat washer		
14	2	2	9959-1020-16	Screw		
16	1	1	1134-5294-01	Floor plate		
17		1	1134-5514-01	Floor mat		
17	1		1134-5513-01	Floor mat		
18	2	2	9893-0616-16	Screw		
20	2	2	9945-0816-16	Screw		
21	2	2	9959-0820-16	Screw		
22	2	2	9739-0831-22	Nut		
28	1	1	1134-4975-01	Rubber block		
29	1	1	9950-0570-12	Screw		
30	2	2	9739-0531-22	Nut		
31	1	1	1134-5337-01	Bumper-rear		
32	2	2	1134-0240-00	Shoulder screw		
33	2	2	1134-4242-01	Spacer washer		
34	2	2	9665-0002-00	Bowed washer		
35	2	2	9747-0831-02	Lock nut		
36	2	2	9943-0516-16	Screw		
37	2	2	1134-5345-01	Attachment		
38	1	1	1134-5344-01	Battery shelf		
39	4	4	9945-0816-16	Screw		



Section: PARK COMPACT HAND CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6101 6103						
1	1	1	1134-5363-01	Control lever		
2	1	1	1134-2551-01	Knob		
3	1	1	1134-3790-02	Bearing		
4	1		9699-0090-02	Flat washer	8.4 x 18 x 1.5	
4		1	9699-0056-02	Flat washer	8.4 x 24 x 2.0	
5	1	1	4231-0013-00	Spring		
6	1	1	1134-5368-01	Dashboard		
7	1	1	9400-0312-01	Micro switch		
8	4	4	9946-0525-16	Screw		
9	1	1	1134-3573-05	Control cable		
20	1	1	1134-5465-01	Throttle lever		
21	1	1	1134-4078-01	Knob		
22	1	1	1134-5464-01	Bracket		
23	1	1	1134-0240-00	Shoulder screw		
24	2	2	1134-4242-01	Spacer washer		
25	1	1	9694-0001-00	Washer		
26	1	1	9747-0831-02	Lock nut		
27	1	1	1134-4197-02	Throttle cable		
28	1	1	9500-9991-00	Cable clamp		
29	1	1	9943-0516-16	Screw		
40	1		1134-5459-01	Gear shift arm		
41	1		1134-0240-00	Shoulder screw		
42	1		9696-0013-01	Bowed washer		
43	1		9739-0831-22	Nut		
44	1		1134-2766-07	Control cable		
45	1		1134-5518-01	Angle bracket		
46	2		9897-0616-16	Carriage bolt		
47	2		9739-0631-22	Nut		
50	1		9570-0001-00	Elbow link		
51	2		9739-0531-22	Nut		




Section: PARK COMPACT PEDAL LIFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

6101 6103


1A	1		1134-5462-01	Bracket		
1B		1	1134-4117-01	Bracket		
2	2	2	1134-2684-01	Bearing		
3	1	1	1134-4945-01	Lift catch assy		
7	1	1	9404-0027-01	.O-ring		
8	1	1	9650-0039-04	.Lock ring		
9	1	1	9595-0276-01	.Locating pin		
10	1	1	9997-0640-12	.Screw		
11	1	1	9747-0631-02	.Lock nut		
13	1	1	9897-0820-16	.Screw		
14	1	1	9747-0831-02	Lock nut		
15	1	1	1134-4860-01	Lift fork		
16	2	2	1134-0240-00	Shoulder screw		
17	1	1	1134-4938-01	Lift pedal		
18	2	2	9997-0625-16	Screw		
19	2	2	9739-0631-22	Nut		
20	1	1	4231-0013-00	Spring		

www.emc-motoculture.com




Section: PARK COMPACT POWER TAKE-OFF

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101					
	6103					
1	1	1134-5548-01	Spacer			
2	1	1134-5109-01	Tension wheel arm			
3	1	1134-1770-01	Tension roller			
4	1	1134-1888-04	Spacer			
5	1	1134-5111-01	Spring			
6	1	9699-0056-02	Flat washer			
7	1	9739-0831-22	Nut			
8	1	9997-0855-12	Screw			
10	1	1134-1769-02	Belt pulley assy			
11	1	1134-0051-09	.Spacer			
12	2	9549-0019-00	.Ball bearing			
13	1	1134-5112-01	Spring attachment			
14	2	9945-0816-16	Screw			
15	1	1134-5110-01	Hook			
16	2	9893-0616-16	Screw			
18	1	1134-2018-02	Tension arm			
19	1	1134-9027-01	Tension roller			
20	1	1134-9071-01	V-belt		= 9585-0129-01	
21	1	9997-1030-16	Screw			
22	1	9799-1031-02	Nut			
23	1	1134-4111-01	Brake arm			
24	1	1134-4164-01	Brake pad			
25	1	9897-0825-16	Screw			
26	1	9747-0831-02	Lock nut			
27	1	1134-4162-01	Brake rod			
28	1	9675-0008-02	Locking washer			
29	1	1134-4170-01	Nipple			
30	1	9699-0025-02	Washer			
31	1	9747-0631-02	Lock nut			
32	1	4231-0013-00	Spring			
33	1	1134-4231-01	Spring			
34	1	1134-1565-10	Spacer			
35	1	9997-0865-12	Screw			
36	1	9699-0056-02	Flat washer			
37	1	9739-0831-22	Nut			
38	1	1134-4163-01	Shoulder bolt			
39	1	9747-1031-02	Lock nut			
40	1	1134-3958-01	Belt guide			
41	2	9893-0616-16	Screw			
42	1	1134-0041-03	Collar			
43	1	9997-1070-12	Screw			
44	1	9739-1031-22	Nut			
45	1	1134-3654-01	Finger guard			
46	2	9959-0612-16	Screw			
47	2	9739-0631-22	Nut			
48	1	9699-0090-02	Flat washer			
49	2	9699-0035-02	Flat washer			
50	1	9699-0035-02	Flat washer			




Section: PARK COMPACT SEAT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101					
	6103					
1	1	1134-5506-01	Seat			
3	1	1134-5301-01	Seat plate			
4	2	1134-0240-00	Shoulder screw			
5	2	9747-0831-02	Lock nut			
6	1	1134-5454-01	Catch			
7	1	9675-0012-02	Locking washer			
10	4	9893-0616-16	Screw			
11	1	1134-5300-01	Rear plate			
12	1	1134-5296-01	Seat bracket-yellow			
13	1	1134-4256-01	Seat spring			
14	1	9924-1235-19	Screw			
15	1	9747-1231-02	Lock nut			
16	1	9997-0840-16	Screw			
17	1	1134-1565-06	Spacer			
18	1	1134-5302-01	Spring			
19	1	1134-5299-01	Push plate			
20	1	9699-0090-02	Flat washer			
21	1	9747-0831-02	Lock nut			
22	1	1134-3156-02	Switch			
26	2	9897-0880-12	Screw		L = 80 mm	
27	2	1134-1565-08	Spacer			
28	4	9897-0820-16	Screw		L = 20 mm	
29	6	9747-0831-02	Lock nut			




Section: PARK COMPACT STEERING

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101					
	6103					
1	1	1134-2820-06	Chain		83 länk	
2	1	1134-9084-01	Steering cable assy		Sats vä+hö/kit l+r	
4	2	1134-2824-01	Chain lock			
5	2	1134-3817-01	Compression spring			
6	2	9699-0090-02	Flat washer			
7	2	9747-0831-02	Lock nut			
8	4	1134-2816-01	Sprocket			
9	4	1134-0041-02	Idler wheel bush			
10	4	9699-0035-02	Flat washer			
11	2	9997-1050-16	Screw			
12	2	9897-1040-12	Screw			
13	4	9739-1031-22	Nut			
14	2	1134-9025-01	Steering pulley-kit		Sats 2 st/kit of 2	
15	2	1134-0041-01	Bushing			
16	2	1134-3022-01	Cable holder			
17	2	9997-1030-16	Screw			
18	2	9739-1031-22	Nut			
19	1	1134-5349-01	Steering console-ye			
20	4	9897-0820-16	Screw			
21	4	9739-0831-22	Nut			
22	1	1134-1305-05	Steering column-low			
23	2	1134-1901-01	Bearing			
24	2	9893-0616-16	Screw			
25	1	1134-2821-03	Steering rod			
26	1	1134-2837-01	Spacer			
27	1	1134-5496-01	Steering wheel			




Section: PARK COMPACT WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6101					
	6103					
1	2	1134-0075-01	Front axle			
2	2	9595-0258-00	Locating pin			
3	2	1134-4844-05	Wheel hub assy			
3A	1	9501-0500-00	.Grease joint			
4	1	1134-9026-01	.Bearing bush kit		Sats 4 st/kit of 4	
5	2	1134-5255-01	Rim			
6	2	9545-0126-01	Tyre		16 x 6.00 - 8	
7	2	9545-0500-00	Vallve			
8	6	9747-1031-02	Lock nut			
9	6	9699-0035-02	Flat washer			
10	8	1134-0341-01	Washer			
11	2	9599-0080-02	Cotter pin			
12	2	1134-4844-02	Wheel hub			
13	2	1134-5255-01	Rim			
14	2	9545-0126-01	Tyre		16 x 6.00 - 8	
15	2	9545-0500-00	Vallve			
16	6	9747-1031-02	Lock nut			
17	6	9699-0035-02	Flat washer			
18	2	1134-4796-01	Hub cap			
19	2	9947-0540-19	Screw			
20	2	1134-2471-01	Key			
21	2	9699-0042-02	Flat washer			
22	2	9653-0001-04	Lock ring			
25	2	9598-0003-02	Spring pin			
26	2	9699-0042-02	Flat washer			
99		9545-0203-00	Inner tube		Reservdel/spare par	



Section: PARK COMPACT HST FOOT CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6103						
1	1	1134-4247-01	Brake/clutch pedal			
2	1	1134-9024-01	.Bearing		Sats 4 st/kit of 4	
3	1	1134-3584-03	Brake/clutch cable			
4A	1	1134-3906-01	Cable holder			
5	2	9959-0816-16	Screw			
6	2	9739-0831-22	Nut			
7	1	1134-3974-01	Spring			
8	1	1134-4008-01	Drive pedal			
9	2	1134-2780-01	Bearing			
10	2	1134-2700-01	Bracket			
11	2	9959-0820-16	Screw			
12	2	9739-0831-22	Nut			
13	1	9997-0870-16	Screw			
14	1	9959-0816-16	Screw			
15	3	9739-0831-22	Nut			
16	1	1134-2766-05	Speed control cable			
17	2	9570-0001-00	Elbow link			
18	3	9739-0531-22	Nut			
19	1	1134-0266-00	Attaching clamp			
20	1	1134-0267-00	Clamp plate			
21	2	9997-0520-16	Screw			
22	2	9739-0531-22	Nut			
23	1	1134-3395-01	Attachment			
24	2	9959-0820-16	Screw			
25	2	9739-0831-22	Nut			
26	1	1134-2021-01	Clamp			
27	1	1134-4013-01	Spacer			
28	1	9959-0820-16	Screw			
48	1	1134-5353-01	Brake rod			
49	1	1134-2786-01	Plastic knob			
50	1	1131-1497-01	Spring			
51	1	1134-4002-01	Brake rod attachmen			
52	3	9838-9516-12	Screw			



Section: PARK COMPACT HST TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6103						
1	1	1134-4000-02	Tension arm			
2	1	1134-3459-01	Tension roller			
3	1	9924-1035-16	Screw			
4	1	9799-1031-02	Nut			
5	1	1134-9058-01	V-belt		= 9585-0091-01	
6	1	9997-0625-16	Screw			
7	1	9739-0631-22	Nut			
7A	1	9747-0631-02	Lock nut			
8	1	1134-3377-02	Control rod			
10	1	1134-4171-01	Pivot pin			
11	1	1134-4183-01	Compression spring			
12	2	1134-3456-01	Bushing			
13	1	9747-0631-02	Lock nut			
14	1	1134-1565-08	Spacer			
15	1	9997-0870-16	Screw			
16	1	9699-0056-02	Flat washer			
17	1	9747-0831-02	Lock nut			
18	1	1134-1949-01	Spring			
19	1	9699-0060-02	Flat washer			
20	1	1134-4848-01	Transaxle		Kanzaki K46G	
21	4	9997-0865-12	Screw			
22	4	9747-0831-02	Lock nut			
23	1	1134-3913-01	Strut			
24	1	9959-0825-16	Screw			
25	1	9997-0845-12	Screw			
26	1	9699-0028-02	Flat washer			
27	2	9747-0831-02	Lock nut			
28	1	9747-0631-02	Lock nut			
29	1	1134-2765-02	Oil tank			
30	1	1134-2777-02	Filler cap			
31	1	1134-3734-01	Vent plug			
32	1	1134-2778-01	Retainer strap			
33	2	9852-8013-16	Screw			
34	2	9699-0099-02	Washer			
35	2	9578-0023-04	Hose clamp			
36	1	1134-2779-07	Tube		L = 140 mm	
40	1	1134-4015-01	Pull rod			
41	1	1134-4014-01	Plastic button			
42	1	1134-4713-01	Bracket			
43	1	1134-2790-01	Rubber grommet			
44	1	9959-0816-16	Screw			
45	1	9739-0831-22	Nut			
46	1	9675-0009-02	Starlock			
51	1	1134-3289-02	Belt guide			
52	1	9959-0820-16	Screw			
53	1	9699-0056-02	Flat washer			
54	1	9739-0831-22	Nut			