







Section: PARK 2WD ASSEMBLY PARTS


Pos.	Quantity	Spare part No				Description	Kit	Notes	New
		6184							
	6141	6189			6142				
	6182	6193			6144				
	6183	6195	6180	6179					
4	1	1	1	1	9595-0262-00	Locating pin			
5A	1	1	1	1	9699-0103-02	Flat washer		0.5 mm	
5B	1	1	1	1	9699-0114-02	Flat washer		1.0 mm	
10	2	2		2	1134-4734-01	Ignition key			
11			2		1134-4909-01	Ignition key			
13	1	1	1	1	1134-5512-01	Towing plate			
14	2	2	2	2	9959-0820-16	Screw			
15	2	2	2	2	9739-0831-22	Nut			
17	1	1	1	1	1134-6113-02	Battery screws			
18	2	2	2	2	9898-1035-16	Screw			
19	2	2	2	2	9739-1031-22	Nut			
31			1		8211-0008-80	Owner's manual			
31	1				8211-0003-80	Owner's manual			
31			1		8211-0007-80	Owner's manual			
31				1	8211-0071-80	Owner's manual		6142-64	
31		1			8211-0014-80	Owner's manual			
31		1			8211-0015-80	Owner's manual			
31	1	1	1	1	8211-0604-80	Assy instructions			
31	1	1	1	1	8211-0701-80	Safety regulations			
31	1	1		1	8211-0901-80	Service book			
31			1		8211-0902-80	Service book			
31	1	1	1	1	8211-0950-80	Warranty card			
31	1				8211-0020-80	Owner's manual		6141-54	
31	1				8211-0021-80	Owner's manual		6141-54	
31			1		8211-0033-80	Owner's manual		6179-04	
31			1		8211-0072-80	Owner's manual		6144-74	
31	1				8211-0004-80	Owner's manual			



Section: PARK 2WD BODY WORK-FRONT



Pos.	Quantity				Spare part No	Description	Kit	Notes	New
					6142				
	6141				6179				
	6182	6193			6183				
	6184	6195	6189	6180					
1	1	1	1	1	1134-3943-01	Mud guard-LH, yell.			
2	1	1	1	1	1134-3943-02	Mud guard-RH, yell.			
3	2	2	2	2	9893-0616-16	Screw			
4	4	4	4	4	1134-4176-01	Clips			
5	2	2	2	2	9699-0060-02	Flat washer			
6	2	2	2	2	9747-0631-02	Lock nut			
7	2	2	2	2	1134-0225-00	Support plate			
8	6	6	6	6	9945-0816-16	Screw			
9	4	4	4	4	9699-0056-02	Flat washer			
10	1	1	1	1	1134-4220-02	Bumper-grey			
11	6	6	6	6	9893-0616-16	Screw			
12	2	2	2	2	1134-4176-01	Clips			
13	1	1	1	1	1134-4216-05	Front plate-yellow			
14	1	1	1	1	1134-3984-03	Front plate upper-y			
15	2	2	2	2	9946-0525-16	Screw			
16	2	2	2	2	9840-8019-16	Screw			
17	1	1	1	1	1134-4360-01	Cover-inner			
18	3	3	3	3	9946-0525-16	Screw			
19	1	1	1	1	1134-3979-01	Cover-outer			
20	2	2	2	2	9840-8019-16	Screw			
21	2	2	2	2	9950-0570-12	Screw			
22	2	2	2	2	9747-0531-02	Nut			
23	1	1	1	1	1134-6461-01	Rear plate			
24	4	4	4	4	9893-0616-16	Screw			
25	2	2	2	2	9897-0616-16	Carriage bolt			
27	1	1	1	1	1134-3970-05	Moulding-LH, grey			
29	1	1	1	1	1134-3970-02	Moulding-RH, grey			
30	4	4	4	4	9893-0616-16	Screw			

www.emc-motoculture.com



Section: PARK 2WD BODY WORK-REAR

Pos.	Quantity				Spare part No	Description	Kit	Notes	New
					6142				
	6141				6179				
	6182	6193			6183	6144			
	6184	6195			6189	6180			
1	1	1	1	1	1134-6025-01	Engine hood			
2	4	4	4	4	9893-0616-16	Screw			
3	1	1	1	1	1134-9028-01	Rubber strap kit		Sats 3 st/kit of 3	
4	1	1	1	1	9632-0513-00	Pop rivet			
5	1	1	1	1	9699-0120-02	Washer			
6	1	1	1	1	1134-6026-01	Engine cover			
7	1	1	1	1	1134-6027-01	Bumper end-LH			
8	1	1	1	1	1134-6027-02	Bumper end-RH			
9	4	4	4	4	1134-6310-01	Clips			
15				1	1134-4012-03	Support-RH			
16				1	1134-4012-04	Support-LH			
17				1	9959-0820-16	Screw			
18				1	9739-0831-22	Nut			
19	1	1	1	1	1134-6241-01	Hood support			
20	3	3	3	3	9893-0616-16	Screw			
21				1	1134-4800-01	Inner mud guard-RH			
22				4	9699-0060-02	Flat washer			
23				4	9893-0616-16	Screw			
24				1	1134-4801-01	Inner mud guard-LH			
99	1				1134-6443-05	Decal kit		Unlimited	
99				1	1134-4593-08	Decal kit		Diesel	
99	1				1134-6443-01	Decal kit		Comfort	
99				1	1134-6443-02	Decal kit		Royal	
99	1				1134-6443-03	Decal kit		President	
99				1	1134-6443-04	Decal kit		Excellent	







Section: PARK 2WD COMFORT-ROYAL-DIESEL EXCELLENT STEERING

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6180					
	6182					
	6183	6189				
1	1	1	1134-6374-10	Chain	129 länk	
2	2	2	1134-6374-09	Chain	35 länk	
3	1	1	1134-6374-02	Chain	41 länk	
4	1	1	1134-6374-05	Chain	47 länk	
5A	1	1	1134-3550-01	End nipple	L = 110 mm	
5B	1	1	1134-3550-02	End nipple	L = 90 mm	
6	4	4	1134-3565-01	Connection nipple		
7	12	12	1134-2824-02	Chain lock		
8	2	2	1134-5652-01	Attachment		
9	4	4	1134-5651-01	Bracket		
10	2	2	1134-2816-01	Sprocket		
11	2	2	1134-0041-02	Idler wheel bush		
12	2	2	1134-4817-01	Pin		
13	2	2	9699-0035-02	Flat washer		
14	2	2	9599-0054-02	Cotter pin		
15A	1	1	1134-3817-01	Compression spring	L = 58 mm	
15B	1	1	1134-3817-02	Compression spring	L = 33 mm	
16	2	2	9699-0090-02	Flat washer		
17	2	2	9747-0831-02	Lock nut		
18	4	4	1134-2816-01	Sprocket		
19	4	4	1134-5653-01	Spacer		
20	2	2	9699-0035-02	Flat washer		
21	2	2	9997-1060-12	Screw		
22	2	2	9739-1031-22	Nut		
23	2	2	9897-1060-12	Screw		
24	2	2	9731-1031-22	Nut		
25	3	3	1134-3547-01	Sprocket		
26	2	2	1134-0041-01	Bushing		
27	2	2	1134-0046-00	Wire clamp		
28	2	2	9997-1040-16	Screw		
29	2	2	9699-0035-02	Flat washer		
30	2	2	9739-1031-22	Nut		
31	1	1	1134-4120-04	Steering console		
32	4	4	9897-0820-16	Screw		
33	4	4	9739-0831-22	Nut		
34	1	1	1134-1305-03	Steering column-low		
35	2	2	1134-1901-01	Bearing		
36	1	1	1134-2821-04	Steering rod		
41	2	2	9893-0616-16	Screw		
42	1	1	1134-2837-03	Spacer		
52		1	1134-5173-01	Steering wheel		
52	1		1134-5173-02	Steering wheel assy		
53	1		1134-3769-01	..Steering wheel but		
54	1		1134-3752-01	..Knob holder		
55	1		9997-0870-16	..Screw		
56	1		1134-1565-06	..Spacer		
57	3		9699-0090-02	..Flat washer		
58	1		9747-0831-02	..Lock nut		
59	1		9403-0043-70	..Plug		
60	1		9403-0113-00	..Nut cap		
63	1	1	1134-5216-01	Steering tube-inner		
64	1	1	1134-5177-01	..Slide		
65	1	1	9710-0631-12	..Square nut		
66	1	1	1134-4481-02	Wing nut		
67	1	1	9997-0630-12	Screw		

Section: PARK 2WD COMFORT-ROYAL-DIESEL RANGER-EXCELLENT HAND CONTROL

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6179	6182					
6183	6193	6180	6189			
1	1	1	1	1	1134-4156-01 Panel bracket-inner	
2	2	2	2	2	9897-0820-16 Screw	
3	2	2	2	2	9739-0831-22 Nut	
4	1	1	1	1	9695-0011-00 Washer	
5	1	1	1	1	1134-4065-01 Control shaft	
6	1	1	1	1	1134-4079-01 Spring	
7	1	1	1	1	1134-4080-03 Control sleeve	
8	2	2	2	2	9959-0820-16 Screw	
9	1	1	1	1	1134-4077-01 Throttle control	
10	1	1	1	1	1134-4078-01 Knob	
11	1	1	1	1	1134-0240-00 Shoulder screw	
12	2	2	2	2	1134-4242-01 Spacer washer	
13	1	1	1	1	9694-0001-00 Washer	
14	1	1	1	1	9747-0831-02 Lock nut	
15	1			1	1134-4195-01 Throttle cable	L1 = 1413 mm
15		1			1134-4197-01 Throttle cable	L1 = 925 mm
15			1		1134-4923-01 Throttle cable	L1 = 880 mm
16	1	1	1	1	9500-9991-00 Cable clamp	
17	1	1	1	1	9943-0516-16 Screw	
18	1	1	1	1	1134-4072-01 Control lever	
19	1	1	1	1	1134-2551-01 Knob	
20	1	1	1	1	1134-3573-03 PTO cable	
21	1	1	1	1	1134-5358-01 Switch bracket	
22	2	2	2	2	9852-8013-16 Screw	
23	1	1	1	1	9400-0285-01 Switch	
24			2		9847-7732-16 Screw	L = 32 mm
24	2	2		2	9840-7716-16 Screw	L = 16 mm
25	1	1	1	1	1134-6328-01 Panel bracket-front	
26	2	2	2	2	9893-0616-16 Screw	
27	1	1	1	1	1134-6327-01 Front plate	
28	4	4	4	4	9893-0616-16 Screw	
32	1		1	1	1134-6096-02 Dashboard	
32		1			1134-6096-05 Dashboard	
33	4	4	4	4	9946-0525-16 Screw	
34	1	1	1	1	1134-4154-01 Cover	
35	5	5	5	5	1134-4129-01 Cover	
36	1	1		1	1134-4093-01 Ignition switch	
36			1		1134-4908-01 Ignition switch	
39	1	1		1	1134-4749-01 Nut	
40	1				1134-2872-03 Choke control	
40				1	1134-2872-02 Choke control	
40A	1			1	1134-4338-01 .Control knob	
41	1		1	1	9699-0090-02 Flat washer	
42	1	1	1	1	9400-0282-01 Switch w.diode	
44	1	1	1	1	1134-6097-01 Hour meter	
45		1			1134-4100-01 Plug	
46			1		9400-0296-01 Switch	
47			1		1134-4697-02 Switch	
49	1	1	1	1	9400-0280-03 Cover-height adjust	
99	1	1	1	1	9400-0290-01 Tool for cover	Tillbehör/Accessory




Section: PARK 2WD EL. EQUIPMENT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6141					
6144	6142	6182				
6179	6184	6189				
6183	6195	6193	6180			
1	1	1	1	1	1134-5751-01	Battery
2	1	1	1	1	1134-5994-01	Battery loop
3	1	1	1	1	1134-5995-01	Battery loop
4	1	1	1	1	1134-4481-02	Wing nut
5	1	1	1	1	9747-0631-02	Lock nut
6	1	1	1	1	1134-2962-01	Solenoid assy
7	2	2	2	2	9794-5131-02	.Nut
8	2	2	2	2	9852-8013-16	Screw
9	2	2	2	2	9699-0060-02	Flat washer
10	1	1	1	1	1134-4970-02	Cable-red
11	1	1	1	1	1134-3491-01	Fuse holder
12	1	1	1	1	1134-3496-01	Fuse
12	1	1	1	1	1134-3496-06	Fuse
12	1	1	1	1	1134-3496-07	Fuse
13	1	1	1	1	1134-3631-01	Cover-fuse holder
14	1	1	1	1	1134-3399-02	Switch
15	2	2	2	2	9943-0516-16	Screw
16	1	1	1	1	1134-4172-01	Headlamp assy
16A	1	1	1	1	9400-0293-01	.Bulb
17	2	2	2	2	9849-7819-16	Screw
18	2	2	2	2	1134-4177-01	Clips
19B	1	1	1	1	1134-6291-01	Female terminal
22A	1	1	1	1	1134-0234-02	Battery cable (+)
22B	1	1	1	1	1134-6067-01	Cable (+)
23	1	1	1	1	1134-2310-01	Guard cap
24	7	7	7	7	9579-0003-00	Cable holder
27	2	2	2	2	9849-8006-16	Screw
37	1	1	1	1	9959-0612-16	Screw
38	1	1	1	1	9739-0631-22	Nut
39	1	1	1	1	1134-6454-01	Ground plate
40	1	1	1	1	1134-6441-01	Harness
40	1	1	1	1	1134-6469-01	Harness
40	1	1	1	1	1134-6034-01	Cable harness

10A
20A
30ANot on 13-6144-74
12V - 21W



Not on 13-6144-74

Honda
Diesel




Section: PARK 2WD EXCELLENT-UNLIMITED ENGINE (Briggs & Stratton)

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6189 6142						
1	1	1134-6116-02	Air duct			
2	4	9955-3725-16	Screw			
3A	1	1134-6339-01	Exhaust pipe			
3B	1	1134-6422-01	Exhaust pipe			
4	1	9578-0011-01	Clamp			
5	1	1134-6024-01	Muffler			
6	1	9959-0820-16	Screw			
7	1	9739-0831-22	Nut			
8	1	1134-5827-01	Oil drain assy		Inkl. pos 9 - 12	
8	1	1134-5827-04	Oil drain assy		Inkl. pos 9 - 12	
9	1	1134-5825-01	.Nipple			
10	1	9578-0023-04	.Hose clamp			
11	1	1134-3499-02	.Hose clamp			
12	1	1134-5826-01	.Plug			
13	1	1134-6137-01	Engine pulley			
14	1	1134-6419-01	Engine pulley			
15	1	9600-0251-01	Key			
16	1	1134-5017-01	Washer			
17	1	9987-5332-16	Screw			
18	1	1134-5938-01	Fuel tank			
19	1	1134-5532-01	Fuel tank cap			
20	1	1134-3224-01	Fuel shut-off valve			
21	1	1134-3225-01	Grommet			
22	1	1134-2975-13	Fuel hose		L = 1100	
23	1	9578-0023-02	Hose clamp			
24	1	9578-0023-02	Hose clamp			
25	1	1134-5942-01	Tank loop			
26	1	1134-5996-01	Tank loop			
27	1	1134-4481-02	Wing nut			
28	1	9747-0631-02	Lock nut			
29	1	9579-0003-00	Cable holder			
30	1	9893-0616-16	Screw			
30	1	9852-8013-16	Screw			
31	2	1134-0433-00	Muffler gasket			
32	4	9939-0820-16	Screw			
32	4	1134-4930-01	Screw			
42	1	1134-0994-02	Tube clamp			
43	1	1134-4168-01	Fan disc			
44	4	9838-9516-12	Screw			
50	1	1134-6234-01	Heat deflector			
51	2	9943-0516-16	Screw			
52	1	1134-6251-01	Heat deflector			
53	4	9959-0612-16	Screw			
54	4	9739-0631-22	Nut			
99	1	1134-7233-01	Cable			



Section: PARK 2WD FOOT CONTROLS


Pos.	Quantity	Spare part No				Description	Kit	Notes	New
		6141		6179					
		6142		6189					
	6144	6182		6193					
	6184	6183	6180	6195					
1	1	1	1	1	1134-4247-01	Brake/clutch pedal			
2	1	1	1	1	1134-9024-01	.Bearing		Sats 4 st/kit of 4	
3	1	1	1	1	1134-3584-03	Brake/clutch cable			
4A	1	1		1	1134-6467-01	Cable holder			
4B			1		1134-6052-01	Cable holder			
5	3	3	3	3	9959-0820-16	Screw			
6	3	3	3	3	9739-0831-22	Nut			
7	1	1	1	1	1134-3974-01	Spring			
8	1	1	1	1	1134-6353-01	Drive pedal			
9	2	2	2	2	1134-6313-01	Bearing			
10	2	2	2	2	1134-2700-01	Bracket			
11	2	2	2	2	9959-0820-16	Screw			
12	2	2	2	2	9739-0831-22	Nut			
16	1	1	1	1	1134-2766-05	Speed control cable			
17	2	2	2	2	9570-0001-00	Elbow link			
18	2	2	2	2	9739-0531-22	Nut			
19	2	2	2	2	9747-0531-02	Nut			
20	1	1	1	1	1134-6317-01	Cable holder			
21	2	2	2	2	9959-0620-16	Screw			
22	2	2	2	2	9739-0631-22	Nut			
23	1	1	1	1	1134-3395-01	Attachment			
24	2	2	2	2	9959-0820-16	Screw		L = 20 mm	
25	2	2	2	2	9739-0831-22	Nut			
26	1	1	1	1	1134-2021-01	Clamp			
29		2	2	2	1134-6340-02	Foot rest			
30		4	4	4	9959-0620-16	Screw			
31		4	4	4	9739-0631-22	Nut			
48	1	1	1	1	1134-5101-01	Brake rod			
49	1	1	1	1	1134-3808-01	Knob			
50	1	1	1	1	1131-1497-01	Spring			
51	1	1	1	1	1134-4002-01	Brake rod attachmen			
52	3	3	3	3	9838-9516-12	Screw			
53				1	1134-4944-01	Stop plate			
58	1	1	1	1	9997-0835-16	Screw			
59	1	1	1	1	9739-0831-22	Nut			



Section: PARK 2WD PEDAL LIFT

Pos.	Quantity			Spare part No	Description	Kit	Notes	New
	6141	6182						
	6142	6183	6180					
	6144	6184	6193					
	6179	6189	6195					
1	1	1	1	1134-4117-01	Bracket			
2	2	2	2	1134-2684-01	Bearing			
3	1	1	1	1134-4945-01	Lift catch assy			
7	1	1	1	9404-0027-01	.O-ring			
8	1	1	1	9650-0039-04	.Lock ring			
9	1	1	1	9595-0276-01	.Locating pin			
10	1	1	1	9997-0640-12	.Screw			
11	1	1	1	9747-0631-02	.Lock nut			
13	1	1	1	9897-0820-16	.Screw			
14	1	1	1	9747-0831-02	Lock nut			
15	1	1	1	1134-4860-01	Lift fork			
16	2	2	2	1134-0240-00	Shoulder screw			
17	1	1	1	1134-4938-01	Lift pedal			
18	2	2	2	9997-0625-16	Screw			
19	2	2	2	9739-0631-22	Nut			
20	1	1	1	4231-0013-00	Spring			


www.emc-motoculture.com



Section: PARK 2WD PETROL FRAME


Pos.	Quantity			Spare part No	Description	Kit	Notes	New
	6141	6182						
	6142	6183						
	6144	6184	6193					
	6179	6189	6195					
1	1	1	1	1134-5315-03	Frame-front			
2	1	1	1	1134-3963-02	.Clevis			
3	1	1	1	1134-0031-00	.Pivot shaft stop			
4	1	1	1	9595-0262-00	.Locating pin			
5	1	1	1	1134-2171-01	Spring			
6	2	2	2	9501-0500-00	Grease joint			
7	1	1	1	1134-6466-01	Frame-rear			
8	1	1	1	1134-5705-01	.Spacer			
9	2	2	2	9547-0001-00	.Bearing			
10	2	2	2	9501-0500-00	.Grease joint			
11	1	1	1	1134-5988-01	Centre shaft			
13	2	2	2	9699-0035-02	Flat washer			
14	2	2	2	9959-1025-16	Screw			
15	2	2	2	9403-0048-70	Plug			
16	1	1	1	1134-5294-01	Floor plate			
17	1	1	1	1134-6372-04	Floor mat			
18	2	2	2	9893-0616-16	Screw			
19	1	1	1	1134-5944-01	Tank shelf			
20	2	2	2	9945-0816-16	Screw			
21	2	2	2	9959-0820-16	Screw			
22	2	2	2	9739-0831-22	Nut			
24	1	1	1	1134-5676-01	Bumper			
25	2	2	2	1134-4100-01	Plug			
26	2	2	2	1134-0240-00	Shoulder screw			
27	2	2	2	1134-4242-01	Spacer washer			
28	2	2	2	9665-0002-00	Bowed washer			
29	2	2	2	9747-0831-02	Lock nut			
30	2	2	2	9943-0516-16	Screw			

www.emc-motoculture.com




Section: PARK 2WD POWER TAKE-OFF

Pos.	Quantity	Spare part	No	Description	Kit	Notes	New
	6141 6182						
	6142 6183						
	6144 6184		6193				
	6179 6189 6180 6195						
1	1	1	1	1134-5548-01	Spacer		
2	1	1	1	1134-5109-01	Tension wheel arm		
3	1	1	1	1134-1770-01	Tension roller		
4	1	1	1	1134-1888-04	Spacer		
5	1	1	1	1134-5111-01	Spring		
6	1	1	1	9699-0056-02	Flat washer		
7	1	1	1	9739-0831-22	Nut		
8	1	1	1	9997-0855-12	Screw		
10	1	1	1	1134-1769-03	Centre pulley assy		
11	1	1	1	1134-0051-09	.Spacer		
12	2	2	2	9549-0019-00	.Ball bearing		
13	1	1	1	1134-5112-01	Spring attachment		
14	2	2	2	9945-0816-16	Screw		
15	1	1	1	1134-5110-01	Hook		
16	2	2	2	9893-0616-16	Screw		
18	1	1	1	1134-2018-02	Tension arm		
19	1	1	1	1134-9027-02	Tension roller-grey		
20	1	1	1	1134-9071-01	V-belt	= 9585-0129-01	
21	1	1	1	9997-1030-16	Screw		
22	1	1	1	9799-1031-02	Nut		
23	1	1	1	1134-4111-01	Brake arm		
24	1	1	1	1134-4164-03	Brake pad		
25	1	1	1	9897-0825-16	Screw		
26	1	1	1	9747-0831-02	Lock nut		
27	1	1	1	1134-4162-01	Brake rod		
28	1	1	1	9675-0008-02	Locking washer		
29	1	1	1	1134-4170-01	Nipple		
30	1	1	1	9699-0025-02	Washer		
31	1	1	1	9747-0631-02	Lock nut		
32	1	1	1	4231-0013-00	Spring		
33	1	1	1	1134-4231-01	Spring		
34	1	1	1	1134-1565-10	Spacer		
35	1	1	1	9997-0860-16	Screw		
36	1	1	1	9699-0056-02	Flat washer		
37	1	1	1	9739-0831-22	Nut		
38	1	1	1	1134-4163-01	Shoulder bolt		
39	1	1	1	9731-1031-22	Nut		
40	1	1	1	1134-3958-01	Belt guide		
41	2	2	2	9893-0616-16	Screw		
42	1	1	1	1134-0041-03	Collar		
43	1	1	1	9997-1070-12	Screw		
44	1	1	1	9739-1031-22	Nut		
45	1	1	1	1134-3654-01	Finger guard		
46	2	2	2	9959-0612-16	Screw		
47	2	2	2	9739-0631-22	Nut		
48	1	1	1	9699-0090-02	Flat washer		
49	2	2	2	9699-0035-02	Flat washer		




Section: PARK 2WD SEAT

Pos.	Quantity				Spare part No	Description	Kit	Notes	New
	6141	6182							
	6142	6183							
	6144	6184		6193					
	6179	6189	6180	6195					
1	1	1	1	1	1134-6444-01	Seat			
2	1	1	1	1	1134-6090-01	Slide plate			
3	1	1	1	1	1134-3262-01	Compression spring			
4	1	1	1	1	1134-6073-01	Handle			
5	1	1	1	1	9893-0616-16	Screw			
6	1	1	1	1	9747-0631-02	Lock nut			
7	1	1	1	1	1134-6068-01	Slide plate-lower			
8	1	1	2	1	1134-3156-01	Switch (black)			
9	1	1		1	1134-3156-02	Switch (grey)			
10	1	1	1	1	1134-5302-01	Spring			
11	1	1	1	1	1134-5299-01	Push plate			
12	1	1	1	1	9699-0090-02	Flat washer			
13	1	1	1	1	1134-1565-06	Spacer			
14	1	1	1	1	9997-0840-16	Screw			
15	1	1	1	1	9747-0831-02	Lock nut			
16	1	1	1	1	1134-5179-01	Catch			
17	1	1	1	1	9675-0012-02	Locking washer			
18	2	2	2	2	1134-0240-00	Shoulder screw			
19	2	2	2	2	1134-4620-01	Spring nut			
22	4	4	4	4	1134-6078-01	Flange washer			
23	4	4	4	4	9959-0820-16	Screw			
30	1	1	1	1	1134-5698-01	Seat bracket			
31	1	1	1	1	1134-4256-01	Seat spring			
32	1	1	1	1	9924-1235-19	Screw			
33	1	1	1	1	9747-1231-02	Lock nut			
34	1	1	1	1	1134-3990-01	Attachment-side pan			
35	2	2	2	2	9897-0820-16	Screw			
36	2	2	2	2	9739-0831-22	Nut			
37	1	1	1	1	1134-4130-01	Cover-lower			
38	4	4	4	4	9840-8019-16	Screw			
40	2	2	2	2	9897-0880-12	Screw			
41	2	2	2	2	1134-1565-08	Spacer			
42	4	4	4	4	9897-0820-16	Screw			
43	6	6	6	6	9747-0831-02	Lock nut			



Section: PARK 2WD TRANSMISSION

Pos.	Quantity	Spare part No				Description	Kit	Notes	New
	6141								
	6144								
	6182	6142		6184					
	6183	6189	6180	6195					
1	1	1	1	1	1134-4000-02	Tension arm			
2	1	1	1	1	1134-3459-01	Tension roller			
3	1	1	1	1	9924-1035-16	Screw			
4	1	1	1	1	9799-1031-02	Nut			
5	1	1	1	1	1134-9058-01	V-belt		= 9585-0091-01	
6	1	1	1	1	9997-0625-16	Screw			
7	1	1	1	1	9739-0631-22	Nut			
7A	1	1	1	1	9747-0631-02	Lock nut			
8	1	1	1	1	1134-3377-02	Control rod			
9	1	1	1	1	4231-0013-00	Spring			
10	1	1	1	1	1134-4171-01	Pivot pin			
11	1	1	1	1	1134-4183-01	Compression spring			
12	2	2	2	2	1134-3456-01	Bushing			
13	1	1	1	1	9747-0631-02	Lock nut			
14	1	1	1	1	1134-1565-08	Spacer			
15	1	1	1	1	9997-0870-16	Screw			
16	1	1	1	1	9699-0056-02	Flat washer			
17	1	1	1	1	9747-0831-02	Lock nut			
18	1	1	1	1	1134-6414-01	Spring			
19	1	1	1	1	9699-0060-02	Flat washer			
20	1	1	1	1	1134-4848-01	Transaxle assy		Kanzaki K46G	
21	4		4	4	9960-0860-12	Screw		L = 60 mm	
21		4			9997-0870-16	Screw		L = 70 mm	
22	4	4	4	4	9747-0831-02	Lock nut			
23	1	1	1	1	1134-3913-01	Strut			
24	1	1	1	1	9959-0825-16	Screw			
25	1	1	1	1	9997-0845-12	Screw			
26	1	1	1	1	9699-0090-02	Flat washer			
27	2	2	2	2	9747-0831-02	Lock nut			
28	1	1	1	1	9747-0631-02	Lock nut			
29	1	1	1	1	1134-2765-02	Oil tank			
30	1	1	1	1	1134-2777-02	Filler cap			
31	1	1	1	1	1134-3734-01	Vent plug			
32	1	1	1	1	1134-2778-01	Retainer strap			
33	2	2	2	2	9852-8013-16	Screw			
35	2	2	2	2	9578-0023-04	Hose clamp		15 x 8	
36	1	1		1	1134-2779-09	Tube		L = 290 mm	
36			1		1134-2779-06	Tube		L = 230 mm	
39	1	1	1	1	1134-3208-01	Grommet			
40	1	1	1	1	1134-4015-01	Pull rod			
41	1	1	1	1	1134-4014-01	Plastic button			
42	1	1	1	1	1134-4713-01	Bracket			
43	1	1	1	1	1134-2790-01	Rubber grommet			
44	1	1	1	1	9959-0820-16	Screw			
45	1	1	1	1	9739-0831-22	Nut			
46	1	1	1	1	9675-0009-02	Starlock			
48			1		1134-6047-01	Belt guide			
49			1		9959-1025-16	Screw			
50			1		9739-1031-22	Nut			
51	1	1		1	1134-3289-02	Belt guide			
52	1	1		1	9959-0820-16	Screw			
53	1	1		1	9699-0056-02	Flat washer			
54	1	1		1	9739-0831-22	Nut			
55	1	1	1	1	1134-5941-01	Tank bracket			
56	2	2	2	2	9959-0820-16	Screw			
57	2	2	2	2	9739-0831-22	Nut			
58			1		1134-6051-01	Hose nipple			
59			1		1134-6050-01	Elbow			
60			2		9578-0023-06	Hose clamp			
70		2			1134-3376-01	Spacer plate		6142-64, 6189-04	



Section: PARK 2WD WHEELS 16"

Pos.	Quantity	Spare part	No	Description	Kit	Notes	New
	6141	6182					
	6142	6183					
	6144	6179	6189				
	6184	6193	6195	6180			
1	2	2	2	2	1134-0075-01	Front axle	
2	2	2	2	2	9595-0258-00	Locating pin	
3	2	2	2	2	1134-4844-05	Wheel hub assy	
3A	1	1	1	1	9501-0500-00	.Grease joint	
4	1	1	1	1	1134-9026-01	.Bearing bush kit	Sats 4 st/kit of 4
5	2	2	2	2	1134-4558-01	Rim	
6	2	2	2	2	9545-0116-00	Tyre	16 x 7.50 - 8
7	2	2	2	2	9545-0500-00	Valve	
8	6	6	6	6	9731-1031-22	Nut	
10	8	8	8	8	1134-0341-01	Washer	
11	2	2	2	2	9599-0080-02	Cotter pin	
12	2	2	2	2	1134-4844-02	Wheel hub	
13	2	2	2	2	1134-4558-01	Rim	
14	2	2	2	2	9545-0116-00	Tyre	16 x 7.50 - 8
15	2	2	2	2	9545-0500-00	Valve	
16	6	6	6	6	9731-1031-22	Nut	
18	2	2	2	2	1134-4796-01	Hub cap	
19	2	2	2	2	9947-0540-19	Screw	
20	2	2	2	2	1134-2471-01	Key	
21	2	2	2	2	9699-0042-02	Flat washer	
22	2	2	2	2	9653-0001-04	Lock ring	
24	2	2			9598-0003-02	Spring pin	
25	2	2			1134-3710-01	Tool attachment	
26	2	2			9699-0042-02	Flat washer	
45			1	1	13-0992-61	Quick connections	Inkl. pos 46-53
46			1	1	1134-7465-01	.Attachment kit, LH	Inkl. pos 50-51
47			2	2	9598-2001-02	.Spring pin	
48			2	2	9548-0026-01	.Bearing	
50			2	2	9898-1035-16	..Screw	
51			2	2	9739-1031-22	..Nut	
52			2	2	1134-0341-01	.Washer	
53			2	2	9699-0042-02	.Flat washer	
54			2	2	9599-0080-02	.Cotter pin	
99					9545-0203-00	Inner tube	Reservdel/spare par