





Section: VILLA ACCESSORY BAG


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
	2723					
	2724					
0	1	1134-4664-01	Accessory bag assy			
1	1	9595-0262-00	.Locating pin			
2A	1	9699-0103-02	.Flat washer		0.5 mm	
2B	1	9699-0114-02	.Flat washer		1.0 mm	
3	2	1134-4185-01	.Flange washer			
4	2	9959-0820-16	.Screw			
5	4	9699-0056-02	.Flat washer			
6	2	1134-2609-01	.Knob			
7	1	1134-4627-01	.Tow bar			
8	2	9959-0820-16	.Screw			
9	1	1111-9029-02	.Spark plug wrench		5/8" (16 mm)/21 mm	
10	1	1134-4734-01	.Ignition key			
20	1	1134-3771-51	Folder w.manuals			
21	1	8211-2002-03	.Warranty card			
21	1	8211-0288-01	.Owner's manual			
21	1	8211-0290-01	.Assy. instruction			
21	1	8211-0289-01	.Service book			
21	1	8211-0209-08	.Safety regulations			

www.emc-motoculture.com




Section: VILLA BODY WORK

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
2721 2722 2723 2724						
1	1	1	1	1	1134-4467-01 Hood-front	
2	2	2	2	2	9893-0616-16 Screw	
3	2	2	2	2	1134-4444-01 Stay	
4	4	4	4	4	9959-0820-16 Screw	
5	4	4	4	4	9739-0831-22 Nut	
6	1	1	1	1	1134-4469-01 Hood-rear	
7	2	2	2	2	1134-4513-01 Hood attachment	
8	4	4	4	4	9893-0616-16 Screw	
9	2	2	2	2	1134-4490-01 Lock handle	
10	2	2	2	2	1134-4274-01 Bushing	
11	2	2	2	2	1134-4493-01 Dome nut	
12	1	1	1	1	1134-4471-01 Engine cover-grey	
12	1	1	1	1	1134-4471-02 Engine cover-green	2722-81 (Comfort)
13	1	1	1	1	1134-3944-03 Bumper	
14	4	4	4	4	1134-4176-01 Clips	
15	6	6	6	6	9893-0616-16 Screw	
16	1	1	1	1	1134-4592-01 Front plate	
17	2	2	2	2	9946-0525-16 Screw	
99	1				1134-4746-01 Decal kit	Master
99	1				1134-4746-02 Decal kit	Senator
99	1				1134-4746-03 Decal kit	Comfort
99		1			1134-4746-04 Decal kit	President
99			1		1134-4746-05 Decal kit	Royal



Section: VILLA EL. EQUIPMENT


Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		2721	2722	2723	2724		
1	1	1	1	1	1134-2892-01	Battery w/o acid	
2	1	1	1	1	9400-0064-02	Battery holder	
4			1	1	1134-4610-01	Switch bracket	
5			1	1	1134-3399-02	Switch	
6			2	2	9852-8013-16	Screw	
7			3	3	9579-0003-00	Cable holder	
8	1	1	1	1	1134-4701-01	Cable-black	L = 410 mm
9	3	3	3	3	9852-8013-16	Screw	
10	1	1	1		9747-0831-02	Lock nut	
11A	1	1	1		9795-3531-02	Nut	1/4 UNC
11B				1	9739-0831-22	Nut	M8
12	2	2	2	2	9579-0003-00	Cable holder	
13				1	9400-0292-01	Cable connection	
14				1	9943-0640-16	Screw	Likriktare/Rectifie
15		1			1134-4727-01	Cable-red	L = 120 mm
16				1	1134-2427-01	Spacer	
25	1	1	1	1	1134-2871-03	Relay	
26	1	1	1	1	1134-2962-01	Solenoid assy	
27	2	2	2	2	9794-5131-02	.Nut	
28	1	1	1	1	1134-4702-01	Cable-red	L = 380 mm
29	1	1	1	1	1134-2310-01	Guard cap	
30A	1	1	1		1134-4702-01	Cable-red	L = 380 (6 mm - 8 m
30B				1	1134-4703-01	Cable-red	L = 380 (8 mm - 8 m
31				1	1134-4704-01	Cable-white	L = 380 mm
32	1	1			1134-4694-01	Harness	
32			1		1134-4695-01	Harness	
32				1	1134-4696-01	Harness	



Section: VILLA FRAME


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721 2723					
	2722 2724					
1	1	1	1134-4426-01	Frame		
2	1	1	1134-4422-01	Floor plate		
3	2	2	9893-0616-16	Screw		
4		1	1134-4484-01	Floor mat		
4	1		1134-4485-01	Floor mat		
5	1	1	1134-4512-01	Bumper		
6	3	3	9959-0820-16	Screw		
7	1	1	9959-0825-16	Screw		
8	3	3	9739-0831-22	Nut		
9	1	1	9739-0831-22	Nut		

www.emc-motoculture.com




Section: VILLA LIFTING DEVICE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
	2723					
	2724					
1	1	1134-4117-01	Bracket			
2	2	9997-1040-16	Screw			
3	2	9739-1031-22	Nut			
4	2	1134-2684-01	Bearing			
5	1	1134-4184-01	Lift catch assy			
9	1	9404-0027-01	.O-ring			
10	1	9650-0039-04	.Lock ring			
11	1	9595-0276-01	.Locating pin			
12	1	9997-0640-12	.Screw			
13	1	9747-0631-02	.Lock nut			
15	1	9897-0820-16	.Screw			
16	1	9747-0831-02	Lock nut			
17	1	1134-4033-01	Lift fork			
18	2	1134-0240-00	Shoulder screw			
19	1	1134-4098-01	Lift pedal			
20	2	9997-0620-16	Screw			
21	2	9739-0631-22	Nut			
22	1	4231-0013-00	Spring			




Section: VILLA MASTER-SENATOR FOOT CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
1	1	1134-4608-01	Pedal			
2	2	1134-4624-01	Bearing			
3	4	9898-0635-12	Screw			
4	4	9739-0631-22	Nut			
5	1	1134-4666-01	Clutch rod			
6	1	1134-2138-01	Eye bolt			
7	2	9699-0035-02	Flat washer			
8	2	9595-0208-00	Locating pin			
9	1	9739-0831-22	Nut			
10	1	9747-0831-02	Lock nut			
11	1	9595-0208-00	Locating pin			
12	2	9699-0035-02	Flat washer			
13	1	9598-0002-02	Pin lock			
14	1	1134-4616-01	Brake rod			
15	1	1134-4617-01	Spring			
16	1	1134-2138-01	Eye bolt			
17	2	9699-0035-02	Flat washer			
18	1	1134-4775-01	Lock nut			
19	1	9739-0831-22	Nut			
20	1	9747-0831-02	Lock nut			
21	1	9675-0015-02	Lock washer			
22	1	1134-4675-01	Brake arm			
23	1	9997-0820-16	Screw			
25	1	9747-0831-02	Lock nut			
26	1	1134-3953-01	Brake rod			
27	1	1134-3808-01	Knob			
28	1	1131-1497-01	Spring			
29	1	1134-4002-01	Brake rod attachmen			
30	3	9838-9516-12	Screw			
31	1	1134-4714-01	Angle bracket			
32	2	9959-0820-16	Screw			
33	2	9739-0831-22	Nut			
34	1	1134-4715-01	Triangular plate			
35	1	1134-0240-00	Shoulder screw			
36	1	9694-0001-00	Washer			
37	1	9699-0036-02	Flat washer			
38	1	9747-0831-02	Lock nut			
39	1	1134-4717-01	Threaded rod			
40	2	9570-0004-00	Elbow link			
41	2	9747-0661-02	Lock nut			
42	2	9739-0631-22	Nut			
43	1	1134-4722-01	Shifter lever			
44	1	9987-5016-16	Screw			
45	1	9699-0060-02	Flat washer			
46	1	9675-0009-02	Starlock			
47	1	9694-0001-00	Washer			




Section: VILLA MASTER-SENATOR HAND CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
1	1	1134-4683-01	Panel bracket			
2	2	9959-0820-16	Screw			
3	2	9739-0831-22	Nut			
4	2	9893-0616-16	Screw			
5	1	1134-4487-01	Panel bracket			
6	1	1134-3986-01	Front plate			
7	4	9893-0616-16	Screw			
8	1	1134-4580-01	Gear shifter lever			
9	1	1134-2551-01	Knob			
10	1	1134-4065-01	Control shaft			
11	1	1134-4080-03	Control sleeve			
12	1	1134-4079-01	Spring			
13	2	9959-0820-16	Screw			
14	1	1134-4217-01	Switch bracket			
15	2	9852-8013-16	Screw			
16	1	1134-4233-01	Switch			
17	1	1134-4697-01	Switch			
18	2	9847-7732-16	Screw			
19	1	1134-4716-01	Shifter rod			
20	1	9675-0009-02	Starlock			
21	1	1134-4590-01	Throttle control			
22	1	1134-4078-01	Knob			
23	1	1134-0240-00	Shoulder screw			
24	1	9694-0001-00	Washer			
25	2	1134-4242-01	Spacer washer			
26	1	9747-0831-02	Lock nut			
27	1	1134-1597-11	Throttle cable			
28	1	9500-9991-00	Cable clamp			
29	1	9943-0516-16	Screw			
30	1	1134-4093-01	Ignition switch			
31	1	1134-4749-01	Nut			
33	1	1134-4734-01	Ignition key			
34	1	1134-4472-01	Attachment plate			
35	2	9943-0516-16	Screw			
36	1	1134-4470-04	Dashboard			
37	4	9943-0516-16	Screw			
38	2	1134-4129-01	Cover			
39	1	9400-0282-01	Switch w.diode			
40	1	9400-0280-01	Cover-PTO			
41	1	9840-7716-16	Screw			
99	1	9400-0290-01	Tool for cover		Tillbehör/accessory	



Section: VILLA MASTER-SENATOR TRANSMISSION



Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
4	1	1134-4613-01	Belt guide			
5	1	9699-0056-02	Flat washer			
6	1	1134-4519-01	Tension arm			
7	1	1134-3053-01	Tension roller			
8	1	1134-4614-01	Shoulder spacer			
9	1	9997-1040-16	Screw			
10	1	9699-0035-02	Flat washer			
11	1	9739-1031-22	Nut			
12	1	1134-9027-01	Tension roller			
13	1	1134-1795-01	Belt stirrup			
14	1	9997-1040-16	Screw			
15	1	9699-0035-02	Flat washer			
16	1	9739-1031-22	Nut			
17	1	1134-9065-01	Drive belt		= 9585-0124-01	
18	1	1134-1565-08	Spacer			
19	1	9997-0870-16	Screw			
20	2	9699-0056-02	Flat washer			
21	1	9739-0831-22	Nut			
22	1	1134-3212-01	Spring			
23	1	1134-3716-03	Transaxle		Peerless MST 205	
24	4	9997-0870-16	Screw			
25	4	9747-0831-02	Lock nut			
26	1	1134-4687-01	Strut			
27	2	9945-0816-16	Screw			
28	1	1134-1849-01	Belt pulley			
29	1	9600-0050-00	Key			
30	1	9650-0016-04	Lock ring			
31	1	1134-4707-01	Belt guide			



Section: VILLA MASTER-SENATOR- PRESIDENT ENGINE




Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2722					
	2721	2723				
1	4	4	9997-0840-16	Screw		
2	4	4	9747-0831-02	Lock nut		
3A	1		1134-4468-01	Spacer	H = 39.5	
3B	1		1134-4468-02	Spacer	H = 84	
4	1	1	1134-4222-02	Seal ring		
5	1	1	1134-4504-01	Fuel tank		
6	1	1	1134-2877-02	Fuel tank cap		
7	1	1	1134-3224-01	Fuel shut-off valve		
8	1	1	1134-3225-01	Grommet		
9	1	1	1134-2975-08	Fuel hose	L = 580 mm	
10	2	2	9578-0023-02	Hose clamp		
11	2	2	9579-0003-00	Cable holder		
12	1	1	1134-4505-01	Tank clamp		
13	1	1	1134-4481-02	Wing nut		
14	1	1	9747-0631-02	Lock nut		
15	1	1	1134-4508-01	Tank/battery shelf		
16	4	4	9959-0820-16	Screw		
17	4	4	9739-0831-22	Nut		
18	1		1134-4526-01	Exhaust pipe		
19	1		1134-0433-00	Muffler gasket		
20	1		1134-2462-01	Lock		
21	2		1134-1565-01	Spacer		
22	2		9988-3651-12	Screw		
23	1		1134-4525-01	Muffler		
24	1		9578-0011-00	Clamp		
25	1		9959-0820-16	Screw		
26	1		1134-4522-01	Muffler guard		
27	4		9893-0616-16	Screw		
28	1		1134-4553-01	Deflector		
29	1		9893-0616-16	Screw		
41	1	1	1134-4611-01	Engine belt pulley		
42	1	1	9600-0251-00	Key		
43	1	1	9987-5357-12	Screw		

www.emc-motoculture.com



Section: VILLA POWER TAKE-OFF


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
	2723					
	2724					
1	1	1134-4672-01	Electric PTO-clutch			
2	1	1134-4679-01	Strut			
3	1	9959-0820-16	Screw			
4	1	1134-4538-01	Tension roller brkt			
5	1	1134-3053-01	Tension roller			
6	1	9699-0056-02	Flat washer			
7	1	9959-0820-16	Screw			
8	1	1134-4650-01	Pulley bracket			
9	2	9945-0816-16	Screw			
10	1	1134-4643-01	Intermediate pulley			
11	1	1134-0051-12	.Spacer			
12	2	9549-0019-00	.Ball bearing			
13	2	9651-0040-04	.Retaining ring			
14	2	1134-0052-00	Bearing spacer			
15	1	9997-1040-16	Screw			
16	1	9699-0035-02	Flat washer			
17	1	1134-9066-01	Drive belt		= 9585-0125-01	
18	1	1134-4649-01	Tension arm			
19	1	1134-9027-01	Tension roller			
20	1	1134-4619-01	Spacer			
21	1	9997-1060-12	Screw			
22	1	9739-1031-22	Nut			
23	1	1134-1842-01	Holder			
24	1	9997-0645-12	Screw			
25	1	9747-0631-02	Lock nut			
26	1	1134-4619-01	Spacer			
27	1	9997-1040-16	Screw			
28	1	9699-0035-02	Flat washer			
29	1	9739-1031-22	Nut			
30	1	1134-4708-01	Bracket			
31	2	9959-0820-16	Screw			
32	2	9739-0831-22	Nut			
33	1	1134-4441-01	Link			
34	1	9959-0820-16	Screw			
35	1	9739-0831-22	Nut			
36	1	1131-1507-00	Spring			
37	1	9739-0831-22	Nut			



Section: VILLA SEAT

Pos.	Quantity			Spare part No	Description	Kit	Notes	New
	2721							
	2722	2723	2724					
1	1	1		1134-4585-01	Seat			
2			1	1134-4223-01	Seat			
3	1	1	1	1134-4628-01	Seat plate			
4	2	2	2	1134-0240-00	Shoulder screw			
5	2	2	2	1134-4620-01	Spring nut			
6	1	1	1	1134-4340-01	Catch			
7	1	1	1	9675-0008-02	Locking washer			
8	1	1	1	1134-4014-01	Plastic button			
12	1	1	1	1134-4211-02	Seat bracket			
13	1	1	1	1134-4659-01	Seat spring			
14	1	1	1	9924-1230-19	Screw			
15	1	1	1	9747-1231-02	Lock nut			
16	1	1	1	1134-4629-01	Shaft			
17	2	2	2	9675-0012-02	Locking washer			
18	1	1	1	1134-4631-01	Bracket			
19	2	2	2	9893-0616-16	Screw			
20	2	2	2	9739-0631-22	Nut			
21	1	1	1	1134-4648-01	Switch			
22	2	2	2	9840-7716-16	Screw			
23	1	1	1	1134-4632-01	Compression pin			
24	1	1	1	1134-4755-01	Compression spring			
25	1	1	1	9699-0060-02	Flat washer			
26	1	1	1	1134-3456-01	Bushing			
27	1	1	1	9652-0004-04	Circlip			
28	5	6	6	9959-0820-16	Screw		L = 20 mm	
29	2			9959-0825-16	Screw		L = 25 mm	
30	2			9699-0056-02	Flat washer			
31	7	7	7	9739-0831-22	Nut			
32		1	1	9897-0820-16	Screw			


www.emc-motoculture.com



Section: VILLA STEERING

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721 2723					
	2722 2724					
1	4	4	1134-0041-01	Bushing		
2	4	4	1134-3022-01	Cable holder		
3	2	2	1134-9025-01	Steering pulley-kit	Sats 2 st/kit of 2	
4	4	4	9997-1040-16	Screw		
5	2	2	9739-1031-22	Nut		
6	1	1	1134-2032-03	Steering cable		
7	1	1	1134-1310-01	Compression spring		
8	1	1	9699-0056-02	Flat washer		
9	1	1	9747-0831-02	Lock nut		
10	1	1	9959-0820-16	Screw		
11	1	1	1134-4120-02	Steering console		
12	4	4	9897-0820-16	Screw		
13	4	4	9739-0831-22	Nut		
14	1	1	1134-4483-01	Bushing		
15	1	1	1134-1305-03	Steering column-low		
16	2	2	1134-1901-01	Bearing		
17	2	2	9893-0616-16	Screw		
18	2	2	9699-0060-02	Flat washer		
19	1	1	1134-4431-01	Steering rod		
20	1	1	1134-1933-01	Steering pulley		
21	1	1	9595-0262-00	Locating pin		
22	1		1134-1966-03	Steering wheel		
23		1	1134-3754-02	Steering wheel assy		
24		1	1134-3769-01	..Steering wheel but		
25		1	1134-3752-01	..Knob holder		
26		1	9997-0865-12	..Screw		
27		1	1134-1565-06	..Spacer		
28		2	9699-0090-02	..Flat washer		
29		1	9747-0831-02	..Lock nut		
30		1	9403-0043-70	..Plug		
31		1	9403-0113-00	..Nut cap		
32	1	1	1134-3047-01	Spacer		
33	2	2	9699-0104-02	Washer		

www.emc-motoculture.com



Section: VILLA WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
	2723					
	2724					
1	1	1134-4604-01	Rear axle			
2	2	9501-0500-00	Grease joint			
3	1	1134-4528-01	Wheel spindle-L.H.			
4	1	1134-4528-02	Wheel spindle-R.H.			
5	2	9699-0088-02	Flat washer			
6	2	9650-0020-04	Circlip			
7	1	1134-1500-02	Steering pulley			
8	1	1134-1583-01	Shaft-steering pull			
9	1	1134-9024-01	Bearing		Sats 4 st/kit of 4	
10	1	1134-0341-01	Washer			
11	1	9650-0020-04	Circlip			
12	2	1134-3247-04	Tie rod			
13	4	9997-0825-16	Screw			
14	2	9699-0028-02	Flat washer			
15	4	9747-0831-02	Lock nut			
16	2	1134-4706-01	Rim			
17	1	1134-9026-01	Bearing bush kit		Sats 4 st/kit of 4	
18	2	9545-0125-01	Tyre		14 x 5.50 - 6	
19	2	9545-0500-00	Valve			
20	2	1134-0341-01	Washer			
21	2	9650-0020-04	Circlip			
22	2	1134-4344-01	Hub cap			
25	1	9501-0500-00	Grease joint			
26	1	9699-0088-02	Flat washer			
27	1	9650-0020-04	Circlip			
28	2	1134-4670-01	Rim			
29	2	9545-0116-00	Tyre		16 x 7.50 - 8	
30	2	9545-0500-00	Valve			
31	2	9997-0840-16	Screw			
32	2	9747-0831-02	Lock nut			
33	2	1134-2471-01	Key			
34	2	9598-0003-02	Spring pin			
35	4	1134-0341-02	Washer			
98		9545-0204-00	Inner tube		Reservdel/spare par	
99		9545-0203-00	Inner tube		Reservdel/spare par	