






Section: VILLA CLASSIC-2000-SENATOR CLUTCH BRAKE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855					
	2856	2858				
1	1	1	1134-1633-01	Engine belt pulley		
2	1	1	9987-5338-12	Screw		
11	1	1	1134-3832-01	Tension arm		
12	1	1	1134-9027-01	Tension roller		
13	1	1	1134-9008-01	V-belt	= 9585-0050-00	
14	1	1	9739-1031-22	Nut		
15	1	1	9997-1030-16	Screw		
16	1	1	1134-1949-01	Spring		
17	1	1	1134-0240-00	Shoulder screw		
18	1	1	9696-0013-01	Bowed washer		
19	1	1	9699-0037-02	Washer		
20	1	1	9699-0090-02	Flat washer		
21	1	1	9739-0831-22	Nut		
30	1	1	1134-1849-01	Belt pulley		
31	1	1	9650-0016-04	Lock ring		
32	1	1	1134-1795-01	Belt stirrup		
33	1	1	9699-0090-02	Flat washer		
40	1	1	1134-3801-01	Clutch pedal		
41	1	1	1134-1927-01	Bearing		
42	2	2	9898-0635-12	Screw		
43	2	2	9739-0631-22	Nut		
44	1	1	1134-3633-01	Spring		
45	1	1	1134-3829-01	Control rod		
46	1	1	1134-2138-01	Eye bolt		
47	2	2	9747-0831-02	Lock nut		
48	2	2	9739-1031-22	Nut		
49	1	1	9595-0208-00	Locating pin		
50	1	1	1134-3817-01	Compression spring		
51	2	2	9699-0035-02	Flat washer		
52	1	1	1134-3809-01	Brake rod		
53	1	1	9598-0002-02	Pin lock		
54	1	1	1134-3802-01	Parking brake lever		
55	1	1	1134-3808-01	Knob		
56	1	1	1134-0240-00	Shoulder screw		
57	1	1	9699-0069-02	Flat washer		
58	1	1	9694-0001-00	Washer		
59	1	1	9739-0831-22	Nut		
60	1	1	4231-0013-00	Spring		
70	1	1	1134-0139-01	Belt guide		
71	1	1	9699-0090-02	Flat washer		
72	1	1	1134-3827-01	Belt guide		




Section: VILLA CLASSIC-2000-SENATOR TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855					
	2856	2858				
1	1	1	1134-3820-01	Sprocket		
2	1	1	1134-3823-01	Spacer		
3	1	1	9739-0831-22	Nut		
4	1	1	9997-0855-12	Screw		
5	1	1	1134-1942-01	Adjusting screw		
6	1	1	9747-0831-02	Lock nut		
7	2	2	1134-1561-01	Lever		
8	1	1	1134-3823-01	Spacer		
9	1	1	9739-0831-22	Nut		
10	1	1	9997-0855-12	Screw		
11	1	1	9500-9949-00	Transmission assy	Peerless 781B	
12	4	4	9988-3619-16	Screw		
13	1	1	9589-0008-02	Chain w. chain lock		
14	1	1	9589-0504-00	.Chain lock		
15	1	1	9600-0050-00	Key		
16	1	1	1134-1694-04	Differential assy	Peerless 100-019C	
17	1	1	1134-1691-02	Sprocket		
18	4	4	9743-3621-32	Nut		
30	2		1134-3176-02	Rim		
31		2	1134-3707-02	Rim		
32	2	2	9545-0116-00	Tyre	16 x 7.50-8	
32A			9545-0203-00	Inner tube	Reservdel/spare par	
33	2	2	9545-0500-00	Vallve		
34	2	2	1134-0341-01	Washer		
35	2	2	1134-1348-01	Screw		
36	2	2	9743-3721-32	Nut		
37	2	2	1134-1876-01	Axle mounting		
38	2	2	1134-1875-01	Bushing		
39	4	4	9739-0831-22	Nut		
40	4	4	9959-0820-16	Screw		
50	1	1	1134-1925-02	Gear shifter		
51	1	1	1134-1981-01	Shift lock		
52	1	1	9699-0060-02	Flat washer		
53	1	1	9987-5016-16	Screw		
54	1	1	1134-1916-01	Stop plate		
55	2	2	9945-0816-16	Screw		
60		2	1134-3840-01	Protection cover		
61		2	1134-3850-01	Hose		



Section: VILLA ELECTRICAL SYSTEM


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855	2881				
	2856	2858	2843			
1	1	1	1134-3251-02	Bracket		
2		1	9959-0616-16	Screw	L = 16 mm (US, CA)	
2	1	1	9959-0612-16	Screw	L = 12 mm	
3	2	2	9739-0631-22	Nut		
4	1	1	1134-3156-02	Switch		
5		1	9959-0616-16	Screw	L = 16 mm	
5	1	1	9997-0625-16	Screw	L = 30 mm	
6		1	1134-3551-01	Attachment	2843	
7		1	1134-3156-01	Seat switch	2843	
12	1	1	1134-3204-01	Cable holder		
13	1	1	1131-1455-00	Battery cable (-)		
14	1	1	1134-0234-01	Battery cable (+)		
15	1	1	1134-2310-01	Guard cap		
16	1	1	1134-1594-01	Panel		
17	1	1	1134-1814-01	Starter switch assy		
18	1	1	1134-2853-01	.Washer		
19	1	1	1134-2852-01	.Nut		
20	1	1	1134-2848-01	.Ignition key		
21	1	1	1134-1922-01	Battery plate		
22	1	1	1134-3621-01	Harness		
22		1	1134-3815-01	Harness		
22		1	1134-3839-01	Harness	2843 (US, CA)	
23	1	1	1134-3623-02	.Interlock module		
24	1	1	1134-2962-01	Solenoid assy		
25	2	2	9794-5131-02	.Nut		
26	4	4	9849-8009-16	Screw		
27	1	1	9942-0612-16	Screw		
28	2	2	9739-0631-22	Nut		
29	2	2	9959-0612-16	Screw		
30	1	1	9400-0086-00	Battery w/o acid		
31	1	1	1134-2333-01	Battery pad		
32	1	1	9400-0064-02	Battery holder		
33	1	1	1134-3300-01	Battery acid	2 x 0.85 liter	
34	2	2	9699-0060-02	Flat washer		
35	1	1	9747-0631-02	Lock nut		
36	1	1	9795-3531-02	Nut		
37		1	1134-3778-01	Battery shelf		
38		1	1134-3779-01	Electric console		
39		1	1134-3399-02	Switch		
40		2	9997-0520-16	Screw		
41		2	9747-0631-02	Nut		
42		1	9959-0616-16	Screw		
43		1	9747-0631-02	Lock nut		
44		2	9699-0060-02	Flat washer		
45	1	1	9400-0275-00	Terminal contact		
46	1	1	9400-0276-00	Terminal plug		



Section: VILLA ENGINE


Pos.	Quantity	Spare part No				Description	Kit	Notes	New
				2881					
	2855	2858	2843	2856					
1	4	4	4	4	9747-0831-02	Lock nut			
2	4	4	4	4	9997-0840-16	Screw			
3		1	1	1	9500-9915-01	Tank bracket-front			
4		2	2	2	9931-3619-16	Screw			
5		1	1	1	9500-9916-01	Tank bracket-rear			
6		2	2	2	9795-3631-02	Nut			
7		1	1	1	1134-3582-01	Fuel tank			
8		1	1	1	1134-2877-02	Fuel tank cap			
9		1	1	1	1134-3586-01	Strap-short			
10		1	1	1	1134-3587-01	Strap-long			
11		2	2	2	9948-0630-16	Screw			
12		2	2	2	9747-0631-02	Lock nut			
13		1	1	1	1134-3224-01	Fuel shut-off valve			
14		1	1	1	1134-3225-01	Grommet			
15		1	1	1	1134-2975-01	Fuel hose			
16		1	1	1	9500-9917-01	Heat guard			
17		2	2	2	9578-0010-00	Cable clip			
18		2	2	2	9578-0023-02	Hose clamp			
19		2	2	2	9943-0510-16	Screw			
20	1	1	1	1	1134-1364-02	Spacer ring			
21	1	1	1	1	9600-0250-00	Key			
22		1	1		1134-2350-01	Exhaust pipe			
23		1	1		1134-0433-00	Muffler gasket			
24		1	1		1134-2462-01	Lock			
25		2	2		1134-1565-01	Spacer			
26		2	2		9988-3651-12	Screw			
27		1	1		1134-2394-01	Heat guard			
28		2	2		9739-0831-22	Nut			
29		1	1		1134-3869-01	Muffler			
30		1	1		9578-0011-00	Clamp			
31		1	1		9959-0820-16	Screw			
32		1	1		1134-3724-01	Guard			
33		1	1		9578-0022-00	Clamp			
34		1	1		9842-0001-16	Screw			
40	1	1	1	1	1134-1975-01	Gas control			
41	1	1	1	1	9403-0035-10	Handle			
42	2	2	2	2	9849-8009-16	Screw			

www.emc-motoculture.com



Section: VILLA FRAME BODYWORK


Pos.	Quantity			Spare part No	Description	Kit	Notes	New
	2855		2881					
	2856	2858	2843					
2	5	5	5	9739-0831-22	Nut			
3	3	3	4	9959-0816-16	Screw		L = 16 mm	
4	1	1	1	9997-0855-12	Screw		L = 55 mm	
5	1	1		9959-0825-16	Screw		L = 25 mm	
6	1	1	1	1134-1595-02	Tube			
7	2	2	2	1134-2849-01	Rubber hose			
8	2	2	2	9403-0015-70	Plug			
9	2	2	2	9739-0831-22	Nut			
10	2	2	2	9959-0816-16	Screw			
11	2	2	2	9997-1055-12	Screw			
12		1	1	1134-2352-03	Tow bar		2858, 2881	
13	1	1	1	1134-3799-01	Cover			
14	4	4	4	9849-8013-16	Screw			
15		1	1	9699-0056-02	Flat washer			
16	1			1134-3113-01	Spacer		2856	
17	1			9997-0840-16	Screw			
18	1			9739-0831-22	Nut			
20	1	1		1134-3819-01	Floor mat			
20			1	1134-3818-01	Floor mat			
30	1	1	1	1134-2856-01	Engine hood-yellow			
31	1	1	1	9948-0616-16	Screw			
32	1	1	1	9699-0060-02	Flat washer			
33	1	1	1	1134-3643-01	Nut			
34	2	3	3	9405-0029-00	Knob			
35	3	3	3	9632-0516-00	Pop rivet			
36	1	1	1	1134-9028-01	Rubber strap kit		Sats 3 st/kit of 3	
37	1			9699-0054-02	Flat washer			
38	2	2	2	9699-0087-02	Flat washer			
39	2	2	2	9849-8013-16	Screw			
40	1			1134-2855-01	Engine cover-black		2855	
40		1	1	1134-2855-04	Engine cover-black			
40	1			1134-2855-05	Engine cover-green		2856	
41	1	1	1	1134-2267-01	Guarding net			
42		1	1	1134-3750-01	Panel			
43		1	1	9849-8013-16	Screw			
99	1	1	1	1134-3923-01	Decal kit			



Section: VILLA MANUAL LIFTING DEVICE


Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855	2881				
	2856	2858	2843			
0	1	1	1	1134-1437-02	Lifting device assy	
1	1	1	1	9403-0110-01	.Handle	
2	2	2	2	9699-0025-02	.Washer	
3	1	1	1	1134-0583-00	.Plastic knob	
4	2	2	2	9739-0631-22	.Nut	
5	1	1	1	1111-0053-00	.Compression spring	
6	1	1	1	1134-1889-01	.Eyebolt	
7	1	1	1	1134-0859-03	.Lift lever	
8	1	1	1	9646-0099-22	.Rivet	
9	1	1	1	1134-0858-00	.Push rod	
10	1	1	1	9675-0008-02	.Locking washer	
11	1	1	1	1134-2911-01	.Locking pawl	
12	1	1	1	9675-0012-02	.Locking washer	
13	2	2	2	1134-2684-01	.Bearing	
14	1	1	1	1134-0536-00	.Lift quadrant	
15	2	2	2	9739-1031-22	Nut	
16	2	2	2	9959-1020-16	.Screw	
17	2	2	2	9595-0258-00	.Locating pin	
18	1	1	1	1134-1604-01	.Trippet	
19	1	1	1	1134-1884-01	.Lifting shaft	

www.emc-motoculture.com




Section: VILLA POWER TAKE-OFF

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855	2881				
	2856	2858	2843			
1	1	1	1134-1633-01	Engine belt pulley		
10	1	1	1131-1497-01	Spring		
11	1	1	1134-0022-00	Control rod		
12	1	1	1134-0027-01	Control lever		
12		1	1134-1396-02	Control lever	2843	
13	1	1	1134-2453-01	Locking pawl		
14	1	1	1134-0143-00	Stop washer		
15	1	1	1134-0153-00	Handle		
16	1	1	1134-0583-00	Plastic knob		
17	1	1	1134-1972-01	Disengaging lever		
18	2	2	9672-0004-02	Lock washer		
20	2	2	9699-0025-02	Washer		
21	1	1	9739-0831-22	Nut		
22	1	1	9847-8016-16	Screw		
23	1	1	9959-0820-16	Screw		
30	1	1	1134-3512-01	Brake lever		
31	1	1	1134-3510-01	Spacer		
32	1	1	9699-0056-02	Flat washer		
33	1	1	1134-3443-01	Spring		
39	1	1	9677-0009-02	Lock washer		
40	1	1	1134-3053-01	Tension roller		
41	1	1	1134-1023-00	Spring		
42	1	1	1134-1438-02	Tensioning arm		
43	1	1	1134-1647-01	Belt stirrup		
44	1	1	1134-1888-02	Spacer		
45	1	1	1134-1935-01	Link rod		
46	1	1	1134-9010-01	V-belt	= 9585-0053-00	
47	2	2	9699-0028-02	Flat washer		
48	1	1	9699-0062-02	Flat washer		
49	1	1	9739-0831-22	Nut		
50	1	1	9747-0831-02	Lock nut		
51	1	1	9997-0845-12	Screw		
52	1	1	1134-3974-01	Spring		
53	1	1	9675-0011-00	Star lock		
54	1	1	9699-0090-02	Flat washer		
55	1	1	1134-1838-01	Bracket		
56	1	1	9696-0013-01	Bowed washer		
57	1	1	9699-0056-02	Flat washer		
58	1	1	9739-0831-22	Nut		
59	1	1	9997-0845-12	Screw		
60	1	1	1134-1838-01	Tensioning arm		
61	1	1	1134-3043-01	Tension roller		
62	1	1	9997-0845-12	Screw		
63	1	1	9739-0831-22	Nut		
64	1	1	1134-1322-01	Spring		
65	1	1	1134-1486-01	Double v-belt pulle		
69	1	1	1134-9031-01	V-belt	= 9585-0072-00	
70	1	1	1134-1839-01	Shaft		
71	1	1	1134-1569-01	Belt guide		
72	2	2	9699-0035-02	Flat washer		
73	1	1	9997-1080-12	Screw		
74	1	1	1134-3783-01	Bracket		
74		1	1134-3784-01	Bracket		
75	2	2	9959-0816-16	Screw		
76	2	2	9739-0831-22	Nut		



Section: VILLA SEAT

Pos.	Quantity			Spare part No	Description	Kit	Notes	New
	2855		2881					
	2856	2858	2843					
1		1	1	1134-2541-01	Seat			
1	1			1134-0800-06	Seat			
2	2	2	2	1134-2961-01	Seat adapter			
3	2	2	2	1134-1711-01	Knob			
4	2	2	2	9699-0062-02	Flat washer			
5	4	4	4	9988-3616-16	Screw			
6	2	2	2	9898-0820-16	Screw			
12	1	1	1	1134-3800-01	Seat bracket-yellow			
13	1	1	1	1134-2163-01	Rod			
14	1	1	1	1134-2166-01	Spacer			
15	1	1	1	1134-0019-00	Spring nut			
16	1	1	1	9595-0160-00	Locating pin			
17	2	2	2	9799-0831-02	Nut			
18	1	1	1	1134-2847-01	Shaft			
19	1	1	1	1134-2846-01	Tube			
20	2	2	2	1134-1650-01	Tie bar			
21	1	1	1	1134-3871-02	Pivot shaft			
22	2	2	2	9997-0816-02	Screw			
23	4	4	4	9699-0062-02	Flat washer			
24	2	2	2	9747-0831-02	Lock nut			
25			1	1134-3877-01	Seat bracket-R.H.		2843	
25	1	1	1	1134-3878-01	Seat bracket-R.H.			
26	1	1	1	1134-3878-02	Seat bracket-L.H.			
26			1	1134-3877-02	Seat bracket-L.H.		2843	
27	1	1	1	1134-3876-01	Spring shackle			
28	1	1	1	1134-3879-01	Seat spring			
29	1	1	1	1134-1883-01	Axle			
30	1	1	1	1134-0022-00	Control rod			
31	2	2	2	9672-0004-02	Lock washer			
32	1	1	1	1134-0050-00	Seat rod			
33	1	1	1	1134-2454-01	Shaft			
34	2	2	2	9672-0006-02	Lock washer			



Section: VILLA STEERING

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855	2881				
	2856	2858	2843			
1	4	4	4	1134-0041-01	Bushing	
2	1	1	1	1134-3022-01	Cable holder	
3	3	3	3	1134-3022-01	Cable holder	
4	2	2	2	1134-9025-01	Steering pulley-kit	Sats 2 st/kit of 2
5	4	4	4	9942-1030-16	Screw	
6	1	1	1	1134-9023-01	Steering wire	
7	1	1	1	1134-1310-01	Compression spring	
8	1	1	1	9699-0090-02	Flat washer	
9	1	1	1	9747-0831-02	Lock nut	
10	1	1	1	9959-0816-16	Screw	
11	1			1134-2390-01	Steering wheel	
11		1	1	1134-3754-01	Steering wheel w.kn	
12		1	1	1134-3769-01	.Steering wheel but	
13		1	1	1134-3752-01	..Knob holder	
14		1	1	9997-0865-12	..Screw	
15		1	1	1134-1565-06	..Spacer	
16		2	2	9699-0090-02	..Flat washer	
17		1	1	9747-0831-02	..Lock nut	
18		1	1	9403-0043-70	..Plug	
19		1	1	9403-0113-00	..Nut cap	
20	1	1	1	1134-1424-01	Steering column	
21	1	1	1	1134-1933-01	Steering pulley	
22	1	1	1	9595-0262-00	Locating pin	
23	2	2	2	1134-1901-01	Bearing	
30			1	1134-3538-01	Rear weight (no spa	2843
31			2	9997-1080-12	Screw	
32			2	9699-0035-02	Flat washer	
40	1	1	1	1134-0341-01	Washer	
41	2	2	2	1134-3247-02	Tie rod	
42	1	1	1	1134-1428-01	Spindle L.H.	
43	1	1	1	1134-1428-02	Spindle R.H.	
44	1	1	1	1134-1500-02	Steering pulley	
45	1	1	1	1134-9024-01	Bearing	Sats 4 st/kit of 4
46	1	1	1	1134-1583-01	Shaft-steering pull	
47	1	1	1	1134-1634-01	Rear axle	
47			1	1134-1634-02	Rear axle (no spare	2843
48	2	2	2	9501-0500-00	Grease joint	
49	3	3	3	9650-0020-04	Circlip	
50	2	2	2	9699-0088-02	Flat washer	
51	4	4	4	9747-0831-02	Lock nut	
52	2	2	2	9699-0028-02	Flat washer	
53	4	4	4	9997-0825-16	Screw	
54	1	1	1	9501-0500-00	Grease joint	
55	1	1	1	9650-0020-04	Circlip	
56	1	1	1	9699-0088-02	Flat washer	
57	2	2	2	1134-4342-01	Rim	
58	1	1	1	1134-9026-01	Bearing bush kit	Sats 4 st/kit of 4
59	2	2	2	9545-0117-00	Tyre	13 x 5.00-6
59A				9545-0204-00	Inner tube	Reservdel/spare par
60	2	2	2	9545-0500-00	Vallve	
61	2	2	2	1134-0341-01	Washer	
62	2	2	2	9650-0020-04	Circlip	
63	2	2	2	1134-4344-01	Hub cap	
70	1	1	1	9595-0262-00	Locating pin	
71	1	1	1	9699-0103-02	Flat washer	0.5 mm
71	1	1	1	9699-0114-02	Flat washer	1.0 mm